

[manuals.plus](#) /› [EGLO](#) /› **EGLO Kaoki LED Ceiling Light (Model 75536) Instruction Manual****EGLO 75536**

EGLO Kaoki LED Ceiling Light (Model 75536) Instruction Manual

Brand: EGLO | Model: 75536

1. INTRODUCTION

This manual provides essential information for the safe and efficient installation, operation, and maintenance of your EGLO Kaoki LED Ceiling Light, Model 75536. Please read these instructions carefully before installation and retain them for future reference.

2. SAFETY INFORMATION

- **Electrical Safety:** Installation must be performed by a qualified electrician or competent person in accordance with local electrical codes. Always disconnect power at the main circuit breaker before installation, maintenance, or bulb replacement.
- **Voltage:** This fixture is designed for 230 Volts AC. Ensure your electrical supply matches this requirement.
- **Indoor Use Only:** The fixture has an IP20 rating, indicating protection against solid objects larger than 12.5mm. It is not protected against water. Do not install in bathrooms, outdoors, or areas exposed to moisture.
- **Handling:** Handle the light fixture with care to avoid damage. Do not modify the product in any way.
- **Light Source:** The LED light source is integrated and not user-replaceable. Attempting to replace it may damage the fixture and void the warranty.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- EGLO Kaoki LED Ceiling Light Fixture (with integrated LED)
- Mounting hardware (screws, wall plugs)
- Instruction Manual

4. SETUP AND INSTALLATION

Follow these steps for proper installation. If you are unsure about any step, consult a qualified electrician.

- Disconnect Power:** Turn off the electrical power at the main circuit breaker or fuse box to avoid electric shock.
- Prepare Mounting Surface:** Ensure the ceiling surface is clean, dry, and capable of supporting the fixture's weight.
- Attach Mounting Bracket:** Secure the mounting bracket to the ceiling using the provided screws and wall plugs. Mark the drilling points carefully.
- Wire Connections:** Connect the electrical wires from the ceiling to the fixture's terminals. Typically, this involves connecting live (L), neutral (N), and ground (E) wires. Ensure all connections are secure.
- Mount the Fixture:** Carefully align the fixture with the mounting bracket and secure it in place. Some models may require twisting or screwing the fixture onto the bracket. Ensure no wires are pinched.
- Restore Power:** Once the fixture is securely mounted and all connections are checked, restore power at the circuit breaker.



This image displays a technical diagram detailing the dimensions of the EGLO Kaoki LED Ceiling Light. It shows a diameter of 31.5 cm (12.40 inches) and a height of 4.5 cm (1.77 inches), crucial for installation planning.

5. OPERATING INSTRUCTIONS

The EGLO Kaoki LED Ceiling Light is designed for simple operation via a standard wall switch.

- Turning On/Off:** Use the connected wall switch to turn the light fixture on or off.
- Light Output:** The integrated LEDs provide a pleasant neutral white light at 4000 Kelvin, with a luminous flux of 2000 lumens and a power consumption of 18 watts.
- Backlight Feature:** The fixture includes an integrated backlight that creates an indirect lighting effect, adding a subtle glow around the fixture on the ceiling.



The EGLO Kaoki LED Ceiling Light is shown installed on a ceiling in a room, demonstrating its neutral white illumination and how it integrates into a modern living space.



This image provides a side view of the installed EGLO Kaoki LED Ceiling Light, illustrating the subtle indirect backlight that creates a halo effect on the ceiling, adding to the room's ambience.

6. MAINTENANCE

To maintain the appearance and performance of your EGLO Kaoki LED Ceiling Light:

- **Cleaning:** Ensure the power is off before cleaning. Wipe the fixture with a soft, dry, or slightly damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish or electrical components.

- **No User Serviceable Parts:** The LED light source is integrated and cannot be replaced by the user. Do not attempt to disassemble the fixture.

7. TROUBLESHOOTING

If you encounter issues with your EGLO Kaoki LED Ceiling Light, consider the following:

- **Light Does Not Turn On:**

- Check if the power supply to the fixture is active at the circuit breaker.
- Ensure the wall switch is in the 'ON' position.
- Verify that all electrical connections are secure. If unsure, consult a qualified electrician.

- **Flickering Light:**

- Ensure all electrical connections are tight and properly insulated.
- Check for any loose wiring in the wall switch or junction box.

If these steps do not resolve the issue, contact customer support or a qualified electrician.

8. SPECIFICATIONS



This image displays the EGLO Kaoki LED Ceiling Light from a direct front perspective, highlighting its round, minimalist design and white finish.

Feature	Specification
Brand	EGLO
Model Number	75536

Feature	Specification
Dimensions (Diameter x Height)	31.5 cm x 4.5 cm (12.40 in x 1.77 in)
Weight	564 grams
Material	Steel and Plastic
Color	White
Light Source	Integrated LED
Power Consumption	18 Watts
Luminous Flux	2000 Lumens
Color Temperature	4000 Kelvin (Neutral White)
Voltage	230 Volts
IP Rating	IP20
Installation Type	Ceiling Mount
Special Features	Energy-saving, Indirect Backlight

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the retailer. Information regarding the availability of spare parts is not provided. For technical assistance or inquiries, please contact EGLO customer service through their official website or your point of purchase.