

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› **SteamOne** /

› **SteamOne Portable Garment Steamer SN300SB User Manual**

SteamOne SN300SB

SteamOne Portable Garment Steamer SN300SB User Manual

Model: SN300SB

1. INTRODUCTION

Thank you for choosing the SteamOne Portable Garment Steamer SN300SB. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new steamer. Please read it thoroughly before first use and keep it for future reference.



Figure 1: SteamOne Portable Garment Steamer SN300SB

2. PRODUCT FEATURES

- **Powerful Performance:** 2000 Watts for efficient steaming.
- **High Steam Output:** 30 g/min steam flow for effective wrinkle removal and disinfection.
- **Quick Heat-up:** Ready to use in just 40 seconds.
- **Large Water Tank:** Removable 300 ml capacity for up to 20 minutes of continuous steaming.
- **Disinfection:** Eliminates 99.99% of impurities with steam.
- **Portable Design:** Compact and lightweight, ideal for travel and easy storage.
- **User-Friendly:** Features an ergonomic trigger, backlit button, aluminum boiler, 2 operating modes, and an LED screen.
- **Versatile:** Suitable for various fabrics and household items.



Figure 2: Key Features of the SteamOne Steamer

3. COMPONENTS AND PARTS

The SteamOne Portable Garment Steamer consists of the following main components:

- **Steamer Head:** With steam outlets.

- **Water Tank:** Removable, with MAX/MIN fill lines.
- **Handle:** Ergonomically designed for comfortable grip.
- **Power Cord:** For electrical connection.
- **Steam Trigger:** Activates steam emission.
- **Backlit Button:** Power indicator and mode selection.
- **Bottle Connector:** Allows use with standard water bottles for extended use (included).



Figure 3: Steamer with included bottle connector

4. SETUP

1. **Fill the Water Tank:** Remove the water tank from the steamer. Fill it with distilled or demineralized water up to the 'MAX' line. Do not overfill. Reattach the tank securely.
2. **Connect to Power:** Plug the power cord into a suitable electrical outlet (230 Volts).
3. **Power On:** Press the backlit power button. The steamer will begin to heat up.

The steamer will be ready for use in approximately 40 seconds, indicated by the LED light.

5. OPERATING INSTRUCTIONS

5.1 Steaming Garments

1. **Prepare Garment:** Hang the garment on a hanger.
2. **Activate Steam:** Once heated, press and hold the steam trigger to release steam.
3. **Steam Technique:**
 - Pull the garment taut with your free hand to ensure proper steaming.
 - Ensure the steamer's soleplate is flat against the fabric.
 - Move the diffusion head from top to bottom along the fabric.
 - **Do NOT** move the diffusion head from bottom to top, as this can push wrinkles further into the fabric.

GUIDE D'UTILISATION



Tirez le vêtement vers vous pour le steamer correctement



Veillez toujours à ce que la semelle soit bien à plat sur le tissu



Déplacez toujours la tête de diffusion du haut vers le bas



Ne placez pas la tête de diffusion vers le bas

Figure 4: Correct Steaming Technique

5.2 Suitable Materials and Items

The SteamOne steamer is effective on a wide range of fabrics and household items, including:

- **Fabrics:** Jean, Silk, Wool, Lace, Flocked fabrics, Tulle, Muslin, Cotton, Sequin, Linen.
- **Items:** Tablecloths, Sofas, Cushions, Bedding, Plush toys, Towels, Carpets, Covers, Curtains.



Figure 5: Versatility for different fabrics



Figure 6: Versatility for different household items

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your steamer.

- **Empty Water Tank:** After each use, unplug the steamer and allow it to cool. Remove the water tank and empty any remaining water.
- **Clean Exterior:** Wipe the exterior of the steamer with a soft, damp cloth. Do not use abrasive cleaners.
- **Descaling (if necessary):** If you notice reduced steam output or mineral buildup, descale the steamer according to the instructions provided in the full product manual (not included here). Using distilled water will minimize mineral buildup.
- **Storage:** Store the steamer in a cool, dry place when not in use.

7. TROUBLESHOOTING

If you encounter issues with your SteamOne steamer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No steam or low steam output	Water tank empty or low Steamer not heated sufficiently Mineral buildup	Refill water tank Wait 40 seconds for heat-up Perform descaling procedure
Water leaking from steamer head	Overfilled water tank Steamer not hot enough Condensation buildup	Do not overfill tank Allow steamer to fully heat up Hold steamer upright and allow steam to flow for a few seconds before use
Steamer not turning on	Not plugged in Power outlet issue	Ensure power cord is securely plugged in Test outlet with another appliance

If the problem persists after trying these solutions, please contact SteamOne customer support.

8. SPECIFICATIONS

Feature	Specification
Brand	SteamOne
Model Number	SN300SB (PA-DEFPORTATIFS)
Power	2000 Watts
Voltage	230 Volts
Water Tank Capacity	300 Milliliters
Steam Flow	30 g/min
Heat-up Time	40 seconds
Autonomy	Up to 20 minutes
Product Dimensions (L x W x H)	25 x 17 x 15 cm
Item Weight	1.1 Kilograms
Color	Dark Black
Material	Aluminum boiler, Plastic body
Features	Portable, Compact, Ergonomic, Lightweight

9. WARRANTY AND SUPPORT

SteamOne products are designed for high efficiency and reliability. For any questions, concerns, or warranty

claims, please contact SteamOne customer service. Your satisfaction is important to us.
Please refer to your purchase documentation for specific warranty terms and conditions.

© 2024 SteamOne. All rights reserved.