



[Manuals.plus](#) /

> [Minecraft](#) /

> Minecraft TNT Block 14-Inch Desk Lamp with 3D Creeper Puller | LED Lamp

## Minecraft 16108

# Minecraft TNT Block Desk Lamp Instruction Manual

Model: 16108

## PRODUCT OVERVIEW

---

The Minecraft TNT Block Desk Lamp is a novelty lighting fixture designed for indoor use. It features a unique TNT block design with a Creeper puller for operation. This lamp is energy-efficient and comes with an LED bulb included.



Figure 1: Minecraft TNT Block Desk Lamp

This image displays the full Minecraft TNT Block Desk Lamp, showcasing its red and white TNT block shade, silver stand, and green

Creeper puller, all resting on a pixelated grass block base.

## SETUP INSTRUCTIONS

---

1. **Unpacking:** Carefully remove all components from the packaging. Ensure all parts are present: lamp base, lamp stand, TNT block shade, Creeper puller, and LED bulb.
2. **Shade Assembly:** The TNT block shade may be inverted for packaging. Gently unscrew the shade from the lamp stand, flip it to the correct upright position, and re-screw it securely onto the stand.
3. **Bulb Installation:** Insert the included E26 LED bulb into the lamp's socket. Ensure it is screwed in firmly but do not overtighten.
4. **Placement:** Place the lamp on a stable, flat tabletop surface. Ensure the power cord can reach a suitable electrical outlet without strain.
5. **Power Connection:** Plug the lamp's cord into a standard 120V AC electrical outlet.



Figure 2: Lamp Power Connection

This image shows the back of the Minecraft TNT Block Desk Lamp, highlighting the power cord extending from the base, ready for connection to an electrical outlet.

## OPERATING INSTRUCTIONS

---

The Minecraft TNT Block Desk Lamp is operated using the attached Creeper puller.

- **To Turn On:** Gently pull down on the Creeper figure attached to the ball chain. The lamp will illuminate.
- **To Turn Off:** Pull down on the Creeper figure again. The lamp will turn off.



Figure 3: Lamp in Use

This image shows the Minecraft TNT Block Desk Lamp placed on a light-colored desk, next to books and a mug, demonstrating its use as a functional and decorative item.

## MAINTENANCE

- **Cleaning:** Disconnect the lamp from the power outlet before cleaning. Wipe the lamp shade and base with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Bulb Replacement:** Ensure the lamp is unplugged and the bulb has cooled completely before attempting to replace it. Unscrew the old E26 bulb and screw in a new E26 LED bulb of appropriate wattage (max 10W).
- **General Care:** Avoid placing the lamp in direct sunlight or near heat sources. Do not expose to water or high humidity.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	<ol style="list-style-type: none"> <li>1. Lamp not plugged in.</li> <li>2. Bulb is loose or faulty.</li> <li>3. Power outlet is not functioning.</li> </ol>	<ol style="list-style-type: none"> <li>1. Ensure the lamp is securely plugged into a working electrical outlet.</li> <li>2. Check if the bulb is screwed in tightly. Replace the bulb if it is burnt out.</li> <li>3. Test the outlet with another device to confirm it has power.</li> </ol>
Lamp flickers or light is dim.	<ol style="list-style-type: none"> <li>1. Loose bulb connection.</li> <li>2. Incorrect bulb type or wattage.</li> </ol>	<ol style="list-style-type: none"> <li>1. Tighten the bulb in the socket.</li> <li>2. Ensure you are using an E26 LED bulb with a maximum of 10W.</li> </ol>

Problem	Possible Cause	Solution
Creeper puller does not activate light.	1. Internal switch mechanism issue.	1. If other troubleshooting steps fail, contact customer support.

*Note: While the product description mentions USB connectivity, this lamp is primarily designed for corded electric operation via a standard US plug (120V AC). The bulb socket is rated for up to 250V, allowing for plug modification in regions with different voltage standards, but this should only be performed by a qualified electrician.*

## SPECIFICATIONS

Feature	Detail
Model Number	16108
Brand	Minecraft
Product Dimensions (D x W x H)	7.25" x 11.7" x 7.25"
Item Weight	1.02 Pounds
Lamp Type	Desk Lamp
Light Source Type	LED
Bulb Base	E26
Max Wattage	10W
Voltage	120V AC
Power Source	Corded Electric
Switch Type	Pull Chain (Creeper Puller)
Base Material	Plastic
Shade Material	Cast, Metal, Fabric
Color	Red
Indoor/Outdoor Usage	Indoor
Special Feature	Energy Efficient
UPC	886388161089

## WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in this manual. Please refer to the product packaging or the retailer's website for details regarding warranty coverage and terms.

For technical support or further assistance, please contact the manufacturer or the point of purchase.

