

[manuals.plus](#) /› [MIFA](#) /› **MIFA X5 Truly Wireless Bluetooth Earbuds User Manual**

MIFA X5

MIFA X5 Truly Wireless Bluetooth Earbuds User Manual

Model: X5

INTRODUCTION

Thank you for choosing the MIFA X5 Truly Wireless Bluetooth Earbuds. This manual provides essential information for setting up, operating, and maintaining your earbuds to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.

PACKAGE CONTENTS

The MIFA X5 package typically includes the following items:

- MIFA X5 Truly Wireless Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- Ear Cushions (3 sizes: Small, Medium, Large)
- User Manual (this document)



Image: MIFA X5 earbuds inside their charging case, with the lid open. The earbuds have a black finish with blue LED rings.

SETUP

1. Initial Charging

Before first use, fully charge the earbuds and the charging case. Place both earbuds into the charging case. Connect the charging case to a USB power source using the provided USB cable. The indicator lights on the case will show charging status.



Image: Side view of the MIFA X5 charging case, showing the micro-USB charging port at the back.

2. Earbud Fitting

Select the ear cushions that provide the most comfortable and secure fit for your ears. A proper fit is crucial for optimal sound quality and noise isolation. Gently insert the earbuds into your ear canals and twist slightly to secure them.



Image: Close-up of a single MIFA X5 earbud, highlighting its ergonomic design and the ear tip.

3. Bluetooth Pairing

1. Ensure the earbuds are charged.
2. Open the charging case and remove both earbuds. They will automatically power on and enter pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for available Bluetooth devices and select "X5" from the list.
5. Once connected, you will hear a confirmation tone, and the earbuds' indicator lights will change.

Note: The earbuds support one-step pairing. After the initial pairing, they will automatically connect to the last paired device when removed from the case.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Remove earbuds from the charging case. They will power on automatically. Alternatively, press and hold the touch control area on both earbuds for 3 seconds.
- **Power Off:** Place earbuds back into the charging case. They will power off automatically. Alternatively, press and hold the touch control area on both earbuds for 5 seconds.

Touch Controls

The MIFA X5 earbuds feature smart touch controls for various functions:

Action	Function
Single tap (Left/Right earbud)	Play/Pause music, Answer/End call
Double tap (Right earbud)	Next track
Double tap (Left earbud)	Previous track
Triple tap (Right earbud)	Volume Up
Triple tap (Left earbud)	Volume Down
Press and hold for 2 seconds (Left/Right earbud)	Activate Voice Assistant (Siri, Google Assistant)
Press and hold for 2 seconds during incoming call	Reject call



Image: Close-up of the MIFA X5 earbuds, highlighting the circular touch-sensitive area on the outer surface.

MAINTENANCE

- **Cleaning:** Regularly clean the earbuds, especially the ear tips and charging contacts, with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Water Resistance:** The earbuds are IPX56 waterproof and sweat-proof. This means they can withstand splashes and sweat, making them suitable for workouts. However, they are not designed for submersion in water. Avoid exposing them to heavy rain or swimming.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust, damage, and to keep them charged.
- **Battery Care:** To prolong battery life, avoid fully discharging the earbuds and charging case frequently. Charge them regularly, even if not used for extended periods.

TROUBLESHOOTING

- **Earbuds not pairing:**
 - Ensure both earbuds are charged.
 - Place earbuds back in the case, close the lid, then open it and remove them again.
 - Turn off Bluetooth on your device, then turn it back on.
 - Forget "X5" from your device's Bluetooth list and attempt to pair again.
 - Ensure no other Bluetooth devices are interfering.
- **Only one earbud working:**
 - Place both earbuds back into the charging case, close the lid, and then remove them simultaneously.
 - Check if both earbuds have sufficient charge.

- Perform a factory reset (refer to manufacturer's specific instructions if available, otherwise try holding touch areas for 10+ seconds while in case).

- **Poor sound quality or disconnections:**

- Ensure the earbuds are fully charged.
- Reduce the distance between the earbuds and your device.
- Avoid obstacles between the earbuds and your device.
- Clean any debris from the earbud speakers.

- **Earbuds not charging:**

- Ensure the charging cable is securely connected to both the case and the power source.
- Check if the charging contacts on the earbuds and inside the case are clean and free of debris.
- Try a different USB cable or power adapter.

SPECIFICATIONS

Feature	Detail
Model Number	X5
Wireless Communication Technology	Bluetooth 5.0
Ear Placement	In Ear
Form Factor	In Ear
Control Method	Touch
Microphone Format	Built-In
Water Resistance Level	IPX56 Waterproof
Material	Plastic
Item Weight	150 g (total package weight)
Playtime	Up to 30 hours (with charging case)

WARRANTY INFORMATION

The MIFA X5 Truly Wireless Bluetooth Earbuds come with a **1 Year Warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For further assistance, technical support, or warranty claims, please contact MIFA customer service through their official website or the retailer from whom you purchased the product. Please have your product model number (X5) and proof of purchase ready when contacting support.

Official MIFA Website: www.mifa.net

