

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [DeLUX](#) /

› [DeLUX M618ZD Left-Handed Ergonomic Vertical Mouse User Manual](#)

DeLUX M618ZD

DeLUX M618ZD Left-Handed Ergonomic Vertical Mouse User Manual

Model: M618ZD



1. INTRODUCTION

This manual provides detailed instructions for the DeLUX M618ZD Left-Handed Ergonomic Vertical Mouse. Designed for left-handed users, this mouse promotes a natural handshake posture to reduce wrist strain and discomfort during prolonged use. It features versatile connectivity options, adjustable DPI settings, and a rechargeable battery for enhanced productivity and comfort.



The DeLUX M618ZD Left-Handed Ergonomic Vertical Mouse, designed for comfort and efficiency.



Traditional Grip

Uncomfortable posture causes nerve compression and pain in the hand



Natural Handshake Posture

Reduce carpal tunnel syndrome and tenosynovitis efficiently.

Comparison illustrating the ergonomic benefits of the natural handshake posture provided by the vertical mouse, reducing wrist pressure compared to a traditional grip.

2. SETUP

2.1 Package Contents

- DeLUX M618ZD Left-Handed Ergonomic Vertical Mouse
- USB Nano Receiver (stored in the mouse bottom)
- USB-C Charging Cable
- User Manual (this document)

2.2 Initial Charging

Before first use, it is recommended to fully charge the mouse. Connect the provided USB-C charging cable to the charging port on the front of the mouse and to a USB power source. A full charge typically takes approximately two hours. The LED indicator will show charging status.

500mAh Rechargeable Battery


One full charge, 2 weeks of operating.



The DeLUX M618ZD mouse connected to a charging cable, illustrating its 500mAh rechargeable battery feature.

2.3 Connecting the Mouse

The M618ZD mouse supports both 2.4G wireless and Bluetooth connectivity. You can switch between these modes using the mode switch button located on the bottom of the mouse.



Multi-Device Workflow

Press the bottom mode switch button to easily switch.



Multi-System compatibility

The bottom of the mouse with the mode switch button (labeled 1 for 2.4G) and the USB Nano Receiver storage slot, demonstrating multi-device workflow and multi-system compatibility.

2.3.1 2.4G Wireless Connection

1. Locate the USB Nano Receiver stored in the compartment on the bottom of the mouse.
2. Plug the USB Nano Receiver into an available USB port on your computer.
3. Slide the mode switch on the bottom of the mouse to the '2.4G' position.
4. The mouse should automatically connect to your computer.

2.3.2 Bluetooth Connection

1. Slide the mode switch on the bottom of the mouse to the 'BT' position.
2. On your computer or device, open Bluetooth settings.
3. Search for new devices and select 'DeLUX M618ZD' from the list.
4. Follow any on-screen prompts to complete the pairing process.

3. OPERATING THE MOUSE

3.1 Button Functions

The DeLUX M618ZD features 6 buttons for various functions:

- **Left Click Button:** Primary function.
- **Right Click Button:** Secondary function.
- **Scroll Wheel:** Scroll up/down, and middle click.
- **DPI Button:** Adjusts cursor sensitivity.
- **Forward Button:** Navigates forward in web browsers or file explorers.
- **Backward Button:** Navigates backward in web browsers or file explorers.



Quiet Clicks

Work with less distractions.

A left hand comfortably gripping the DeLUX M618ZD vertical mouse, showcasing the natural handshake posture and button placement.



Comfy Thumb And Pinky Rest

Detail of the mouse highlighting the comfortable thumb and pinky finger rest areas, designed for improved grip and reduced strain.

3.2 DPI Adjustment

The mouse features five adjustable DPI settings: 800, 1200, 1600, 2400, and 4000. Press the DPI button, located above the backward button, to cycle through these settings. Each press will change the cursor speed, allowing you to select the sensitivity that best suits your needs.

**LESS MOVEMENT,
LESS FATIGUE.**

up to 4000 DPI, easy adjustment.



5 adjustable DPI

Illustration of the 5 adjustable DPI settings (800, 1200, 1600, 2400, 4000) and the location of the DPI button for easy adjustment, promoting less movement and less fatigue.

3.3 Quiet Clicks

The DeLUX M618ZD is designed with quiet click buttons, minimizing noise during operation to reduce distractions in quiet environments.



Visual representation of the quiet click feature, indicating noise-free operation for a less distracting work environment.

3.4 Compatibility

The mouse is compatible with Windows 7/8/10 and Mac OS. Please note that for Mac systems, the forward and backward buttons may have limited functionality or require custom software/settings to operate as intended.

4. MAINTENANCE

4.1 Battery Management

The built-in 500mAh Polymer Li-ion battery provides stable use for approximately one week (8 hours/day) on a two-hour full charge. The mouse features an auto energy-saving sleep mode to conserve power, extending battery life to about one month under normal usage patterns. Recharge the mouse when the battery indicator light signals low power or when performance decreases.

4.2 Cleaning

To clean the mouse, gently wipe its surface with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, ensuring no moisture enters the internal components. Avoid using harsh chemicals or abrasive materials.

4.3 Storage

When not in use for extended periods, store the mouse in a cool, dry place. If storing for a long time, ensure the battery is partially charged (around 50%) to maintain battery health.

5. TROUBLESHOOTING

• Mouse not responding:

- Ensure the mouse is charged. Connect it to a power source using the USB-C cable.
- Check the mode switch on the bottom of the mouse. Ensure it is set to the correct connection mode (2.4G or BT).
- For 2.4G mode, ensure the USB Nano Receiver is securely plugged into a working USB port.
- For Bluetooth mode, verify that Bluetooth is enabled on your device and the mouse is paired correctly. Try re-pairing if necessary.

- **Cursor movement is erratic or slow:**

- Adjust the DPI setting using the DPI button on the mouse.
- Ensure the mouse sensor is clean and free from obstructions.
- Use the mouse on a suitable surface (e.g., a mouse pad).

- **Connectivity issues (disconnections):**

- Move the mouse closer to the USB receiver or Bluetooth-enabled device to reduce interference.
- Avoid using the mouse near strong electromagnetic interference sources.
- Ensure your device's drivers are up to date.

- **Forward/Backward buttons not working on Mac:**

- This is a known limitation. Some Mac applications or system settings may not fully support these buttons without third-party software or specific configuration.

6. SPECIFICATIONS

Feature	Detail
Brand	DeLUX
Model Number	M618ZD
Product Dimensions	4.02 x 3.46 x 2.68 inches (103 x 89 x 69 mm)
Item Weight	4.2 ounces
Connectivity Technology	2.4G Wireless, Bluetooth
Movement Detection Technology	Optical
DPI Settings	800/1200/1600/2400/4000
Battery	500mAh Polymer Li-ion (Rechargeable, included)
Special Features	Ergonomic Design, Rechargeable, Silent Clicks



Vertical Mouse for Small Hands

Detailed dimensions of the DeLUX M618ZD vertical mouse: 103mm length, 89mm width, 69mm height.

7. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official DeLUX website or contact the seller directly. Keep your purchase receipt for warranty claims.