

Arkrocket ARK-01-PK

Arkrocket Discovery 3-Speed Bluetooth Record Player User Manual

Model: ARK-01-PK

1. INTRODUCTION

Thank you for purchasing the Arkrocket Discovery 3-Speed Bluetooth Record Player. This retro console turntable is designed to provide a high-quality audio experience with the convenience of modern technology. It features built-in speakers, Bluetooth connectivity, and removable legs for versatile placement. This manual provides essential information for the safe and proper operation of your new record player.





Figure 1: Arkrocket Discovery 3-Speed Bluetooth Record Player with removable legs.

2. SAFETY INFORMATION

- Read all instructions before using the product.
- Keep this manual for future reference.
- Do not expose the unit to rain or moisture.
- Do not block any ventilation openings.
- Use only attachments/accessories specified by the manufacturer.
- Unplug the unit during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.

3. PACKAGE CONTENTS

Verify that all items are included in the package:

- Turntable unit
- Power adapter
- 7-inch adapter
- User manual
- Removable legs (4)

4. PRODUCT OVERVIEW



Figure 2: Close-up view of the turntable platter and tonearm with the Rocket Moving Magnet Cartridge.



Figure 3: Detailed view of the control panel, including volume, mode selection, and headphone jack.





Figure 4: Rear view of the unit showing the RCA output ports for external connection.

5. SETUP

5.1 Attaching the Legs

1. Carefully unpack the turntable and the four removable legs.
2. Place the turntable upside down on a soft, stable surface to avoid scratching the finish.
3. Align each leg with the designated screw holes on the bottom corners of the turntable.
4. Securely screw each leg into place. Do not overtighten.
5. Carefully turn the turntable upright and place it on a level surface.

5.2 Power Connection

Connect the provided power adapter to the DC input jack on the rear of the turntable and then plug the adapter into a wall outlet.

5.3 External Audio Connection (Optional)

To connect the Discovery turntable to an external stereo system or powered speakers, use RCA cables

(not included) to connect the RCA outputs on the rear of the turntable to the corresponding inputs on your audio system.

6. OPERATING INSTRUCTIONS

6.1 Playing a Record

1. Open the lid of the turntable.
2. Place a record on the platter. If playing a 7-inch single, use the included 7-inch adapter.
3. Select the appropriate speed (33 1/3, 45, or 78 RPM) using the speed selector switch.
4. Carefully move the tonearm from its rest and position the stylus over the desired groove of the record.
5. Gently lower the tonearm onto the record. The platter will begin to spin and audio will play through the built-in speakers.
6. Adjust the volume using the volume knob on the control panel.
7. At the end of the record, the tonearm will automatically return to its rest (auto-stop feature).

Your browser does not support the video tag.

Video 1: Demonstration of playing a record on the Arkrocket Discovery turntable.

6.2 Bluetooth Operation

The Arkrocket Discovery features a built-in Bluetooth receiver, allowing you to stream music wirelessly from your compatible device to the turntable's speakers.

1. Turn on the turntable and select the 'BT' mode using the mode selector knob. The Bluetooth indicator light will begin to flash, indicating pairing mode.
2. On your Bluetooth-enabled device (e.g., smartphone, tablet), enable Bluetooth and search for available devices.
3. Select "ARKROCKET" from the list of devices. Once connected, the Bluetooth indicator light will stop flashing and remain solid.
4. You can now play audio from your device through the turntable's speakers. Adjust volume using both your device and the turntable's volume knob.

6.3 Auxiliary Input

To play audio from a non-Bluetooth device, connect it to the 'AUX IN' port on the control panel using a 3.5mm audio cable (not included). Select 'AUX' mode using the mode selector knob.

6.4 Headphone Output

For private listening, plug headphones into the headphone jack on the control panel. The built-in speakers will be muted when headphones are connected.

7. MAINTENANCE

7.1 Cleaning the Unit

- Wipe the exterior of the unit with a soft, dry cloth.
- Do not use harsh chemicals or abrasive cleaners.

- Keep the dust cover closed when not in use to prevent dust accumulation on the platter and stylus.

7.2 Stylus Care

- The stylus (needle) is a delicate component. Handle with care.
- Clean the stylus periodically using a soft brush, brushing gently from back to front.
- Replace the stylus if you notice a decrease in sound quality or visible damage.

8. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---------------------------------|--|---|
| No power | Power adapter not connected; outlet not active | Ensure power adapter is securely connected and plugged into a working outlet. |
| No sound from speakers | Volume too low; wrong mode selected; headphones connected | Increase volume; select correct mode (PH/BT/AUX); disconnect headphones. |
| Record skips or distorted sound | Record dirty/damaged; stylus dirty/worn; unit not level | Clean record; clean or replace stylus; ensure unit is on a level surface. |
| Bluetooth not connecting | Turntable not in BT mode; device not in pairing mode; interference | Select BT mode; ensure device Bluetooth is on and searching; move closer to unit. |

9. SPECIFICATIONS

| Feature | Detail |
|--------------------------|--|
| Model Name | Discovery II |
| Item Model Number | ARK-01-PK |
| Product Dimensions | 13.9 x 15.8 x 35.7 inches |
| Item Weight | 17 pounds |
| Color | Pink |
| Material | PU Leather, Plastic, Wood |
| Connectivity Technology | Auxiliary, Bluetooth, RCA |
| Maximum Rotational Speed | 78 RPM |
| Special Features | Built-in Speaker, Built-In Bluetooth Receiver, Moving magnet cartridge |

10. WARRANTY AND SUPPORT

This product comes with a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, troubleshooting assistance, or warranty

claims, please contact Arkrocket customer service through the contact information provided on the warranty card or the official Arkrocket website.

© 2024 Arkrocket. All rights reserved.