

[Manuals.plus](#) /

› [GUY-TECH](#) /

› GUY-TECH AC Adapter for Nix X08D, X08E Digital Photo Frame User Manual

## GUY-TECH AC Adapter for Nix X08D, X08E

# GUY-TECH AC Adapter User Manual

For Nix X08D, X08E 8-inch Digital Photo Frames

## INTRODUCTION

---

This manual provides essential instructions for the safe and effective use of your GUY-TECH AC Adapter. This adapter is specifically designed as a compatible replacement power supply for Nix X08D and X08E 8-inch Digital Photo Frames. Please read this manual thoroughly before use and retain it for future reference.

## IMPORTANT SAFETY INFORMATION

---

- This product is intended for indoor use only. Do not expose to rain, moisture, or extreme temperatures.
- Keep the adapter and cable away from water, heat sources, and sharp objects.
- Ensure the adapter is connected to a power outlet within the specified voltage range (100V-240V).
- Do not attempt to disassemble or modify the adapter. This may cause damage and void any warranty.
- Disconnect the adapter from the power outlet when not in use for extended periods.
- If the adapter or cable appears damaged, discontinue use immediately and seek a replacement.

## PACKAGE CONTENTS

---

- 1 x GUY-TECH AC Adapter

## SETUP INSTRUCTIONS

---

1. Ensure your Nix X08D or X08E digital photo frame is powered off before connecting the adapter.
2. Locate the DC input port on your digital photo frame.
3. Connect the barrel connector end of the GUY-TECH AC Adapter cable firmly into the DC input port of the photo frame.
4. Plug the AC adapter's wall plug into a standard electrical outlet (100V-240V).
5. You may now power on your digital photo frame.

## OPERATING INSTRUCTIONS

---

Once properly connected to both the digital photo frame and a power outlet, the GUY-TECH AC Adapter will automatically supply the necessary power to your device. The adapter is designed for continuous operation when the photo frame is in use.

This adapter features an integrated LED indicator light. When the adapter is successfully plugged into a live power outlet and functioning, the LED light will illuminate, providing a visual confirmation of power delivery.



This image highlights two key features of the GUY-TECH AC adapter: its 5-foot cable length, providing ample reach, and the integrated LED indicator light, which confirms the adapter is receiving power and operating correctly.

## MAINTENANCE AND CARE

---

- To clean the adapter, gently wipe it with a dry, soft cloth. Do not use liquid cleaners or abrasive materials.
- Avoid bending or twisting the cable excessively, especially near the connectors, to prevent internal damage.
- Store the adapter in a cool, dry place when not in use.

## TROUBLESHOOTING

---

### No Power to Photo Frame

- Ensure the AC adapter is securely plugged into both the wall outlet and the digital photo frame.
- Check if the wall outlet is functional by plugging in another device.

- Verify that the LED indicator on the adapter is lit. If not, check the power source.

## LED Indicator Not Lit

- Confirm the adapter is fully inserted into a working electrical outlet.
- Inspect the cable for any visible damage. If damaged, discontinue use.

## SPECIFICATIONS

Feature	Detail
Input Voltage	100V - 240V (Worldwide)
Output Voltage	5 Volts (DC)
Cable Length	5 Feet
Connector Type	Barrel Connector
Compatible Devices	Nix X08D, Nix X08E Digital Photo Frames
Special Features	Over Voltage Protection, Over Current Protection, Short Circuit Protection, LED Indicator
Item Weight	5 Ounces

## WARRANTY AND SUPPORT

For information regarding product warranty or technical support, please refer to the documentation provided at the time of purchase or contact your retailer. You may also visit the GUY-TECH official website for further assistance.