

- › [Amazon Basics](#) /
- › [Amazon Basics 6-Button Ergonomic 2.4GHz Wireless Mouse User Manual](#)

## Amazon Basics G6K-B01

# Amazon Basics 6-Button Ergonomic 2.4GHz Wireless Mouse User Manual

Model: G6K-B01

### PRODUCT OVERVIEW

The Amazon Basics 6-Button Ergonomic 2.4GHz Wireless Mouse is designed for comfortable and precise navigation. It features a large-size ergonomic grip with a thumb rest, making it suitable for extended use. This mouse operates on a 2.4GHz wireless connection and is compatible with both Windows and Mac OS.

It includes six buttons for dynamic usability: left click, right click, middle click (integrated into the scroll wheel), forward and backward buttons (located on the left side), and a DPI switch button for adjusting sensitivity.



Image: Front-right view of the Amazon Basics 6-Button Ergonomic 2.4GHz Wireless Mouse, showcasing its black finish and ergonomic shape.

## WHAT'S IN THE BOX

---

Upon unboxing, ensure all components are present:

- 1 x Amazon Basics 6-Button Ergonomic 2.4GHz Wireless Mouse
- 1 x USB Nano Receiver
- 2 x AAA Batteries



Image: The contents of the package laid out, including the wireless mouse (bottom view with battery compartment open), two AAA batteries, and the USB Nano receiver.

## SETUP GUIDE

1. **Insert Batteries:** Open the battery compartment on the underside of the mouse. Insert the two included AAA batteries, ensuring correct polarity (+/-). Close the battery compartment.



Image: Underside of the mouse, showing the battery compartment, optical sensor, and the On/Off switch.

2. **Connect USB Nano Receiver:** Locate an available USB port on your computer (Windows or Mac OS). Insert the USB Nano receiver into the USB port. The system should automatically detect and install the necessary drivers.
3. **Power On:** Slide the On/Off switch located on the underside of the mouse to the "On" position. The mouse is now ready for use.

## OPERATING INSTRUCTIONS

### Button Functions

- **Left Click:** Standard selection and activation.
- **Right Click:** Opens context menus.
- **Middle Click (Scroll Wheel):** Activates auto-scroll or opens links in new tabs, depending on application.
- **Forward Button (Left Side):** Navigates forward in web browsers or file explorers.

- **Backward Button (Left Side):** Navigates backward in web browsers or file explorers.
- **DPI Switch Button:** Adjusts mouse sensitivity.

## DPI Adjustment

The mouse offers 3 adjustable sensitivity levels: 800, 1200, or 1600 DPI (Dots Per Inch). Press the DPI switch button, located behind the scroll wheel, to cycle through these settings. A higher DPI setting results in faster cursor movement across the screen for the same physical mouse movement.



Image: Top-down view of the mouse, highlighting the scroll wheel, left and right click buttons, and the DPI switch button.

## MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the mouse. For the optical sensor, use a cotton swab lightly dampened with rubbing alcohol, ensuring no liquid enters the mouse.
- **Battery Replacement:** When the mouse performance degrades or it becomes unresponsive, replace the AAA batteries. The approximate battery life is 3.3 months with average daily use (2 hours/day, 20 working days/month).
- **Storage:** When not in use for extended periods, slide the On/Off switch to the "Off" position to conserve battery life.

## TROUBLESHOOTING

Problem	Solution
---------	----------






Problem	Solution
Mouse is unresponsive.	<ul style="list-style-type: none"><li>• Ensure the mouse is powered on.</li><li>• Check if the USB Nano receiver is securely plugged into a working USB port.</li><li>• Replace the AAA batteries.</li><li>• Try plugging the USB Nano receiver into a different USB port.</li></ul>
Cursor movement is erratic or slow.	<ul style="list-style-type: none"><li>• Clean the optical sensor on the underside of the mouse.</li><li>• Ensure you are using the mouse on a suitable surface (non-reflective, non-transparent).</li><li>• Adjust the DPI setting using the DPI switch button.</li></ul>
Mouse goes to sleep frequently.	The mouse is designed to enter sleep mode after being idle for 5 minutes to conserve battery life. Move the mouse or click a button to wake it up.

## SPECIFICATIONS

Feature	Detail
Model Number	G6K-B01
Connectivity	2.4GHz Wireless (USB Nano Receiver)
Number of Buttons	6 (Left, Right, Middle, Forward, Backward, DPI Switch)
DPI Levels	800, 1200, 1600
Power Source	2 x AAA Batteries
Approx. Battery Life	3.3 months (based on 2 hours/day, 20 working days/month)
Operating System Compatibility	Windows, Mac OS
Dimensions (LxWxH)	4.57 x 3.24 x 2.1 inches (11.63 x 8.25 x 5.34 cm)
Weight	4.8 ounces
Color	Black





	<p><a href="#">Amazon Basics ABIM03 Wired Mouse User Manual   Features, Installation, Warranty, E-Waste Disposal</a></p> <p>Official user manual for the Amazon Basics ABIM03 Wired Mouse. Find detailed information on product features, step-by-step installation, warranty terms, service information, and responsible e-waste disposal guidelines.</p>
	<p><a href="#">Amazon Basics Ergonomic Wireless Mouse - DPI Adjustable User Guide</a></p> <p>Learn how to set up and use your Amazon Basics Ergonomic Wireless Mouse with DPI adjustment. This guide covers parts, setup, operation, specifications, safety, and disposal.</p>
	<p><a href="#">Amazon Basics Ergonomic Wireless Mouse User Manual and Specifications</a></p> <p>This document provides the user manual, setup instructions, specifications, and safety information for the Amazon Basics Ergonomic Wireless Mouse, featuring DPI adjustable settings and multiple language support.</p>
	<p><a href="#">Amazon Basics Wireless Mouse User Manual and Guide</a></p> <p>Explore the Amazon Basics Wireless Mouse user manual for detailed setup, operation, safety, and maintenance instructions. Available in multiple languages, this guide ensures optimal use of your device.</p>
	<p><a href="#">Amazon Basics Ergonomic Wireless Keyboard and Mouse Combo User Guide</a></p> <p>Comprehensive user guide for the Amazon Basics Ergonomic Wireless Keyboard and Mouse Combo (HM8190US/CA, HK8013US/CA). Includes setup instructions, pairing guide, parts list, LED indicator information, cleaning and maintenance tips, safety compliance, and technical specifications.</p>