

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Tylza](#) /

› [Tylza TYBC120-A 24-Inch Dual Zone Wine and Beverage Refrigerator Instruction Manual](#)

## Tylza TYBC120-A

# Tylza TYBC120-A 24-Inch Dual Zone Wine and Beverage Refrigerator Instruction Manual

Model: TYBC120-A

## 1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Tylza TYBC120-A 24-inch Dual Zone Wine and Beverage Refrigerator. This appliance features two independent cooling zones, allowing for optimal storage of both wine and beverages. The left zone maintains temperatures between 35-50°F for beverages, while the right zone is designed for wine storage at 41-64°F. It offers a capacity for up to 18 standard 750ml wine bottles and 57 standard 12oz beverage cans. Please read this manual thoroughly before use to ensure safe and efficient operation.



Image 1.1: Front view of the Tylza 24-inch Dual Zone Wine and Beverage Refrigerator, showcasing its dual glass doors and stainless steel finish.

## 2. IMPORTANT SAFETY INFORMATION

To reduce the risk of fire, electric shock, or injury when using your appliance, follow these basic precautions:

- Read all instructions before using the appliance.
- Connect to a properly grounded outlet only.

- Do not remove the grounding prong, bypass the grounding adapter, or use an extension cord.
- Unplug the appliance before cleaning or making any repairs.
- Do not use flammable fluids near the appliance.
- Ensure proper ventilation; keep ventilation openings clear of obstruction.
- Do not damage the refrigerant circuit.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- The appliance is equipped with a door key lock on the bottom to prevent unauthorized access, especially by children. Always keep keys out of reach of children.



Image 2.1: Close-up of the safety lock mechanism located at the bottom of the refrigerator door, designed to secure contents and prevent accidental opening.

### 3. PACKAGE CONTENTS

Verify that all components are present upon unpacking:

- Tylza Wine and Beverage Refrigerator (Model TYBC120-A)
- Instruction Manual
- Keys for door lock
- Wooden Wine Shelves
- Glass Beverage Shelves

### 4. INSTALLATION

#### 4.1 Location Requirements

Place the appliance on a flat, solid surface strong enough to support it when fully loaded. Ensure adequate ventilation around the unit. Avoid direct sunlight or heat sources.

#### 4.2 Built-In or Freestanding Installation

The Tylza TYBC120-A is designed for both built-in under-counter installation and freestanding use.

- **Built-in Installation:** Requires a space of approximately 34.25 inches (height) x 23.42 inches (width) x 22.63 inches (depth). Ensure sufficient clearance for the front ventilation grille. The maximum door opening angle for built-in installation is 180 degrees.
- **Freestanding Installation:** Allows for a maximum door opening angle of 225 degrees. Ensure at least 2-3 inches of clearance on the sides and back for proper air circulation.



Image 4.1: Visual representation of the refrigerator installed as a built-in unit under a counter and as a freestanding appliance.

### 4.3 Leveling the Appliance

Adjust the leveling legs at the bottom of the unit to ensure it is stable and level. This is crucial for proper door alignment and efficient operation.

### 4.4 Electrical Connection

Plug the appliance into a dedicated, grounded 115 Volt, 60 Hz AC outlet. Do not use extension cords or adapter plugs.



Image 4.2: Detailed diagram illustrating the dimensions of the refrigerator: 34.3 inches height, 23.4 inches width, and 22.6 inches depth.

## 5. OPERATION

### 5.1 Control Panel Overview

The appliance features an easy-to-use touch screen control panel located above each door.

# 24" Dual Zones Wine & Beverage Cooler



Image 5.1: Close-up of the touch control panel, showing buttons for light, temperature adjustment (up/down), temperature display, unit switch (°C/°F), and power on/off.

## 5.2 Setting Temperatures

Each zone has independent temperature controls.

- **Beverage Zone (Left):** Temperature range 35-50°F (2-10°C). Use the+ and - buttons on the left panel to adjust.
- **Wine Zone (Right):** Temperature range 41-64°F (5-18°C). Use the+ and - buttons on the right panel to adjust.
- Press the **Lock** button to prevent accidental temperature changes.
- Press the **Unit Switch** button to toggle between Fahrenheit (°F) and Celsius (°C).



Image 5.2: Illustration detailing the independent temperature zones: Beverage Zone (left) with a range of 35-50°F and Wine Zone (right) with a range of 41-64°F.

### 5.3 Interior Lighting

Press the **Light** button on the control panel to turn the white LED interior light on or off.

### 5.4 Shelf Adjustment

The shelves are adjustable to accommodate various bottle and can sizes. Carefully slide shelves out and reposition them as needed.



Image 5.3: The interior of the refrigerator with adjustable shelves, demonstrating how they can be configured to suit different storage needs for bottles and cans.

### 5.5 Power Failure Protection

In the event of a power failure, the unit is designed to automatically restore to its previous settings once power is re-established.



Image 5.4: Graphic illustrating the power failure protection feature, where the unit automatically turns on and restores settings after a power outage.

## 6. MAINTENANCE

### 6.1 Cleaning the Interior

Unplug the appliance before cleaning. Use a soft cloth and a mild, non-abrasive cleaning solution to wipe down the interior surfaces. Avoid harsh chemicals or abrasive cleaners.

### 6.2 Cleaning the Exterior

Clean the exterior with a soft cloth and a mild detergent. For stainless steel surfaces, use a stainless steel cleaner and polish in the direction of the grain.

### 6.3 Auto-Defrost Function

The refrigerator features an automatic defrost cycle that runs every 6 hours. During this cycle, frost on the evaporator is melted and the water drains into a tray at the back of the unit, where it evaporates. No manual defrosting is required.

### 6.4 Power Saving Tips

- Ensure the appliance is located in the coolest part of the room, away from heat-producing appliances or heating ducts, and out of direct sunlight.
- Avoid opening the doors too frequently or for extended periods.
- Ensure the doors close completely and the seals are intact.



Image 6.1: An Energy Guide label for the Tylza refrigerator, indicating an estimated yearly energy cost of \$19 and 162.2 kWh consumption.

## 7. TROUBLESHOOTING

Review the following common issues and solutions before contacting customer service.

Problem	Possible Cause	Solution
Appliance does not operate	Not plugged in; circuit breaker tripped; power outage.	Ensure plug is secure; check circuit breaker; verify power supply.
Temperature is not cold enough	Temperature setting too high; door not closed properly; excessive door openings; warm items added recently; poor ventilation.	Lower temperature setting; ensure door is sealed; reduce door openings; allow time for new items to cool; ensure proper clearance around unit.
Excessive vibration	Appliance is not level.	Adjust leveling legs to ensure the unit is stable.
Noise level is high	Normal compressor operation; fan obstruction; unit not level.	Some noise is normal (under 38 dB); check for obstructions around fans; level the unit.
Door does not close properly	Appliance not level; door gasket dirty or damaged; shelves are out of position.	Level the unit; clean or replace door gasket; ensure shelves are correctly inserted.

## 8. SPECIFICATIONS

Feature	Detail
Brand	Tylza
Model Number	TYBC120-A
Product Dimensions (D x W x H)	22.63 x 23.42 x 34.25 inches
Item Weight	101 pounds
Capacity	4.42 Cubic Feet (approx. 18 wine bottles & 57 cans)
Noise Level	38 Decibels
Installation Type	Built-in or Freestanding
Form Factor	French Door
Voltage	115 Volts
Wattage	120 watts
Defrost System	Frost Free (Auto-Defrost)
Door Material Type	Stainless Steel / Glass
Shelf Type	Wooden Wine Shelves + Glass Beverage Shelves
Certification	ETL, DOE

# LOW NOISE PERFORMANCE



Noise < 42DB



ETL Listed



Safety Lock



Energy Saving



Upgraded  
Compressor



Environmental  
Protection



Image 8.1: Visual summary of key features including low noise operation (under 42dB), ETL listing, safety lock, energy saving, upgraded compressor, and environmental protection.

# Upgrade Compressor & Air Cooling Technology



Image 8.2: Illustration of the advanced air-cooling circulation system and upgraded compressor technology, highlighting efficient, quiet, and low-vibration cooling.

## 9. WARRANTY AND CUSTOMER SUPPORT

### 9.1 Return Policy

The product comes with a 30-day return policy for refund or replacement.

### 9.2 Quality Assurance

If the product fails due to quality-related issues within 12 months from the date of purchase, Tylza will provide a replacement or full refund.

### 9.3 Contact Customer Support

For any questions, inquiries, or concerns, please contact Tylza customer service. They aim to respond within 24 hours.

- **Phone:** 1-213-352-5535 (US Mon-Sat 10am - 6pm PST)

- **Email:** [support@itylza.com](mailto:support@itylza.com)

