

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Dreo](#) /

> [Dreo Tower Fan Cruiser Pro T1 User Manual](#)

Dreo Cruiser Pro T1

Dreo Tower Fan Cruiser Pro T1 User Manual

Model: Cruiser Pro T1

IMPORTANT SAFETY INSTRUCTIONS

Please read this manual carefully before use and keep it for future reference. Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Do not operate any fan with a damaged cord or plug.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- Do not use the fan in wet or damp locations such as bathrooms.
- Always place the fan on a stable, flat, and dry surface.
- Unplug the fan from the outlet when not in use, when moving it from one location to another, and before cleaning.

PRODUCT OVERVIEW



Figure 1: Dreo Tower Fan Cruiser Pro T1 and its remote control.

The Dreo Tower Fan Cruiser Pro T1 is designed to provide powerful and quiet airflow for your home or office. It features multiple speed settings, operating modes, oscillation, and a convenient timer function.

Package Contents:

- Dreo Tower Fan Unit
- Base (2 parts)
- Remote Control
- User Manual

ASSEMBLY

Assembly of the Dreo Tower Fan is quick and requires no tools.

1. Align the two halves of the base and snap them together.
2. Align the assembled base with the bottom of the fan unit.
3. Gently push the fan unit onto the base until it clicks securely into place. No screws or tools are needed for this step.

OPERATING INSTRUCTIONS

Power On/Off

Plug the fan into a standard electrical outlet. Press the Power button on the control panel or remote control to turn the fan on or off.

Adjusting Fan Speeds

Peaceful Nights Start with Silent Breeze



*Test conducted internally by Dreo's lab at the lowest setting.

Figure 2: The fan offers 6 speed levels for personalized cooling.

The fan offers 6 speed levels. Press the Speed button (+ or -) on the control panel or remote to increase or decrease the airflow intensity.

Selecting Operating Modes

Set the Perfect Wind in Every Situation



Figure 3: Choose from 4 distinct operating modes.

Press the Mode button on the control panel or remote to cycle through the 4 available modes:

- **Normal Mode:** Provides constant airflow at the selected speed.
- **Natural Mode:** Simulates natural breeze by varying fan speeds.
- **Sleep Mode:** Gradually decreases fan speed and dims the display for quiet, undisturbed sleep. Operates at an ultra-quiet 28dB.
- **Auto Mode:** Adjusts fan speed automatically based on the ambient room temperature.

Oscillation Function



Figure 4: The fan oscillates 90 degrees for wide coverage.

Press the Oscillation button (~) on the control panel or remote to activate or deactivate the 90° oscillation feature, allowing the fan to sweep air across a wider area.

Setting the Timer

The fan features a 12-hour timer. Press the Timer button (⌚) repeatedly to set the desired operating duration in 1-hour increments. The fan will automatically turn off once the set time has elapsed.

Quiet Operation for Sleep

The Dreo Difference

High-torque motor provides faster air circulation, and super-precision bearing minimizes resistance at all speeds.



Figure 5: Enjoy peaceful nights with ultra-quiet operation at 28dB.

The Dreo Tower Fan is engineered for quiet performance, operating as low as 28dB in Sleep mode, ensuring minimal disturbance for a restful night.

Official Product Video

Video 1: Official product video showcasing the Dreo Tower Fan Cruiser Pro T1 features and benefits.



Detachable Design. Clean in a Breeze.

Figure 6: The fan features a detachable design for easy cleaning of the impeller.

Regular cleaning helps maintain optimal performance. The fan features a detachable design for easy access to the impeller.

1. Unplug the fan before cleaning.
2. Carefully detach the rear grille and remove the impeller.
3. Wipe the fan's exterior with a soft, damp cloth. For the impeller, you can rinse it under water or wipe it clean.
4. Ensure all parts are completely dry before reassembling and operating the fan.

SPECIFICATIONS

Feature	Specification
Brand	Dreo
Model	Cruiser Pro T1
Color	Black
Electric Fan Design	Floor Fan
Power Source	Corded Electric
Product Dimensions	12.72"D x 12.72"W x 41.89"H
Special Feature	6 Speeds, 4 Modes, 12H Timer, 90° Oscillation
Noise Level	28 dB
Recommended Uses	Ventilating, Cooling, Air Circulation

TROUBLESHOOTING

If you encounter any issues with your Dreo Tower Fan, please refer to the following common troubleshooting steps:

- **Fan does not turn on:** Ensure the power cord is securely plugged into a working outlet. Check if the power button is pressed.
- **Weak airflow:** Verify the fan speed setting is at a higher level. Ensure the air intake and outlet are not obstructed.
- **Unusual noise:** Check for any foreign objects caught in the fan grille or impeller. Ensure the fan is placed on a stable, flat surface.
- **Remote control not working:** Replace the remote control battery. Ensure there are no obstructions between the remote and the fan.

For further assistance, please contact Dreo Customer Support.

WARRANTY AND SUPPORT

Dreo provides a warranty for this product. Please refer to the warranty card included in your package for detailed terms and conditions.

For product support, spare parts, or any inquiries, please visit the official Dreo store or contact their customer service team.

[Visit the Official Dreopedia Store](#)