

## Vikefon Type C 0129

# Vikefon Type C Charging and Data Cable User Manual

Model: Type C 0129

## INTRODUCTION

---

This manual provides essential instructions for the proper use and maintenance of your Vikefon Type C Charging and Data Cable. This 1-meter cable is designed for efficient charging and high-speed data transfer between your Type C enabled devices and compatible power sources or computers.



Image: The Vikefon Type C Charging and Data Cable, featuring a standard USB-A connector on one end and a reversible USB-C connector on the other.

## PRODUCT FEATURES

---

- **USB Connector Quality:** Ensures reliable charging and high-speed data transmission.
- **Power Output:** Supports up to 5V, 3 Amp for fast charging.
- **Universal Compatibility:** Fully compatible with all Type C mobile devices for fast charging and syncing.
- **Reversible USB Type-C Connector:** Allows for quick and easy connections in any orientation.
- **Durable Design:** Features intricate nylon braiding for enhanced durability and longevity, outlasting standard cables.




Image: A diagram illustrating the reversible nature of the USB-C connector and the cable's 1-meter (3.3 ft) cord length.

## SETUP

---

1. **Identify Connectors:** The cable has a standard USB-A connector on one end and a smaller, oval-shaped USB Type-C connector on the other.
2. **Connect to Power Source/Computer:** Insert the USB-A end of the cable into a compatible USB port on a wall adapter, power bank, car charger, or computer.
3. **Connect to Device:** Insert the USB Type-C end into the charging/data port of your smartphone, tablet, or other Type C enabled device. The USB Type-C connector is reversible, so it can be inserted in either orientation.
4. **Verify Connection:** Ensure both ends are securely connected. Your device should indicate that it is charging or connected for data transfer.

## OPERATING INSTRUCTIONS

---

### Charging Your Device

1. Connect the USB-A end of the cable to a compatible USB power adapter (e.g., wall charger, car charger, power bank).
2. Connect the USB Type-C end to your device's charging port.
3. Ensure the power adapter is plugged into a live power outlet. Your device should begin charging.

### Transferring Data

1. Connect the USB-A end of the cable to a USB port on your computer.
2. Connect the USB Type-C end to your device.
3. On your device, you may receive a prompt asking to allow data access or to select a USB connection mode (e.g., "File Transfer," "MTP"). Select the appropriate option to enable data transfer.
4. Your device should appear as a removable drive or media device on your computer, allowing you to transfer files.

## MAINTENANCE

---

- **Proper Handling:** Always grasp the connector head when plugging or unplugging the cable. Avoid pulling directly on the cable itself to prevent damage to the internal wires.
- **Avoid Bending:** Do not excessively bend or crimp the cable, especially near the connectors, as this can cause internal wire breakage.
- **Storage:** Store the cable in a clean, dry place away from extreme temperatures and direct sunlight. Avoid tangling the cable.
- **Cleaning:** If necessary, gently wipe the cable and connectors with a dry, soft cloth. Do not use liquids or abrasive cleaners.



Image: A close-up view highlighting the durable metal heads of the Vikefon Type C cable connectors, designed for anti-oxidation and corrosion resistance.

## TROUBLESHOOTING

---

- **Device Not Charging:**
  - Ensure both ends of the cable are securely connected.
  - Verify that the power adapter is functioning correctly and plugged into a live outlet.

- Try using a different power adapter or USB port.
- Check your device's charging port for any debris or damage.
- **Slow Charging:**
  - Ensure you are using a power adapter that supports fast charging (e.g., 3A output).
  - Close any unnecessary background applications on your device.
- **No Data Transfer:**
  - Confirm the cable is properly connected to both your device and computer.
  - On your device, check the notification panel for USB options and select "File Transfer" or "MTP."
  - Try connecting to a different USB port on your computer.
  - Restart both your device and computer.

## SPECIFICATIONS

Feature	Detail
Brand	Vikefon
Model Name	Type C
Model Number	Type C 0129
Connector Type	USB Type C (Male-to-Male)
Cable Type	USB
Compatible Devices	Laptop, PC, Smartphone (e.g., Xiaomi Redmi 8A, POCO M2, POCO M2 Pro, Samsung, Motorola, Lenovo, Lava, Sony, HTC, LG, Karbonn, Maxx)
Special Features	Charging Wire, Durable, High Data Transfer Rate, High Quality, Long Length
Data Transfer Rate	Up to 0.48 Gigabits Per Second (480 Mbps)
Connectivity Technology	USB
Specification Met	ISO
Colour	Black
Item Shape	Round
Outer Material Type	Rubber (with Nylon Braiding)
Cable Length	1 Meter

## WARRANTY AND SUPPORT

---

Specific warranty details for the Vikefon Type C Charging and Data Cable are not provided in this manual. For information regarding warranty coverage, returns, or technical support, please refer to the product packaging or contact the manufacturer directly through their official channels.

---

© 2023 Vikefon. All rights reserved.