

**NENO 5902479671925**

## Neno® UNO Electronic Breast Pump User Manual

Model: 5902479671925 | Brand: NENO

### 1. INTRODUCTION

---

The Neno UNO is an intelligent electronic breast pump designed for comfort and efficiency. It offers customizable settings to suit individual needs, making the pumping experience more comfortable and effective. This manual provides comprehensive instructions for the safe and proper use, maintenance, and troubleshooting of your Neno UNO breast pump.

### 2. IMPORTANT SAFETY INFORMATION

---

Please read all instructions carefully before using the Neno UNO breast pump. Failure to follow these instructions may result in injury or damage to the product.

- This device is intended for personal use only.
- Do not immerse the main unit (motor) in water or other liquids.
- Keep out of reach of children.
- Do not use while bathing or showering.
- Always unplug the device after use and before cleaning.
- Inspect all components before each use for any damage. Discard and replace damaged parts immediately.
- Use only original Neno accessories and replacement parts.
- If you experience pain or discomfort during pumping, stop immediately and consult a healthcare professional.
- Ensure all parts are completely dry before assembly and storage to prevent mold or bacterial growth.

### 3. PRODUCT COMPONENTS

---

The Neno UNO breast pump consists of several key components designed for efficient and comfortable milk expression. Familiarize yourself with each part before assembly and use.



Figure 3.1: Neno UNO Electronic Breast Pump and its retail packaging.





Figure 3.2: Detailed view of the Neno UNO's intuitive touch control panel, showing power, mode, and intensity buttons.



Figure 3.3: Angled perspective of the Neno UNO breast pump, highlighting its compact design and assembled components.



Figure 3.4: Side profile of the Neno UNO breast pump, showcasing the connection between the motor unit, flange, and bottle.





Figure 3.5: Another angled view of the Neno UNO, emphasizing its ergonomic shape and clear collection bottle.




Figure 3.6: Illustration showing the internal electronic components of the Neno UNO alongside diagrams of breast anatomy, indicating milk ducts and glands.



Figure 3.7: Visual representation of the Neno UNO breast pump highlighting its 1400mAh lithium-ion battery, indicating long-lasting power.



Figure 3.8: Two Neno UNO breast pumps displayed, with a "BPA Free" logo, emphasizing the safety of the materials used.

## List of Components:

- Main Pump Unit (Motor with control panel)
- Silicone Flange/Shield
- Milk Collection Bottle
- Valve
- Diaphragm
- Bottle Stand/Base
- USB Charging Cable

## 4. SETUP

---

Before first use, and after each use, disassemble and clean all parts that come into contact with breast milk. Refer to the "Cleaning and Maintenance" section for detailed instructions.

1. Ensure the main pump unit is fully charged. Connect the USB charging cable to the pump and a suitable power source. The battery indicator on the display will show charging status.
2. Assemble the clean and dry components:
  - Insert the valve firmly into the bottom of the flange.
  - Place the diaphragm onto the top of the flange, ensuring a tight seal.
  - Screw the milk collection bottle onto the bottom of the flange assembly.
  - Attach the assembled flange and bottle unit to the main pump unit, ensuring it clicks securely into place.
3. Place the assembled pump onto a stable surface or use the provided bottle stand for stability.

## 5. OPERATING INSTRUCTIONS

---

The Neno UNO breast pump is designed for ease of use with its intuitive touch screen and automatic functions.

### 5.1 Powering On/Off

- To turn on: Press and hold the power button () on the touch screen until the display illuminates.
- To turn off: Press and hold the power button () until the display turns off. The pump will also automatically turn off after a predetermined duration of use (e.g., 30 minutes).

### 5.2 Modes of Operation

The Neno UNO features two distinct modes to simulate natural breastfeeding:

- **Stimulation Mode:** This mode uses a fast, light suction to stimulate milk let-down. It has up to 6 levels of intensity. The pump typically starts in this mode.
- **Expression Mode:** Once milk flow begins, switch to this mode for slower, stronger suction to efficiently express milk. It has up to 9 levels of intensity.

To switch between modes, press the mode button on the touch screen. The pump will automatically switch modes after a set period to optimize milk expression.

### 5.3 Adjusting Suction Intensity

- Use the '+' button to increase suction intensity.
- Use the '-' button to decrease suction intensity.

- Adjust the intensity to a comfortable level that allows for efficient milk flow without causing pain. The pump remembers your last settings for convenience.

## 5.4 Battery Life and Charging

The Neno UNO is equipped with a powerful 1400mAh lithium-ion battery, providing up to 2 hours of continuous operation or approximately 4 complete 30-minute pumping sessions on a single charge.

- Monitor the battery indicator on the display.
- Recharge the pump using the provided USB cable when the battery is low.
- Avoid fully depleting the battery to prolong its lifespan.



Figure 5.1: A user demonstrating the portable and discreet use of the Neno UNO breast pump.

## 6. CLEANING AND MAINTENANCE

Proper cleaning and sterilization are crucial for hygiene and the longevity of your breast pump. All parts that come into contact with breast milk must be cleaned and sterilized after each use.

### 6.1 Disassembly

1. Turn off the pump and disconnect it from any power source.
2. Carefully detach the milk collection bottle from the flange.
3. Remove the valve and diaphragm from the flange.
4. Separate the main pump unit from the flange assembly. The main pump unit should never be washed or sterilized.

### 6.2 Cleaning

- Rinse all disassembled parts (except the main pump unit) under cold running water to remove any milk residue.
- Wash parts in warm, soapy water using a mild dish soap. Use a dedicated brush for cleaning breast pump parts.
- Rinse thoroughly under clean running water.

## 6.3 Sterilization

Sterilize parts (flange, bottle, valve, diaphragm) using one of the following methods:

- **Boiling Water:** Place parts in a pot of boiling water for 5 minutes. Ensure parts do not touch the bottom or sides of the pot to prevent damage.
- **Steam Sterilizer:** Use a dedicated steam sterilizer according to its manufacturer's instructions.
- **Dishwasher:** Some parts may be dishwasher safe (top rack only). Refer to product packaging or Neno's official website for confirmation.

After sterilization, place parts on a clean drying rack or paper towel to air dry completely. Do not use a cloth towel as it may transfer germs.

## 6.4 Storage

Store clean and dry breast pump parts in a clean, dry place away from direct sunlight and dust.

## 7. TROUBLESHOOTING

If you encounter issues with your Neno UNO breast pump, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power / Pump not turning on	Battery is low or depleted; Power button not pressed correctly.	Charge the pump fully. Press and hold the power button firmly.
Weak or no suction	Parts not assembled correctly; Damaged valve or diaphragm; Flange not sealed properly to breast.	Ensure all parts are assembled tightly. Check valve and diaphragm for tears or damage and replace if necessary. Reposition the flange on the breast to ensure a good seal.
Milk leaking from pump	Bottle not screwed on tightly; Valve not seated correctly; Overfilled bottle.	Ensure the bottle is securely attached. Check that the valve is properly inserted. Do not overfill the bottle beyond its maximum capacity.
Pump making unusual noise	Parts not assembled correctly; Foreign object in pump mechanism.	Disassemble and reassemble all parts. If noise persists, contact customer support.

If the problem persists after trying these solutions, please contact Neno customer support for further assistance.

## 8. SPECIFICATIONS

Brand	NENO
Model Name	UNO (Electric)
Model Number	5902479671925

<b>ASIN</b>	B08PPNVMY5
<b>Operating Mode</b>	Electric
<b>Power Source</b>	Battery Powered
<b>Battery Type</b>	1 Lithium-ion (included)
<b>Battery Capacity</b>	1400 mAh
<b>Dimensions (L x W x H)</b>	50 x 50 x 28 cm
<b>Weight</b>	671 grams
<b>Material</b>	Silicone (BPA-free)
<b>Special Feature</b>	Lightweight, Portable
<b>Included Components</b>	Battery (main unit, flange, bottle, valve, diaphragm implied)

## 9. WARRANTY AND SUPPORT

---

Neno products are manufactured to high-quality standards. For specific warranty information, please refer to the warranty card included with your product or visit the official Neno website. Keep your proof of purchase for warranty claims.

For technical support, troubleshooting assistance beyond this manual, or to inquire about replacement parts, please contact Neno customer service through their official website or the contact information provided in your product packaging.

**Website:** [www.neno.pl/en/](http://www.neno.pl/en/)