

[manuals.plus](#) /› [alpina](#) /› [Alpina Digital Kitchen Scale Model 18679 User Manual](#)**alpina 18679**

# Alpina Digital Kitchen Scale Model 18679 User Manual

Precision Weighing for Your Culinary Needs

## 1. INTRODUCTION

Thank you for choosing the Alpina Digital Kitchen Scale, Model 18679. This precision instrument is designed to assist you in accurately measuring ingredients for cooking and baking. Featuring a maximum capacity of 5 kilograms and a convenient tare function, this scale ensures precise measurements in grams, kilograms, pounds, or ounces. Please read this manual thoroughly before use to ensure proper operation and maintenance.

## 2. SAFETY INSTRUCTIONS

- Do not immerse the scale in water or other liquids.
- Clean the scale with a damp cloth; do not use abrasive cleaners.
- Place the scale on a flat, stable surface for accurate measurements.
- Do not overload the scale beyond its maximum capacity of 5 kg (11 lb).
- Keep the scale away from extreme temperatures and direct sunlight.
- This appliance is for household use only.
- Remove batteries if the scale will not be used for an extended period.

## 3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Alpina Digital Kitchen Scale (Model 18679)
- 2 x AAA Batteries
- User Manual (this document)

## 4. PRODUCT OVERVIEW

The Alpina Digital Kitchen Scale features a sleek stainless steel design with an easy-to-read digital display. It includes essential buttons for power, unit conversion, and tare functionality.



**Image 4.1:** Top-down view of the Alpina Digital Kitchen Scale, displaying "550g" on its digital screen. The "ON-OFF/TARE" and "UNIT" buttons are visible.



**Image 4.2:** Top view of the Alpina Digital Kitchen Scale, showing the stainless steel platform and a blank digital display, indicating it is off or in standby mode.



**Image 4.3:** Alpina Digital Kitchen Scale with a white mixing bowl placed on its platform, and the display showing "0g" after the tare function has been applied.

## 5. SETUP

### 5.1 Battery Installation

1. Locate the battery compartment on the underside of the scale.
2. Open the battery compartment cover.
3. Insert the 2 AAA batteries, ensuring correct polarity (+/-).

4. Close the battery compartment cover securely.

The scale is now ready for use.

## 6. OPERATING INSTRUCTIONS

### 6.1 Power On/Off

- To turn on the scale, press the **ON-OFF/TARE** button. The display will show "8888" and then "0g".
- To turn off the scale, press and hold the **ON-OFF/TARE** button for approximately 3 seconds. The scale will also automatically turn off after a period of inactivity to conserve battery life.

### 6.2 Unit Conversion

- With the scale powered on, press the **UNIT** button to cycle through the available measurement units: grams (g), kilograms (kg), pounds (lb), and ounces (oz).
- Select the desired unit before weighing.

### 6.3 Tare Function

The tare function allows you to weigh ingredients in a container by subtracting the container's weight.

1. Place an empty container on the scale platform. The display will show the container's weight.
2. Press the **ON-OFF/TARE** button. The display will reset to "0g" (or the selected unit).
3. Add your ingredients to the container. The display will now show only the weight of the ingredients.
4. To clear the tare, remove all items from the scale and press the **ON-OFF/TARE** button again if the display does not return to "0" automatically.

### 6.4 Weighing

1. Ensure the scale is on a flat, stable surface and powered on, displaying "0g".
2. Place the item(s) to be weighed directly onto the scale platform or into a tared container.
3. Read the weight displayed on the digital screen.

## 7. MAINTENANCE AND CLEANING

- Wipe the scale surface with a soft, damp cloth. For stubborn stains, a mild detergent can be used.
- Do not use abrasive cleaning agents, scouring pads, or harsh chemicals, as these can damage the stainless steel finish and electronic components.
- Ensure the scale is completely dry before storage or next use.
- Store the scale in a cool, dry place.

## 8. TROUBLESHOOTING

Problem	Possible Cause	Solution
"Lo" displayed	Low battery power.	Replace the 2 AAA batteries.

Problem	Possible Cause	Solution
"O-Ld" displayed	Scale is overloaded.	Remove items immediately. Do not exceed 5 kg capacity.
Inaccurate readings	Scale not on a flat surface, or external interference.	Place the scale on a stable, level surface. Avoid strong vibrations or air currents.
Scale does not turn on	Batteries incorrectly installed or depleted.	Check battery polarity or replace batteries.

## 9. SPECIFICATIONS


<b>Brand</b>	Alpina
<b>Model Number</b>	18679
<b>Material</b>	Stainless Steel
<b>Maximum Weight Capacity</b>	5 Kilograms (5000g)
<b>Measurement Precision</b>	1 gram
<b>Units of Measurement</b>	g, kg, lb, oz
<b>Display Type</b>	LED
<b>Special Features</b>	Automatic Shut-off, Tare Function
<b>Power Source</b>	2 x AAA Batteries (included)
<b>Product Dimensions (L x W x H)</b>	18 x 14 x 2 cm
<b>Product Weight</b>	200 grams

## 10. WARRANTY AND SUPPORT

This Alpina product is covered by a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation provided at the time of purchase or contact your retailer. For technical support or inquiries, please contact Alpina customer service through their official website or the contact information provided with your purchase.

Please retain your proof of purchase for warranty claims.





### [Arrowhead Electrical Products Master Unit Catalog 2011](#)

The 2011 Master Unit Catalog from Arrowhead Electrical Products, Inc. features a comprehensive listing of new replacement units for automotive, agricultural, heavy-duty trucks, industrial, marine, outdoor power equipment, and powersports applications. This catalog details various alternators and starters, including specifications and cross-references.

lang:i-klingon score:11 filesize: 14.77 M page\_count: 428 document date: 2010-12-03