

[Manuals.plus](#) /

> [AULCMEET](#) /

> AULCMEET ML-L3 Wireless Infrared Remote Control User Manual

## AULCMEET ML-L3

# AULCMEET ML-L3 Wireless Infrared Remote Control User Manual

Model: ML-L3

## 1. INTRODUCTION

---

The AULCMEET ML-L3 Wireless Infrared Remote Control provides a convenient way to trigger your Nikon Digital SLR camera's shutter remotely. This device is ideal for preventing camera shake during long exposures, self-portraits, or group shots where you want to be in the frame. It operates using infrared technology, requiring a clear line of sight to your camera's infrared receiver.

## 2. PRODUCT OVERVIEW

---





This image displays the AULCMEET ML-L3 Wireless Infrared Remote Control. It is a compact, black rectangular device. The front features a prominent circular button, outlined in yellow, which serves as the shutter release. Above the button, three curved yellow lines indicate the infrared emitter. The model number 'ML-L3' is printed in yellow at the bottom of the remote.

### Key Components:

- **Shutter Release Button:** The main button on the front, used to trigger the camera's shutter.
- **Infrared Emitter:** Located at the top edge, this sends the signal to the camera.
- **Battery Compartment:** Located on the side, accessible by sliding a small tray.

## 3. SETUP

---

### 3.1 Battery Installation

1. Locate the small battery tray on the side of the remote control.
2. Gently slide the tray outwards to open the battery compartment.
3. Insert a CR2025 lithium button cell battery with the positive (+) side facing upwards.
4. Slide the battery tray back into the remote until it clicks securely into place.

### 3.2 Camera Preparation

Before using the remote, your Nikon camera must be set to a remote control mode. The exact steps may vary slightly depending on your camera model. Refer to your camera's instruction manual for precise details.

- Access your camera's **Release Mode** settings.
- Select a remote control option, typically labeled as **Remote Control (Delay)** or **Remote Control (Quick Response)**.
- Ensure the camera's infrared receiver (usually on the front grip or near the lens mount) is unobstructed and facing towards where you will be using the remote.

## 4. OPERATING INSTRUCTIONS

---

Once the battery is installed and your camera is set to remote control mode, you can begin using the ML-L3 remote.

1. Point the infrared emitter of the ML-L3 remote directly at the infrared receiver on your Nikon camera.
2. Press the large circular shutter release button on the remote.
3. The camera will respond according to the selected remote release mode:
  - **Quick Response:** The shutter will fire immediately.
  - **Delayed Release:** The shutter will fire after a short delay (e.g., 2 seconds), allowing you to conceal the remote.

**Important:** The remote requires a clear line of sight to the camera's IR receiver. Obstructions or strong sunlight can interfere with the signal. The effective range is typically up to 10 meters (33 feet).

## 5. COMPATIBILITY

---

The AULCMEET ML-L3 Wireless Infrared Remote Control is compatible with a wide range of Nikon Digital SLR cameras, including but not limited to:

- Nikon D7200, D750, D5500, D3300, D5300, D610, D7100, D5200, D600, D7000, D3200, D90, D3000, D5100, D60, D5000, D50, D70, D70s, D40X, D40, D80
- Nikon 1 V3, J1, V2, J2, V1
- Nikon Coolpix P900, P7800, P7700, P7100, P7000
- Nikon D7500, D3400

Always verify your camera's manual for specific remote control compatibility.

## 6. TROUBLESHOOTING

---

### Remote Not Functioning:

- **Check Battery:** Ensure the CR2025 battery is correctly installed and has sufficient charge. Replace if necessary.
- **Camera Settings:** Confirm your camera's release mode is set to a remote control option (e.g., Remote Control (Delay) or Remote Control (Quick Response)).
- **Line of Sight:** Ensure there is a clear, unobstructed path between the remote's infrared emitter and the camera's infrared receiver.
- **Distance and Angle:** Operate the remote within its effective range (typically up to 10 meters) and ensure it is pointed directly at the camera's receiver.
- **Environmental Factors:** Strong direct sunlight can sometimes interfere with infrared signals. Try using the remote in shaded areas or indoors.

## 7. SPECIFICATIONS

---

Feature	Detail
Model Number	ML-L3
Product Dimensions	5 x 1 x 0.5 inches
Item Weight	0.317 ounces
Power Source	1 x CR2025 Lithium Button Cell Battery (included)
Technology	Infrared (IR)
Effective Range	Up to 10 meters (33 feet)

## 8. WARRANTY AND SUPPORT

---

For warranty information or technical support regarding your AULCMEET ML-L3 Wireless Infrared Remote Control, please contact the manufacturer directly through their official website or the retailer from whom the product was purchased. Keep your purchase receipt as proof of purchase.