

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Aqua Laser](#) /

› Aqua Laser Brilliant 1500W Steam Cleaner User Manual

Aqua Laser Brilliant

Aqua Laser Brilliant 1500W Steam Cleaner User Manual

Model: Brilliant

1. INTRODUCTION

Thank you for choosing the Aqua Laser Brilliant 1500W Steam Cleaner. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your steam cleaner. Please read it thoroughly before first use and keep it for future reference.

1.1 Safety Information

- **WARNING:** Never use cleaning agents, scented additives, chemicals, or other products in the steam cleaner. This can damage the appliance or be dangerous.
- Do not use the steam cleaner on unsealed wooden floors, leather, furniture, wax-sealed floors, synthetic fabrics, velvet, or other steam-sensitive materials.
- Keep the appliance out of reach of children and pets.
- Always unplug the appliance before filling with water or performing maintenance.
- Do not immerse the appliance in water or other liquids.
- Use only tap water. Distilled or demineralized water can also be used.
- Ensure the power cord is not damaged and avoid tripping hazards.

1.2 Package Contents

Carefully unpack your steam cleaner and check that all items are present and undamaged. If any items are missing or damaged, contact your retailer.

- Aqua Laser Mop Base
- Handle
- Filling Cup (max. 150 ml)
- Fabric Nozzle with Cleaning Cloth (for windows and hard surfaces)
- Carpet Glider (for carpets and rugs)
- Window Cleaning Kit
- Fine Bristle Brush (for small spaces like joints or shower door rails)

- Scraper Nozzle
- Hard Round Brush (recommended for joints, cooking surfaces)
- Corner Nozzle (for hard-to-reach areas like window frames and toilet bowls)
- Jet Nozzle
- Small Microfiber Pad (bevelable)
- Knikpijpe (bendable pipe)
- Optiser zetstuk (optimizing attachment)
- Wallpaper clicker
- Chamber cleaner








Image 1.2.1: The Aqua Laser Brilliant 1500W Steam Cleaner with its included accessories. This image shows the main unit and several attachments like brushes, nozzles, and cloths, illustrating the comprehensive cleaning kit.

2. SETUP

2.1 Assembly

1. Attach the handle to the main body of the Aqua Laser Mop Base until it clicks securely into place.
2. Select the appropriate cleaning accessory for your task (e.g., mop base for floors, brush for grout) and attach it firmly to the steam cleaner's nozzle.

2.2 Filling the Water Tank

1. Ensure the steam cleaner is unplugged from the power outlet.
2. Locate the water tank cap, usually found on the main body of the unit. Unscrew or open it.
3. Using the provided filling cup (max. 150 ml), carefully pour tap water into the water tank. The tank capacity is approximately 450 ml. Do not overfill.
4. Securely close the water tank cap.

3. OPERATING INSTRUCTIONS

3.1 Powering On and Heating

1. Plug the power cord (5m length) into a suitable electrical outlet (240 Volts).
2. The indicator light will illuminate, signaling that the unit is heating up.
3. Wait for the indicator light to change or turn off (refer to your specific model's light behavior) to indicate that the steam is ready. This usually takes a few minutes.

3.2 Cleaning Surfaces

The Aqua Laser Brilliant steam cleaner is suitable for cleaning various sealed floor surfaces without detergents, including:

- Tiles
- Vinyl
- Laminate
- Marble
- Stone
- Sealed wooden surfaces

For carpets and rugs, use the provided carpet glider. Move the steam cleaner slowly over the surface to allow the steam to penetrate and clean effectively.

3.3 Important Considerations

- Using the steam cleaner on waxed or unwaxed floors may reduce their shine. Test on an inconspicuous area first.
- Do not use on unsealed wooden floors, leather, furniture, wax-sealed floors, synthetic fabrics, velvet, or other steam-sensitive materials.
- Always ensure the surface is suitable for steam cleaning before proceeding.

4. MAINTENANCE

4.1 Cleaning the Appliance

1. Before cleaning, ensure the steam cleaner is unplugged and has cooled down completely.
2. Empty any remaining water from the tank.
3. Wipe the exterior of the appliance with a damp cloth. Do not use abrasive cleaners or solvents.
4. The cleaning cloths and pads can be hand-washed or machine-washed according to their care instructions.

4.2 Water Usage

The steam cleaner can be used with tap water. For areas with very hard water, using distilled or demineralized water may help prevent mineral buildup and extend the life of the appliance.

5. TROUBLESHOOTING

If you encounter issues with your Aqua Laser Brilliant Steam Cleaner, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No steam or low steam output	Water tank is empty or low. Appliance not heated sufficiently. Nozzle/attachment blocked.	Refill the water tank. Wait for the indicator light to signal readiness. Clean the nozzle/attachment.
Water leaking from the unit	Water tank cap not closed properly. Attachment not securely fastened. Overfilling the water tank.	Ensure the water tank cap is tightly closed. Reattach the accessory firmly. Do not exceed the maximum fill line.
Appliance not turning on	Not plugged in. Power outlet malfunction. Appliance fault.	Check if the power cord is securely plugged in. Test the outlet with another device. If the issue persists, contact customer support.

6. SPECIFICATIONS

Brand: Aqua Laser

Model Name: Brilliant

Power: 1500 Watts

Voltage: 240 Volts

Water Tank Capacity: Approximately 450 Milliliters

Cable Length: 5 meters

Product Dimensions (L x W x H): 48 x 25 x 14 cm

Item Weight: 2.6 Kilograms

Special Feature: Lightweight

Form Factor: Stick

Power Source: Corded Electric

7. WARRANTY AND SUPPORT

Information regarding specific warranty terms and customer support contact details is not available in the provided product data. Please refer to the documentation included with your purchase or contact your retailer for warranty claims and technical assistance.

For spare parts availability, please note that information is unavailable based on the provided data.