

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [MoMi](#) /

> [MoMi COLLET Baby Carrier Instruction Manual](#)

MoMi COLLET

MoMi COLLET Baby Carrier Instruction Manual

Model: COLLET | Brand: MoMi

INTRODUCTION

This manual provides essential information for the safe and proper use of your MoMi COLLET Baby Carrier. Please read all instructions carefully before using the product. Keep this manual for future reference.

The MoMi COLLET Baby Carrier is designed for children aged 3 to 48 months, with a weight range of 4 kg to 20 kg. It offers two ergonomic carrying positions and features 6 adjustment points for optimal comfort and safety for both child and parent.

SAFETY INFORMATION

- **Always ensure all buckles and straps are securely fastened** before and during use.
- Regularly check the carrier for any signs of wear, tear, or damage. Discontinue use if any damage is found.
- Ensure your child's airway is clear and unobstructed at all times.
- Maintain an ergonomic "M" position for your baby's hips, with knees higher than the bottom, to support healthy hip development.
- Never use the carrier during activities that could be dangerous for your child, such as cooking, driving, or strenuous exercise.
- Be aware of your child's temperature and ensure they are not overheating or too cold.
- For babies aged 3-6 months, use the front carry position with the baby facing inward towards the parent.
- For children aged 6 months and older, the back carry position (facing forward) can be used, ensuring the child has adequate head and neck control.
- The removable hood provides additional head support and protection from elements.

PRODUCT OVERVIEW

The MoMi COLLET Baby Carrier is designed for comfort and versatility. Key components include:

- **Padded Shoulder Straps:** For parent comfort and weight distribution.
- **Wide Hip Belt:** Provides lumbar support and distributes weight to the hips.
- **Adjustable Buckles and Straps:** 6 points of adjustment to fit various body types and child sizes.
- **Ergonomic Seat:** Wide and adjustable front section to support the baby's back and maintain a natural physiological

position.

- **Removable Hood:** Offers head support and protection.
- **Soft Buckle Covers:** To prevent discomfort from buckles.
- **Integrated Pocket:** For small essentials.



Image: The MoMi COLLET Baby Carrier, highlighting its ergonomic features and overall design.

SETUP

Before placing your child in the carrier, familiarize yourself with its components and adjustments.

1. **Adjust Hip Belt:** Fasten the main hip belt around your waist, ensuring it sits comfortably and securely. The buckle should be centered.
2. **Prepare Shoulder Straps:** Loosen the shoulder straps to allow for easy placement of your child.
3. **Check Buckles:** Ensure all buckles are in good working order and click securely into place.



Image: A parent demonstrating the back carry position, showing the secure fit of the hip belt and shoulder straps.

OPERATING INSTRUCTIONS

1. Front Carry Position (Baby Facing Inward)

Recommended for babies from 3 months.

1. Fasten the hip belt around your waist.
2. Hold your baby against your chest and carefully guide their legs through the leg openings of the carrier.
3. Pull the carrier panel up over your baby's back, ensuring it supports them from knee-to-knee.
4. Bring the shoulder straps over your shoulders and fasten the chest clip behind your neck/upper back.
5. Tighten all straps until the carrier is snug and secure, ensuring your baby is high enough to kiss and their airway is clear.
6. Adjust the width of the seat to ensure an ergonomic "M" position for your baby's hips.




Image: A parent using the front carry position with the baby facing inward, showing correct posture.

2. Back Carry Position (Baby Facing Forward)

Recommended for children from 6 months with good head and neck control.

1. Fasten the hip belt around your waist.
2. With assistance, or using a safe method, position your child on your back.
3. Guide your child's legs through the leg openings and pull the carrier panel up over their back.
4. Bring the shoulder straps over your shoulders and fasten the chest clip in front of you.
5. Tighten all straps for a secure and comfortable fit. Ensure your child is seated high enough to see over your shoulder.
6. Verify the ergonomic "M" position for your child's hips.



Image: A parent using the back carry position with the child facing forward.

Adjustments

- **Shoulder Strap Adjustment:** Use the buckles on the shoulder straps to tighten or loosen for a snug fit.
- **Chest Clip Adjustment:** The chest clip can be moved up or down the shoulder straps for optimal comfort and to prevent straps from slipping.
- **Hip Belt Adjustment:** The hip belt can be tightened or loosened to distribute weight effectively and secure the carrier.
- **Seat Width Adjustment:** Adjust the width of the carrier's seat to ensure proper knee-to-knee support for your child as they grow.



Image: Detail of the adjustable chest strap buckle for secure fitting.



Image: The convenient integrated pocket on the carrier.

MAINTENANCE

Proper care will extend the life of your MoMi COLLET Baby Carrier.

- **Cleaning:** The carrier is machine washable. Use a gentle cycle with cold water and mild detergent.
- **Drying:** Air dry only. Do not tumble dry, bleach, or iron.
- **Storage:** Store the carrier in a clean, dry place away from direct sunlight when not in use.
- **Inspection:** Regularly inspect all buckles, straps, and fabric for any signs of wear or damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Child seems uncomfortable or fussy.	Incorrect positioning, carrier too tight/loose, overheating.	Re-adjust straps for a snug but not restrictive fit. Ensure ergonomic "M" position. Check child's temperature. Take a break from carrying.
Parent experiences back or shoulder pain.	Improper weight distribution, straps too loose/tight, hip belt not positioned correctly.	Ensure hip belt is snug around your waist/hips. Adjust shoulder straps to distribute weight evenly. Refer to "Operating Instructions" for proper fitting.
Buckles are difficult to fasten or unfasten.	Buckle mechanism is dirty or misaligned.	Clean buckles if necessary. Ensure proper alignment before attempting to fasten. Do not force.

SPECIFICATIONS

Feature	Detail
Model	COLLET
Brand	MoMi
Recommended Age	3 to 48 months

Feature	Detail
Minimum Weight	4 kg (8.8 lbs)
Maximum Weight	20 kg (44 lbs)
Material	Polycotton, Polyester
Care Instructions	Machine wash (gentle cycle), Air dry
Dimensions (L x W x H)	48 x 38 x 47 cm (18.9 x 15 x 18.5 inches)
Product Weight	690 grams (1.5 lbs)
Manufacturer	TelForceOne S.A.
Country of Origin	Poland
Color (as per model number)	Gray



Image: Dimensional diagram of the MoMi COLLET Baby Carrier.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official MoMi website or contact your retailer. Keep your proof of purchase for any warranty claims.

Manufacturer: TelForceOne S.A.

For further assistance, please visit momi.info.