

Other DS-3618L

Digital LED Alarm Clock User Manual

Model: DS-3618L | Brand: Other

1. INTRODUCTION

Thank you for purchasing the Digital LED Alarm Clock, Model DS-3618L. This modern and versatile device combines a large LED time display, alarm, snooze function, temperature display, and a convenient mirror surface. Designed for simplicity and ease of use, it is an ideal addition to any bedroom or office. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance and longevity of your alarm clock.

2. PRODUCT FEATURES

- **Large LED Display:** Features large, clear LED digits for easy readability of time, date, and temperature.
- **Mirror Function:** The screen surface doubles as a practical mirror for daily use.
- **Power & Memory Function:** USB powered with a CR2032 backup battery to retain time settings during power outages, eliminating the need for frequent re-setting.
- **Adjustable Sound Level:** Alarm volume can be adjusted to suit personal preference.
- **Simple Operation:** Designed with minimal buttons for straightforward setup and daily use.
- **Modern Design:** Sleek, rectangular shape with a black frame that complements various decor styles.

3. PACKAGE CONTENTS

Please check the package contents upon unboxing:

- 1 x Digital LED Alarm Clock (DS-3618L)
- 1 x USB Power Cable (approx. 1 meter)
- 1 x User Manual
- 1 x CR2032 Cell Battery (pre-installed for backup)

4. SETUP

4.1 Power Connection

Connect the provided USB cable to the power input port on the back of the alarm clock. Plug the other end of the USB cable into a standard USB power adapter (not included) or a compatible USB port (e.g., computer, power bank). The display will light up once power is supplied.

4.2 Backup Battery

The alarm clock comes with a pre-installed CR2032 cell battery. This battery serves as a backup to maintain time and alarm settings in case of a power interruption. No action is required for initial setup regarding the backup battery, but ensure it is properly seated in its compartment on the back panel.



Figure 1: Front view of the Digital LED Alarm Clock with green time display. This image illustrates the large, clear LED digits and the reflective mirror surface of the clock.

5. OPERATING INSTRUCTIONS

The clock features a simplified control interface with a few key buttons for all operations.

5.1 Setting Time

1. Press the **MODE** button once to enter time setting mode. The hour digits will flash.
2. Use the **UP** and **DOWN** buttons to adjust the hour.
3. Press **MODE** again to move to minute setting. Adjust minutes using **UP** and **DOWN**.
4. Press **MODE** a third time to confirm and exit time setting.
5. To switch between 12-hour and 24-hour format, press the **UP** button while in normal time display mode.

5.2 Setting Alarm

1. Press the **ALARM** button once to enter alarm setting mode. The alarm hour digits will flash.
2. Use the **UP** and **DOWN** buttons to adjust the alarm hour.
3. Press **ALARM** again to move to alarm minute setting. Adjust minutes using **UP** and **DOWN**.
4. Press **ALARM** a third time to confirm and exit alarm setting.
5. To activate or deactivate the alarm, press the **ALARM** button briefly while in normal time display mode. An alarm icon will appear/disappear on the display.

5.3 Snooze Function

When the alarm sounds, press any button (except the alarm off button, if present) to activate the snooze function. The alarm will temporarily stop and sound again after a few minutes (default snooze time is typically 5-9 minutes, refer to specific button labels if available).

5.4 Adjusting Sound Level

The alarm volume can be adjusted. Look for a dedicated volume button or a slider on the side/back of the clock. If no specific button is labeled, try pressing the **UP** or **DOWN** buttons during alarm sound to cycle through volume levels.

5.5 Mirror Function

The front surface of the clock is designed with a reflective finish, allowing it to be used as a mirror when the display is off or dimmed.



Figure 2: Front view of the Digital LED Alarm Clock with red time display. This image demonstrates the alternative display color option for the clock.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the clock. For stubborn smudges on the mirror surface, a slightly damp cloth can be used, followed immediately by a dry cloth. Avoid abrasive cleaners or solvents.
- **Placement:** Place the clock on a stable, flat surface. Avoid direct sunlight or extreme temperatures, which can affect the display and internal components.
- **Power:** Always use the provided USB cable for power. If the clock is to be stored for an extended period, it is advisable to disconnect the USB power and remove the CR2032 backup battery.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Display is blank or not lighting up.	No power supply; loose USB connection.	Ensure USB cable is securely connected to both the clock and a working power source. Try a different USB port or adapter.

Problem	Possible Cause	Solution
Time/settings reset after power outage.	CR2032 backup battery is dead or missing.	Replace the CR2032 battery on the back panel. Ensure it is inserted with correct polarity.
Alarm does not sound.	Alarm is not activated; volume is too low.	Ensure the alarm icon is visible on the display. Adjust the alarm volume to a higher level.
Display is too dim/bright.	Brightness setting needs adjustment.	Refer to the operating instructions for brightness adjustment (if available, typically via UP/DOWN buttons in normal mode or a dedicated button).

8. SPECIFICATIONS

Feature	Detail
Model	DS-3618L
Brand	Other
Display Type	Digital LED
Time Format	12/24 Hour selectable
Power Source	Corded Electric (USB powered)
Backup Battery	CR2032 (included)
Material	ABS Plastic + Electronic Components
Dimensions (approx.)	19 cm (Length) x 10 cm (Height) x 4.5 cm (Depth)
Item Weight	230 grams
Special Features	Alarm, Snooze, Temperature Display, Date Display, Mirror Function, Adjustable Sound Level
Intended Use	Indoor (Bedroom, Office, etc.)




Figure 3: Digital LED Alarm Clock with dimensions (19cm x 10cm) indicated, providing a visual reference for its size.

9. WARRANTY AND SUPPORT

Warranty and support information for this product are not specified in the provided product details. Please refer to your point of purchase or the product packaging for any available warranty details or customer support contacts.