

[Manuals.plus](#) /

> [Eld](#) /

> Eld Smart LED Mirror Alarm Clock User Manual

## Eld Smart LED Mirror Alarm Clock

# Eld Smart LED Mirror Alarm Clock User Manual

Model: Smart LED Mirror Alarm Clock

## INTRODUCTION

---

Thank you for purchasing the Eld Smart LED Mirror Alarm Clock. This manual provides detailed instructions for setting up, operating, and maintaining your new alarm clock. Please read this manual thoroughly before use and keep it for future reference.

## SAFETY INSTRUCTIONS

---

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the device to strong impacts.
- Do not disassemble or attempt to repair the device yourself. Contact qualified service personnel.
- Keep the device away from water and other liquids.
- Use only the recommended power adapter (if applicable) or USB cable for charging.

## PACKAGE CONTENTS

---

- 1 x Eld Smart LED Mirror Alarm Clock
- 1 x USB Power Cable
- 1 x User Manual

## PRODUCT OVERVIEW

---

Familiarize yourself with the components of your alarm clock.



**Figure 1:** Front view of the Eld Smart LED Mirror Alarm Clock displaying the time. The clock features a large digital display and a reflective mirror surface.



**Figure 2:** Another perspective of the Eld Smart LED Mirror Alarm Clock, highlighting its sleek design and the USB power input on the side.

*(Note: Specific button locations and functions may vary slightly. Refer to the physical product for exact button layout.)*

- **Display:** Large LED digital time display, also functions as a mirror.
- **Time Set Button:** Used to enter time setting mode.
- **Alarm Set Button:** Used to enter alarm setting mode.
- **Up/Down Buttons:** Used to adjust values (time, alarm) and brightness.
- **Snooze/Light Button:** Activates snooze, adjusts display brightness, or turns off alarm.
- **USB Output Ports:** For charging external devices (e.g., smartphones).
- **DC Input:** For connecting the USB power cable to power the clock.

## SETUP

---

### 1. Power Connection:

Connect the provided USB power cable to the DC input port on the back or side of the alarm clock. Plug the other end into a standard USB power adapter (not included) or a powered USB port.

## 2. Initial Power On:

Once connected to power, the display will light up, usually showing a default time (e.g., 12:00 AM or 0:00).

## OPERATING INSTRUCTIONS

---

### Setting the Time

1. Press and hold the **Time Set** button for approximately 3 seconds. The hour digits will start flashing.
2. Use the **Up** or **Down** buttons to adjust the hour.
3. Press the **Time Set** button again to confirm the hour and move to minute setting. The minute digits will flash.
4. Use the **Up** or **Down** buttons to adjust the minutes.
5. Press the **Time Set** button one more time to confirm the minutes and exit time setting mode.

### Setting the Alarm

1. Press and hold the **Alarm Set** button for approximately 3 seconds. The alarm hour digits will start flashing.
2. Use the **Up** or **Down** buttons to adjust the alarm hour.
3. Press the **Alarm Set** button again to confirm the alarm hour and move to alarm minute setting. The alarm minute digits will flash.
4. Use the **Up** or **Down** buttons to adjust the alarm minutes.
5. Press the **Alarm Set** button one more time to confirm the alarm minutes and exit alarm setting mode.
6. To activate/deactivate the alarm, press the **Alarm Set** button briefly. An alarm icon (e.g., a bell) will appear on the display when the alarm is active.

### Snooze Function

When the alarm sounds, press the **Snooze/Light** button to activate the snooze function. The alarm will pause for a set period (e.g., 5-10 minutes) and then sound again. You can typically repeat this several times.

### Adjusting Display Brightness

Briefly press the **Snooze/Light** button (when the alarm is not sounding) to cycle through different brightness levels (e.g., High, Medium, Low, Off). Some models may have automatic brightness adjustment based on ambient light.

### Using USB Charging Ports

The alarm clock features two USB output ports for charging external devices. Simply connect your device's USB charging cable to one of the ports on the alarm clock. Ensure the alarm clock is powered on for the charging function to work.

## MAINTENANCE

---

- **Cleaning:** Use a soft, dry cloth to wipe the display and casing. Do not use abrasive cleaners or solvents.
- **Storage:** If storing the clock for an extended period, disconnect it from power.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Display is off or flickering.	No power or loose connection.	Check if the USB power cable is securely connected to both the clock and the power source. Ensure the power source is active.
Alarm does not sound.	Alarm is not activated or set incorrectly.	Ensure the alarm icon is visible on the display. Re-check alarm time settings.
USB charging ports are not working.	Clock is not powered or device is incompatible.	Ensure the alarm clock is connected to power. Try a different USB cable or device.

## SPECIFICATIONS

---

- **Brand:** Eld
- **Model:** Smart LED Mirror Alarm Clock
- **Display Type:** Digital LED
- **Special Features:** Alarm, Snooze, USB Charging Ports, Mirror Surface, Adjustable Brightness
- **Power Source:** USB Powered (DC 5V, adapter not included)
- **Material:** Typically ABS Plastic with Mirror Finish
- **Dimensions:** Compact, suitable for bedside or desk use

## WARRANTY AND SUPPORT

---

For warranty information and customer support, please refer to the retailer where you purchased this product or visit the official Eld website (if available). Keep your proof of purchase for warranty claims.