

[Manuals.plus](#) /

> [MEEDEN](#) /

> MEEDEN Vintage Wooden Drafting Table (Model AFD-6062-SHT) Instruction Manual

MEEDEN AFD-6062-SHT

MEEDEN Vintage Wooden Drafting Table (Model AFD-6062-SHT) Instruction Manual

Brand: MEEDEN | Model: AFD-6062-SHT

1. PRODUCT OVERVIEW

The MEEDEN Vintage Wooden Drafting Table is a versatile and durable workspace designed for artists, students, and professionals. Featuring a 35.5" x 23.5" tilting tabletop and adjustable height, it provides a comfortable and ergonomic setup for various creative and academic tasks. Constructed from solid beech wood and particle board with a walnut finish, this table is built for stability and longevity.



Image: The MEEDEN Vintage Wooden Drafting Table in use by an artist.

Key Features:

- **Superb Quality:** Vintage Walnut-colored tabletop made of smooth particle board with excellent craftsmanship. H-frame construction ensures stability and durability with thickened beechwood legs.
- **Multi-Directional Adjustment:** Height adjustable from 32.5" to 37.5" (6 options) and tabletop tiltable from flat to 65° (7 angles).
- **Upgraded Craftsmanship:** Vintage design with semicircle iron sheet and new threaded hole mold design to reduce tabletop shaking.
- **Wide Range of Usage:** Suitable for painting, writing, reading, architectural drawing, and as an art workbench, student desk, computer desk, or craft desk.

2. SAFETY WARNINGS

WARNING: This desk requires assembly. Always follow the assembly instructions carefully to ensure stability. Do not exceed the maximum weight recommendation of 15 kilograms (33 lbs) for the tabletop. Keep the desk on a stable surface and avoid tilting it beyond the recommended 65° angle to prevent accidents. Always use the desk on a flat, even surface and ensure it is properly anchored to the floor to prevent tipping.

3. SETUP AND ASSEMBLY

This drafting table requires assembly. Please follow the detailed instructions provided in the assembly video and diagrams below. Ensure all parts are present before beginning assembly.

Assembly Video Guide:

Video: Official MEEDEN assembly guide for the Artist Wood Drafting Table. This video demonstrates the step-by-step process of putting together the drafting table, including attaching the legs, crossbars, and tabletop, and securing all components.

Assembly Steps (Refer to video for visual guidance):

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components and hardware are present according to the parts list.
2. **Assemble Base:** Attach the crossbar (3) to the two base legs (2) using the provided screws (H). Ensure a secure fit.
3. **Attach Tabletop Supports:** Secure the tabletop supports (6) to the underside of the tabletop (1) using screws (A).
4. **Connect Base to Tabletop:** Attach the assembled base to the tabletop supports using the main adjustment knobs (F) and smaller screws (E). Do not overtighten initially.
5. **Install Pencil Ledge:** Attach the pencil ledge (4) to the front edge of the tabletop using screws (G).
6. **Final Tightening:** Once the table is upright and stable, tighten all screws and knobs to ensure maximum stability.




Image: Diagram illustrating the height adjustment mechanism.

4. OPERATING INSTRUCTIONS

The MEEDEN Drafting Table offers adjustable height and tilt features to customize your workspace for optimal comfort and productivity.

Adjusting Table Height:

1. Locate the height adjustment knobs on the side legs of the table.
2. Loosen the knobs on both sides.
3. Carefully lift or lower the tabletop to one of the 6 available height positions (from 32.5" to 37.5").
4. Once the desired height is reached, firmly tighten both knobs to secure the tabletop in place.



Image: Table dimensions, showing height adjustment range.

Adjusting Tabletop Tilt Angle:

1. Identify the dual-knob mechanisms on the side supports of the tabletop.
2. Loosen these dual-knobs on both sides.
3. Gently tilt the tabletop to your preferred angle, from a flat (0°) position up to 65°. There are 7 distinct angle settings.
4. Once the desired angle is set, firmly tighten both dual-knobs to lock the tabletop securely.

■ ADJUSTABLE ANGLE

Adjustable from 0°- 65°
for different use

0°-65°



Image: Diagram illustrating the tabletop tilt angle adjustment.

Using the T-Square Ruler:

The included 24" T-square ruler can be used for precise straight lines and measurements. Position the head of the T-square against the side edge of the tabletop and slide it up or down as needed. The built-in pencil ledge helps prevent tools from rolling off when the tabletop is tilted.

SOLID HARD WOOD

Retro design and rustic finish



Image: Close-up of the T-square ruler on the solid wood tabletop.

Video: MEEDEN Artist Beechwood Drafting Table in action, demonstrating its adjustable height and tilting features for various artistic applications.

5. MAINTENANCE

To ensure the longevity and appearance of your MEEDEN Vintage Wooden Drafting Table, follow these maintenance guidelines:

- **Cleaning:** Wipe the wooden surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Dusting:** Regularly dust the table to prevent buildup, especially in moving parts.
- **Hardware:** Periodically check all screws and knobs to ensure they are tight. Retighten as necessary to maintain stability.
- **Wood Care:** To preserve the wood finish, avoid prolonged exposure to direct sunlight or extreme temperature changes. Consider using a wood polish specifically designed for furniture every few months.
- **Weight Limit:** Adhere to the maximum weight recommendation of 15 kg (33 lbs) to prevent damage to the tabletop or frame.

6. TROUBLESHOOTING

If you encounter any issues with your drafting table, refer to the following common troubleshooting tips:

- **Table Wobbles:** Ensure all assembly screws and height adjustment knobs are securely tightened. Verify the table is placed on a flat, even surface.
- **Difficulty Adjusting Height/Tilt:** Loosen the respective adjustment knobs sufficiently before attempting to change the position. If resistance persists, check for any obstructions or debris in the adjustment mechanisms.
- **T-Square Ruler Not Sliding Smoothly:** Clean the edge of the tabletop and the T-square ruler to remove any dust or debris. Ensure the ruler is properly aligned.
- **Missing or Damaged Parts:** If any parts are missing or damaged upon arrival, please contact MEEDEN customer support immediately for assistance.

7. SPECIFICATIONS

Feature	Detail
Brand	MEEDEN
Model Number	AFD-6062-SHT
Product Dimensions (D x W x H)	20"D x 32"W x 37.5"H (19.69 x 31.89 x 33.07 inches)
Tabletop Dimensions	35.5" x 23.5"
Color	Walnut
Material Type	Particle board + beech wood
Base Material	Beech Wood
Adjustable Height Range	32.5" to 37.5" (6 positions)
Maximum Tilt Angle	65 Degrees (7 angles)
Item Weight	13.5 Kilograms (approx. 29.76 lbs)
Maximum Weight Recommendation	15 Kilograms (approx. 33 lbs)
Included Components	Drawer, Assembly Tools (Note: Some reviews indicate not all tools are included, please verify upon receipt)
Required Assembly	Yes

8. WARRANTY & SUPPORT

MEEDEN provides a **Limited Warranty** for this product. For specific details regarding warranty coverage, terms, and conditions, please refer to the documentation included with your purchase or contact MEEDEN customer support.

For any questions, technical assistance, or support needs, please reach out to MEEDEN customer service. Contact information can typically be found on the product packaging or the official MEEDEN website.

MEEDEN is committed to customer satisfaction and aims to assist you with any concerns regarding your drafting

table.