

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Blaupunkt](#) /

› [Blaupunkt Portable Evaporative Air Conditioner User Manual](#)

Blaupunkt BP2007

Blaupunkt Portable Evaporative Air Conditioner User Manual

Model: BP2007

1. INTRODUCTION

Thank you for choosing the Blaupunkt Portable Evaporative Air Conditioner. This manual provides important information regarding the safe operation, installation, maintenance, and troubleshooting of your appliance. Please read this manual thoroughly before use and retain it for future reference.

This evaporative air conditioner is designed to provide personal comfort by cooling, ventilating, and humidifying the air. It also features an ionizer function for improved air quality.



Figure 1.1: Blaupunkt Portable Evaporative Air Conditioner in a typical room setting.

This image shows the white Blaupunkt portable evaporative air conditioner positioned in a bright room, demonstrating its compact size and portability.

2. IMPORTANT SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before using the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Do not use outdoors. This appliance is for indoor use only.
- Do not allow water to enter the control panel or electrical components.
- Always unplug the appliance from the power outlet before cleaning, servicing, or moving.

- Ensure the water tank is properly seated and filled before operating the cooling function.
- Keep the appliance away from heat sources and direct sunlight.
- Do not block air inlets or outlets.
- Supervise children and ensure they do not play with the appliance.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your Blaupunkt Portable Evaporative Air Conditioner.

1. Main Unit Body
2. Control Panel (Digital Display)
3. Air Outlet Louvers (Oscillating)
4. Water Tank (6 Liters capacity)
5. Rear Filter/Cooling Pad
6. Caster Wheels
7. Remote Control
8. Ice Packs (optional for enhanced cooling)



Figure 3.1: Front and angled views of the unit, showing the air outlet louvers and control panel. These images display the sleek white design of the air conditioner from the front and a slight angle, highlighting its vertical structure and the horizontal louvers for air distribution.





Figure 3.2: Rear view showing the removable water tank and air filter compartment.

This image provides a clear view of the back of the unit, with the water tank pulled out and the air filter visible, along with two blue ice packs.

4. SETUP AND INITIAL USE

4.1 Unpacking

Carefully remove the appliance from its packaging. Retain the packaging for future storage or transport. Check for any damage during transit. If the unit is damaged, do not operate it and contact customer support.

4.2 Positioning

Place the air conditioner on a flat, stable surface. Ensure there is adequate space around the unit (at least 20 cm) for proper airflow. Do not place it directly against a wall or in a corner that restricts air circulation. For optimal cooling, position the unit near an open window or door to allow fresh air intake.

4.3 Filling the Water Tank

1. Pull out the water tank from the rear of the unit.
2. Fill the tank with clean tap water. Do not exceed the "MAX" fill line indicated on the tank. The tank capacity is 6 liters.
3. For enhanced cooling, you may place the provided ice packs (after freezing them) into the water tank.
4. Carefully slide the water tank back into the unit until it clicks into place. Ensure it is securely closed to prevent leaks.



Figure 4.1: Water tank with ice packs ready for insertion.

This image focuses on the clear water tank and two blue ice packs, illustrating how they are used together to enhance the cooling effect.

4.4 Power Connection

Plug the power cord into a suitable electrical outlet (220-240V, 50Hz). The unit will emit a beep sound, and the digital display will light up, indicating it is in standby mode.

5. OPERATING INSTRUCTIONS

The unit can be operated using the control panel on top of the unit or the remote control.



Figure 5.1: Digital control panel with various function buttons.

This detailed image shows the top control panel of the unit, featuring a digital display and touch-sensitive buttons for Ion, Cooler, Swing, Timer, Speed, and On/Off functions.





Figure 5.2: Remote control for convenient operation.

This image shows a hand holding the compact remote control, which mirrors the functions available on the main unit's control panel.

5.1 Control Panel and Remote Functions

Button/Function	Description
ON/OFF	Powers the unit on or off.
SPEED	Cycles through fan speeds: Low (1000 rpm), Medium (1150 rpm), High (1250 rpm).

Button/Function	Description
TIMER	Sets the auto-off timer from 1 to 12 hours. Each press increases the timer by 1 hour.
SWING	Activates or deactivates the automatic horizontal oscillation of the louvers for wider air distribution.
COOLER	Activates the evaporative cooling function. Requires water in the tank. The water pump will start.
ION	Activates or deactivates the ionizer function, which helps to purify the air.

5.2 Operating Modes

- **Fan Mode:** The unit operates as a fan, circulating air at the selected speed. The COOLER function is off.
- **Cooling Mode:** With water in the tank and the COOLER function activated, the unit provides evaporative cooling, humidifying the air as it cools.
- **Ionizer Mode:** Can be activated independently or in conjunction with Fan or Cooling modes to release negative ions into the air.

6. MAINTENANCE AND CLEANING

Regular maintenance ensures optimal performance and extends the lifespan of your appliance.

6.1 General Cleaning

- Always unplug the unit before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure no water enters the control panel or electrical components.

6.2 Water Tank Cleaning

To prevent mold and mildew growth, clean the water tank regularly, especially if the unit is used frequently or stored for extended periods.

1. Unplug the unit.
2. Pull out the water tank.
3. Empty any remaining water.
4. Clean the tank with a mild detergent and warm water. Rinse thoroughly to remove any soap residue.
5. Dry the tank completely before reinserting it into the unit.

6.3 Air Filter/Cooling Pad Cleaning

The air filter and cooling pad should be cleaned periodically to maintain airflow and cooling efficiency.

1. Unplug the unit.
2. Locate the filter compartment at the rear of the unit (behind the water tank).
3. Remove the filter and cooling pad.
4. Rinse the filter and cooling pad under running water to remove dust and debris. For stubborn dirt, use a soft brush.
5. Allow the filter and cooling pad to air dry completely before reinserting them. Do not expose to direct sunlight.

6.4 Storage

If the unit will not be used for a long period, ensure it is clean and dry before storing. Empty and clean the water tank and filter. Store the unit in a cool, dry place, preferably in its original packaging.

7. TROUBLESHOOTING

Before contacting customer service, please refer to the following table for common issues and their solutions.

Problem	Possible Cause	Solution
Unit does not turn on.	No power supply. Power button not pressed.	Check if the power cord is securely plugged into a working outlet. Press the ON/OFF button.
No cooling effect.	Water tank is empty. COOLER function not activated. Air filter/cooling pad is dirty.	Fill the water tank. Press the COOLER button. Clean the air filter and cooling pad.
Weak airflow.	Air inlets/outlets blocked. Air filter is dirty.	Ensure nothing is obstructing the air vents. Clean the air filter.
Water leakage.	Water tank not properly installed. Water level too high.	Reinstall the water tank correctly. Do not exceed the "MAX" fill line.
Remote control not working.	Batteries are dead or incorrectly inserted. Obstruction between remote and unit.	Replace batteries and ensure correct polarity. Remove any obstructions. Ensure remote is pointed at the unit.

8. TECHNICAL SPECIFICATIONS

Feature	Specification
Model Number	BP2007
Power	80 W
Water Tank Capacity	6 Liters
Timer	Up to 12 hours
Fan Speeds	3 (Low, Medium, High)
Special Functions	Ionizer, Oscillating Movement, Humidifier
Dimensions (L x W x H)	32.9 x 32.1 x 74.9 cm
Weight	6.88 kg
Color	White

9. WARRANTY AND SUPPORT

This Blaupunkt product comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects and faulty materials under normal use.

The warranty does not cover:

- Damage caused by improper use, negligence, or accident.
- Damage caused by unauthorized repairs or modifications.
- Normal wear and tear.

Please retain your proof of purchase for warranty claims. For technical support, warranty claims, or spare parts inquiries, please contact your retailer or the authorized Blaupunkt service center in your region. Contact information can typically be found on the

manufacturer's official website or on your purchase receipt.



© 2024 Blaupunkt. All rights reserved.