

[Manuals.plus](#) /

> [KESSER](#) /

> KESSER 4-in-1 Portable Air Conditioner User Manual

## KESSER 13689-20303-2

# KESSER 4-in-1 Portable Air Conditioner

Model: 13689-20303-2 | Brand: KESSER

## 1. INTRODUCTION AND SAFETY INFORMATION

---

Thank you for choosing the KESSER 4-in-1 Portable Air Conditioner. This device combines the functions of an air cooler, fan, humidifier, and ionizer to provide a comfortable indoor environment. Please read this manual thoroughly before operating the device and keep it for future reference.

### Important Safety Instructions:

- Always ensure the power supply matches the voltage specified on the rating label.
- Do not immerse the unit, power cord, or plug in water or other liquids.
- Unplug the device from the power outlet when not in use, before filling or emptying the water tank, and before cleaning.
- Keep the appliance out of reach of children and pets.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Ensure the unit is placed on a stable, level surface to prevent tipping and water leakage.
- Do not block air inlets or outlets.

## 2. PRODUCT OVERVIEW

---

The KESSER 4-in-1 Portable Air Conditioner is designed for versatility and efficiency, offering cooling, ventilation, humidification, and air ionization. It features a user-friendly control panel and a remote control for convenient operation.



Figure 2.1: Overall view of the KESSER 4-in-1 Portable Air Conditioner, highlighting its multi-functional capabilities and remote control.

### Main Components:

- Control Panel with LED Display
- Air Outlet Louvers (adjustable)
- Water Tank (removable)
- Air Filter (honeycomb structure)
- Casters for mobility
- Remote Control

K&K KESSER®



Figure 2.2: Detailed view of the control panel and the remote control, showing various function buttons.

### 3. SETUP

#### 3.1 Unpacking and Placement:

1. Carefully remove the appliance from its packaging.
2. Place the air conditioner on a firm, level surface in the desired location. Ensure there is adequate space around the unit for proper airflow.
3. The integrated casters allow for easy movement of the unit.

#### 3.2 Filling the Water Tank:

For cooling and humidifying functions, the water tank must be filled.

1. Pull out the water tank from the bottom rear of the unit.
2. Fill the tank with clean tap water. Do not exceed the 'MAX' fill line.
3. For enhanced cooling, place the included ice packs (or ice cubes) into the water tank.

4. Carefully push the water tank back into the unit until it clicks into place.



Figure 3.1: Illustration of the removable water tank, showing the fill level and optional ice cubes for enhanced cooling.

### 3.3 Power Connection:

Plug the power cord into a suitable electrical outlet (220-240V AC).

## 4. OPERATING INSTRUCTIONS

The air conditioner can be operated via the control panel on the top of the unit or using the remote control.



Figure 4.1: Remote control layout with functions such as Power, Cooler, Mode, Speed, Swing, Humidify, Ion, and Timer.

#### 4.1 Power On/Off:

Press the **ON/OFF** button on the control panel or remote control to turn the unit on or off.

#### 4.2 Mode Selection:

Press the **MODE** button to cycle through the available modes:

- **Normal Mode:** Standard airflow.
- **Nature Mode:** Simulates natural, uneven airflow.
- **Sleep Mode:** Provides quiet operation with reduced fan speed.

#### 4.3 Speed Adjustment:

Press the **SPEED** button to select one of the three fan speeds: Low, Medium, or High.

#### 4.4 Oscillation (Swing) Function:

Press the **SWING** button to activate or deactivate the automatic horizontal oscillation of the louvers, distributing air across a wider area.

#### 4.5 Humidifier and Ionizer Functions:

- Press the **HUMIDIFY** button to activate the humidification function. Ensure the water tank is filled.
- Press the **ION** button to activate the air ionizer, which helps to purify the air.

#### 4.6 Timer Setting:

Press the **TIMER** button to set the operating time. The timer can be set in increments from 0.5 hours up to 4.5 hours. The unit will automatically turn off once the set time has elapsed.

## 5. MAINTENANCE

---

Regular maintenance ensures optimal performance and extends the lifespan of your air conditioner.

## 5.1 Cleaning the Air Filter:

The device features a honeycomb air filter that should be cleaned regularly.

1. Turn off the unit and unplug it from the power outlet.
2. Remove the air filter from the back of the unit.
3. Rinse the filter under running water to remove dust and debris. For stubborn dirt, use a soft brush and mild detergent.
4. Allow the filter to dry completely before reinserting it into the unit.



Figure 5.1: Illustration of how to remove and clean the air filter.

## 5.2 Cleaning the Water Tank:

To prevent mold and odors, clean the water tank regularly.

1. Turn off and unplug the unit.
2. Remove the water tank and empty any remaining water.
3. Clean the tank with a mild detergent and warm water. Rinse thoroughly.

4. Dry the tank completely before reinserting.

### 5.3 External Cleaning:

Wipe the exterior of the unit with a soft, damp cloth. Do not use abrasive cleaners or solvents.

## 6. TROUBLESHOOTING

---

If you encounter any issues, please refer to the following troubleshooting guide before contacting customer support.

Problem	Possible Cause	Solution
Unit does not turn on	No power supply; Power cord not plugged in; Power button not pressed.	Check power outlet; Plug in power cord securely; Press the ON/OFF button.
No cooling effect	Water tank empty; No ice packs/ice; Air filter dirty; Room too large.	Fill water tank; Add ice packs/ice; Clean air filter; Use in recommended room size (up to 60 m <sup>2</sup> ).
Weak airflow	Air filter dirty; Air inlets/outlets blocked.	Clean air filter; Ensure clear path for airflow.
Water leakage	Water tank not properly inserted; Unit tilted.	Ensure water tank is securely in place; Place unit on a level surface.

## 7. SPECIFICATIONS

---

Feature	Specification
Brand	KESSER
Model Number	13689-20303-2
Functions	Cooling, Fan, Humidifying, Ionizing
Control Type	Remote Control, On-unit buttons
Water Tank Capacity	8 Liters
Recommended Floor Area	Up to 60 Square meters
Power Consumption	65 W
Number of Fan Speeds	3
Timer	0.5 to 4.5 hours
Dimensions (D x W x H)	32 cm x 29 cm x 70 cm
Product Weight	Approx. 12 kg
Voltage	220-240V AC



Figure 7.1: Product dimensions and included accessories (remote control, ice packs).

## 8. WARRANTY AND SUPPORT

KESSER products are manufactured to high-quality standards. In the unlikely event of a defect or malfunction, please refer to your purchase documentation for warranty details and contact the seller or manufacturer directly for support. Please have your model number (13689-20303-2) and proof of purchase ready when contacting support.