



**Manuals.plus /**

- › **Comfort Zone /**
- › Comfort Zone PowrCurve 18-inch Pedestal Stand Fan Instruction Manual

## **Comfort Zone CZST180BK**

# **Comfort Zone PowrCurve 18-inch Pedestal Stand Fan Instruction Manual**

Model: CZST180BK

## **1. INTRODUCTION**

---

Thank you for choosing the Comfort Zone PowrCurve 18-inch Pedestal Stand Fan. This manual provides important information regarding the assembly, operation, maintenance, and troubleshooting of your new fan. Please read these instructions thoroughly before use and retain them for future reference.

This fan features a 6-blade design for enhanced airflow, a tri-curve grill for reduced noise, 3 speed settings, 180-degree adjustable tilt, and an oscillation function to effectively circulate air in your home or office.



Image: The Comfort Zone PowrCurve 18-inch Pedestal Stand Fan, black, with blue lines indicating powerful airflow.

## 2. IMPORTANT SAFETY INSTRUCTIONS

---

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using this fan.
- Use this fan only as described in this manual. Other uses not recommended may cause fire, electric shock, or injury to

persons.

- To protect against electrical shock, do not place fan in window, immerse unit, plug or cord in water or spray with liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug fan from outlet when not in use, when moving from one location to another, and before cleaning.
- Do not operate any fan with a damaged cord or plug, or after the fan malfunctions or has been dropped or damaged in any manner.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area where it will not be tripped over.
- Avoid contact with moving parts.
- This fan meets UL, ETL, SAA, CE, CSA, and NOM quality standards.

### 3. PACKAGE CONTENTS

---

Please check the package contents to ensure all parts are present and undamaged:

- Fan Motor Housing with Control Panel
- Front Grill
- Rear Grill
- Fan Blades (6 blades)
- Pedestal Pole (Adjustable Height)
- Round Base
- Base Weight (internal)
- Fasteners (nuts, bolts, screws for assembly)
- Power Cord with Fused Plug
- Instruction Manual (this document)

### 4. ASSEMBLY AND SETUP

---

Follow these steps to assemble your Comfort Zone PowrCurve Pedestal Stand Fan. It is recommended to perform assembly on a soft, flat surface to prevent scratching.

1. **Attach the Base:** Secure the pedestal pole to the round base using the provided fasteners. Ensure the base weight is correctly positioned within the base for stability.
2. **Mount the Motor Housing:** Attach the fan motor housing to the top of the pedestal pole. Ensure it is firmly secured.
3. **Install Rear Grill:** Place the rear grill onto the motor housing, aligning any tabs or notches. Secure it with the provided retaining nut or screws.
4. **Attach Fan Blades:** Carefully slide the 6 fan blades onto the motor shaft. Ensure they are seated correctly and secure them with the blade cap.
5. **Install Front Grill:** Align the front grill with the rear grill and secure them together using the clips or screws provided. Ensure the grills are tightly closed to prevent access to the blades.
6. **Adjust Height and Tilt:** The fan's height can be adjusted from 44 inches to 53 inches. Loosen the height adjustment knob on the pedestal pole, set to desired height, and tighten securely. The fan head can also be tilted up to 180 degrees to direct airflow.

## POWR CURVE™ TECHNOLOGY

with it's 6 BLADE FAN DESIGN  
has 30% HIGHER AIRFLOW for maximum cooling\*



\* compared to popular competitive models.

Tilt the head to suit your needs and to feel the best effects of the fan.

Image: Illustration of the fan's 6-blade design and the adjustable tilt feature.

## Quick Easy Assembly

ETL Approved for  
Sale in the **USA**



60 in. Cord with  
Safety Fused Plug

Image: Depicts the fan's quick and easy assembly, highlighting the 60-inch cord with a safety fused plug.

# Keep Yourself Cool and Comfortable



Pedestal Height Adjusts  
From **44 in.** to **53 in.**



**19"**  
Base Diameter



**POWR**  
**CURVE**<sup>™</sup>  
TECHNOLOGY\*

\* Powr Curve™ Technology, with its  
6-blade fan design, has 30% higher  
airflow for maximum cooling

Image: Shows the fan's adjustable pedestal height, ranging from 44 to 53 inches, and a 19-inch base diameter.

## 5. OPERATING INSTRUCTIONS

Once assembled, your fan is ready for use. Ensure the fan is placed on a stable, level surface and plugged into a standard 120V AC electrical outlet.

# Instant **Cooling** Where you Want It



Push Button  
Control with  
**3 Speed**  
Settings



**TRIPLE-ZONE**  
Tri-Curve Grille  
Eliminates Turbulance  
for stronger airflow  
with 20% less noise



**6-Blade fan**  
Design Increases  
Air Flow for Maximum  
Cooling

- Full Function Timer
- Widespread Oscillation



Image: The fan's control panel with push buttons for 3 speed settings, indicating widespread oscillation and a tri-curve grille for reduced noise.



Image: A detailed view of the fan's easy-to-use push-button control panel, showing settings for Low, Mid, and High fan speeds.

- **Power On/Off:** Press the '0' button to turn the fan off. Press '1', '2', or '3' to turn the fan on and select a speed.
- **Speed Selection:** Use the push-button control panel to select your desired airflow speed:
  - **1 (Low):** For a gentle breeze.
  - **2 (Mid):** For moderate cooling.
  - **3 (High):** For maximum airflow and cooling.
- **Oscillation:** To activate the oscillation feature, press the oscillation button located on the top of the motor housing. This will allow the fan head to sweep from side to side, distributing air over a wider area. Press the button again to stop oscillation.
- **Adjustable Tilt:** The fan head can be manually tilted up or down to direct airflow precisely where needed. Gently adjust the fan head to your preferred angle.
- **Night Light:** This fan includes a built-in night light for gentle illumination. Refer to the control panel for the dedicated night light button, if present, or consult the product packaging for specific activation instructions.

## 6. MAINTENANCE AND CLEANING

---

Regular cleaning and maintenance will ensure the longevity and optimal performance of your fan.

- **Always unplug the fan** from the electrical outlet before cleaning.
- Use a soft, damp cloth to clean the exterior surfaces of the fan. Do not use abrasive cleaners or solvents.
- To clean the fan blades and inside the grills, carefully remove the front grill (refer to assembly instructions in Section 4). Wipe the blades and interior surfaces with a soft, damp cloth. Ensure all parts are completely dry before reassembling the grill.
- The fan grills can be hand washed. Ensure they are completely dry before reattaching.
- Do not immerse the fan motor housing or power cord in water or any other liquid.
- For storage, keep the fan in its original packaging or cover it to protect it from dust. Store in a cool, dry place.

## 7. TROUBLESHOOTING

---

If your fan is not operating correctly, please consult the following common issues and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	No power to the unit; Power cord not fully plugged in; Blown fuse in plug.	Ensure the fan is securely plugged into a working electrical outlet. Check the fuse in the plug and replace if necessary. Test the outlet with another appliance.
Reduced airflow or unusual noise.	Obstruction in front or rear grill; Dust buildup on blades; Loose parts.	Unplug the fan. Check for any obstructions in the grills or on the blades and remove them. Clean the blades and grills as per maintenance instructions. Ensure all assembly parts are securely fastened.
Fan does not oscillate.	Oscillation button not engaged; Internal mechanism issue.	Press the oscillation button firmly. If the issue persists, unplug the fan and check for any visible obstructions around the oscillation mechanism.
Fan head does not stay tilted.	Tilt adjustment mechanism is loose or damaged.	Ensure the tilt adjustment knob or mechanism is tightened securely after adjusting the angle. If damaged, contact customer support.

If you experience issues not listed here or if the problem persists after attempting these solutions, please contact Comfort Zone customer support.

## 8. SPECIFICATIONS

---

<b>Brand</b>	Comfort Zone
<b>Model Name</b>	CZST180BK
<b>Color</b>	Black
<b>Product Dimensions</b>	16.54"D x 16.54"W x 54.33"H
<b>Item Weight</b>	12.68 Pounds
<b>Power Source</b>	Corded Electric
<b>Wattage</b>	88 watts
<b>Voltage</b>	120V
<b>Number of Blades</b>	6
<b>Blade Length</b>	18 Inches
<b>Air Flow Capacity</b>	2050 Cubic Feet Per Minute
<b>Noise Level</b>	55 dB
<b>Speed Settings</b>	3
<b>Special Features</b>	Adjustable Height, Adjustable Tilt, Oscillating, Built-in Night Light
<b>Control Method</b>	Push Button
<b>Indoor/Outdoor Usage</b>	Indoor
<b>Certifications</b>	ETL (Meets UL, ETL, SAA, CE, CSA, and NOM quality standards)

## 9. WARRANTY INFORMATION

---

This Comfort Zone PowrCurve Pedestal Stand Fan (Model CZST180BK) comes with a **1 Year Warranty Against Manufacturer Defects** from the date of purchase.

This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, abuse, accident, alteration, unauthorized repair, or failure to follow instructions in this manual. Please retain your proof of purchase for warranty claims.

## 10. CUSTOMER SUPPORT

---

For any questions, assistance, or to report a problem with your Comfort Zone fan, please contact our customer support team.

- **Online Support:** Visit the official Comfort Zone website for FAQs, product registration, and contact forms.
- **Brand Store:** You can also visit the Comfort Zone Store on Amazon for more product information and support resources.
- When contacting support, please have your model number (CZST180BK) and proof of purchase readily available.