

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [LIVIVO](#) /
- › [LIVIVO 80W Evaporative Air Cooler User Manual](#)

LIVIVO AC030-680

LIVIVO 80W Evaporative Air Cooler User Manual

Model: AC030-680

1. INTRODUCTION

Thank you for choosing the LIVIVO 80W Evaporative Air Cooler. This portable unit is designed to provide efficient cooling and humidification, enhancing your indoor comfort. Unlike traditional air conditioners, this evaporative cooler uses water to cool the air, offering a more natural and energy-efficient solution. Please read this manual thoroughly before operation to ensure proper use, maintenance, and to maximize the lifespan of your appliance.





The LIVIVO 80W Evaporative Air Cooler, complete with its remote control and included ice packs.

2. IMPORTANT SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions before using the appliance.
- Ensure the power supply matches the voltage specified on the rating label (230V).
- Do not immerse the appliance, plug, or cord in water or other liquids.
- Unplug from the outlet when not in use, before adding water, cleaning, or servicing.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Keep the appliance out of reach of children and pets.
- Do not block air inlets or outlets. Ensure adequate ventilation around the unit.

- Place the cooler on a stable, level surface to prevent tipping and water spillage.
- Do not use outdoors or in wet environments.
- Only use attachments/accessories specified by the manufacturer.

3. PRODUCT OVERVIEW AND COMPONENTS

Familiarize yourself with the main parts of your LIVIVO Evaporative Air Cooler:

- **Control Panel:** Digital display and buttons for operation.
- **Air Outlet:** Where cooled air is expelled.
- **Water Tank:** Removable tank for water and ice packs.
- **Casters:** Wheels for easy mobility.
- **Remote Control:** For convenient operation from a distance.
- **Ice Packs:** Included to enhance cooling performance.



Detailed view of the intuitive LED digital control panel.



The compact remote control for convenient operation.

4. SETUP AND INITIAL USE

1. **Unpacking:** Carefully remove the air cooler from its packaging. Retain packaging for future storage or transport.
2. **Positioning:** Place the unit on a firm, level surface. Ensure there is at least 20cm of space around the unit for proper airflow.
3. **Filling the Water Tank:**
 - Pull out the water tank from the bottom rear of the unit.
 - Fill the tank with clean tap water. Do not exceed the 'MAX' fill line. The tank capacity is 4 litres.
 - For enhanced cooling, place the included ice packs (after freezing them) into the water tank.
 - Carefully slide the water tank back into the unit until it clicks into place.



The removable 4-litre water tank for easy filling.



Ice packs can be added to the water tank for enhanced cooling.

4. **Power Connection:** Plug the power cord into a suitable electrical outlet.

5. OPERATING INSTRUCTIONS


Your air cooler can be operated using the control panel on the unit or the remote control.

5.1 Basic Functions

- **Power ON/OFF:** Press the 'ON/OFF' button to turn the unit on or off.
- **Speed Adjustment:** Press the 'Speed' button repeatedly to cycle through the 3 fan speeds: Low, Medium, High.
- **Cooler/Humidifier Function:** Press the 'Cooler' button to activate the evaporative cooling function. This will pump water from the tank to cool the air. Press again to deactivate.
- **Oscillation:** Press the 'Swing' button to activate the 120° oscillating function, which distributes air evenly across the room. Press again to stop oscillation.
- **Timer:** Press the 'Timer' button to set the auto-off timer. Each press adds 1 hour, up to a maximum of 4 hours (1H, 2H, 4H). The unit will automatically turn off after the set time.

5.2 Special Modes

- **Natural Wind Mode:** Press the 'Wind' button to activate natural wind mode, which simulates a natural breeze by varying fan speed.
- **Sleep Mode:** Press the 'Wind' button again to activate sleep mode. In this mode, the fan speed gradually decreases to provide a quieter environment for sleep.



Air coolers release chilled moisture into the air, providing greater cooling than traditional electric fans.

The air cooler effectively releases chilled moisture into the air, providing greater cooling than traditional electric fans.

6. MAINTENANCE AND CARE

Regular cleaning and maintenance will ensure optimal performance and extend the life of your air cooler.

6.1 Cleaning the Exterior

- Always unplug the unit before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure no water enters the control panel or other electrical parts.

6.2 Cleaning the Water Tank and Filter

- Remove the water tank from the unit.
- Empty any remaining water.
- Clean the tank with mild soap and water. Rinse thoroughly.
- The dust filter should be cleaned regularly (e.g., weekly) by rinsing it under running water. Allow it to dry

completely before reinserting.

- If the water in the tank appears discolored (e.g., brownish/yellowish), it indicates the filter needs cleaning or replacement.

6.3 Storage

- Before storing, ensure the water tank is empty and clean, and the unit is dry.
- Store the appliance in a cool, dry place, away from direct sunlight and extreme temperatures.
- It is recommended to store the unit in its original packaging to protect it from dust and damage.

7. TROUBLESHOOTING

If you encounter issues with your air cooler, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit does not turn on	No power supply; Power button not pressed.	Check if the plug is securely in the outlet; Press the 'ON/OFF' button.
No cool air / Weak cooling	Water tank empty; Cooler function not activated; Filter is dirty.	Fill water tank; Press 'Cooler' button; Clean or replace filter.
Water leakage	Water tank not properly inserted; Tank overfilled; Unit is tilted.	Ensure tank is securely in place; Do not exceed 'MAX' fill line; Place unit on a level surface.
Unusual noise	Low water level (trickling sound); Obstruction in fan.	Refill water tank; Check for and remove any obstructions (unplug first).
Remote control not working	Batteries dead or incorrectly inserted; Obstruction between remote and unit.	Replace batteries (if applicable, unit states no batteries included); Ensure clear line of sight.

If the problem persists after trying these solutions, please contact LIVIVO customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	AC030-680
Power	80W
Voltage	230V
Water Tank Capacity	4 Litres
Dimensions (L x W x H)	24cm x 26cm x 57cm (approx.)
Weight	4 kg
Fan Speeds	3 (Low, Medium, High)

Feature	Detail
Oscillation	120° Automatic Swing
Timer Function	Up to 4 hours (1H, 2H, 4H)
Special Features	Natural Wind Mode, Sleep Mode, Remote Control, LED Display

DIMENSIONS & SPECIFICATIONS



3 fan power settings



Sleep soundly with night mode



Air cooler holds 4L of water



Smooth 120° oscillation



Room temperature display



Remote control included



Your home, your style.

LIVIVO

Visual representation of the air cooler's dimensions.

9. WARRANTY AND SUPPORT

Your LIVIVO 80W Evaporative Air Cooler comes with a standard manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions. For technical support, spare parts, or any inquiries not covered in this manual, please contact LIVIVO customer service through their official website or the retailer from whom you purchased the product.

For more information and product registration, visit the official LIVIVO website: [LIVIVO Store on Amazon](#)



© 2025 LIVIVO. All rights reserved.