



[Manuals.plus](#) /

> [OMOTON](#) /

> OMOTON Wireless AZERTY Keyboard B0974FPZDZ Instruction Manual

OMOTON B0974FPZDZ

OMOTON Wireless AZERTY Keyboard B0974FPZDZ Instruction Manual

Model: B0974FPZDZ

INTRODUCTION

Thank you for choosing the OMOTON Wireless AZERTY Keyboard. This manual provides essential information for the proper setup, operation, and maintenance of your keyboard. Please read these instructions carefully before use to ensure optimal performance and longevity of your device.



Image: Top-down view of the OMOTON Wireless AZERTY Keyboard, showcasing its full layout including the numeric keypad.

PRODUCT OVERVIEW

The OMOTON Wireless AZERTY Keyboard is a compact, rechargeable Bluetooth keyboard designed for versatility and ease of use across multiple operating systems.

Key Features:

- **Compact Design:** Measuring 36.2 x 11.6 x 2.1 cm, it is smaller than traditional keyboards, making it highly portable.
- **High Compatibility:** Supports Windows and Mac OS systems, suitable for PCs, laptops, MacBooks, and iPads.
- **Rechargeable Battery:** Equipped with a 300mA lithium battery, eliminating the need for disposable batteries.
- **Automatic Reconnection:** Connects automatically upon power-on, saving time on re-pairing.
- **Ultra-thin and Lightweight:** Weighs approximately 450±15g, constructed from durable plastic for portability.
- **Responsive Keys:** Features a scissor-structure key design for a smooth and quiet typing experience.
- **Ergonomic Design:** Offers an optimal 8-degree gradient for comfortable typing.

Dimensions and Design:




Image: Detailed diagram showing the dimensions of the OMOTON Wireless AZERTY Keyboard: 362mm (14.3in) length, 116.5mm (4.6in) width, and thickness ranging from 6.9mm (0.27in) to 21.5mm (0.85in).



Image: Side view illustrating the ergonomic 8-degree tilt of the keyboard for comfortable typing.



Image: The keyboard with an icon indicating its silent operation, highlighting the quiet typing experience.



TOUCHES REACTIVES

La touche de structure à ciseaux offre une expérience de frappe douce et silencieuse



Image: Close-up view of the keyboard's keys, illustrating the reactive scissor-structure mechanism for smooth and silent typing.

SETUP AND PAIRING INSTRUCTIONS

Follow these steps to connect your OMOTON Wireless AZERTY Keyboard via Bluetooth:

1. **Power On:** Locate the ON/OFF switch on the keyboard and slide it to the "ON" position.
2. **Enable Bluetooth:** Ensure that Bluetooth is enabled on your device (PC, laptop, MacBook, iMac, tablet). Navigate to your device's settings and turn Bluetooth on.
3. **Enter Pairing Mode:** Simultaneously press the **Fn + C** keys on the keyboard. The blue Bluetooth indicator light on the keyboard will begin to flash, indicating it is in pairing mode.
4. **Select Keyboard:** On your device, search for available Bluetooth devices. Select "OMOTON Keyboard" from the list to complete the pairing process.
5. **Pairing Confirmation:** The blue indicator light on the keyboard will turn off once pairing is successful.

Note: After successful pairing, the green power indicator light will remain on in Windows systems but not in macOS.



Image: Close-up of the keyboard's top right corner, showing the power switch (OFF/ON) and indicator lights for low battery/charging, Bluetooth status, and Caps Lock.

Compatibility and System Switching:

The keyboard is designed to be compatible with both Windows and Mac OS.



Image: Illustration demonstrating the keyboard's universal compatibility with both Windows and Mac OS devices.



Image: Close-up of the Alt and Win/Cmd keys, indicating their dual functionality for Windows (Win | Alt) and Mac OS (Alt (option) | Command). Note that the orange symbol is only available on Mac OS.

Function Keys and Shortcuts:

The keyboard features dedicated function keys (F1-F12) that provide quick access to various system controls. To use these functions, press the **Fn** key simultaneously with the desired function key.

Function Key Overview

Key Combination	Function
Fn + Esc	Lock/Unlock
Fn + F1	Brightness Down
Fn + F2	Brightness Up
Fn + F3	Application Switch
Fn + F4	Multi-window Display
Fn + F5	Mute
Fn + F6	Volume Down
Fn + F7	Volume Up
Fn + F8	Previous Track
Fn + F9	Play/Pause
Fn + F10	Next Track
Fn + F11	Browser/Home
Fn + F12	Search

Touches de raccourcis




Image: Visual representation of the keyboard's shortcut keys (F1-F12) and their corresponding functions.

VERR FN & TOUCHES DE RACCOURCI



Esc	Esc	F7	Volume+
F1	Luminosité-	F8	Piste précédente
F2	Luminosité+	F9	Lecture/Pause
F3	Changement d'application	F10	Piste suivante
F4	Affichage multi-fenêtres	F11	Navigateur
F5	Muet	F12	Recherche
F6	Volume-		

Image: Diagram showing the Fn lock and various shortcut keys with their functions, including brightness, volume, media control, and application switching.

CHARGING AND BATTERY

The OMOTON Wireless AZERTY Keyboard is equipped with a built-in rechargeable lithium battery.

- **Battery Capacity:** 300mA.

- **Charging Time:** Approximately 2 hours for a full charge.
- **Standby Time:** Up to 90 days on a full charge.
- **Charging Method:** Use the provided USB-C cable to connect the keyboard to a power source.
- **Low Battery Indicator:** The keyboard features an indicator light that signals when the battery is low or when it is charging.



2 heures
Temps de charge



90 jours
Temps de veille

Image: Graphic illustrating the charging specifications: 2 hours charging time and 90 days standby time.



Rechargeable



Bluetooth



Économie d'énergie
intelligente



Silencieux



Longue durée de vie
de la batterie



Image: Icons representing key features: rechargeable, Bluetooth connectivity, intelligent power saving, silent operation, and long battery life.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the keyboard surface. For deeper cleaning, a slightly damp cloth with mild soap can be used, ensuring no liquid enters the keyboard.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Liquids:** This keyboard is not waterproof. Avoid exposing it to liquids to prevent damage.
- **Charging:** Charge the keyboard regularly, even if not in frequent use, to maintain battery health.

TROUBLESHOOTING

- **Keyboard not connecting:**
 - Ensure the keyboard is powered on and fully charged.
 - Verify Bluetooth is enabled on your device.

- Re-enter pairing mode by pressing **Fn + C** and try pairing again.
- Remove "OMOTON Keyboard" from your device's Bluetooth list and attempt to pair from scratch.
- Restart both the keyboard and your device.

- **Keys not responding or double typing:**

- Ensure the keyboard is fully charged. Low battery can affect key responsiveness.
- Check for any physical obstructions under the keys.
- If the issue persists, try connecting the keyboard to another device to determine if the problem is with the keyboard or the original device.

- **Short battery life:**

- Ensure the keyboard is fully charged for the recommended 2 hours.
- Avoid leaving the keyboard powered on when not in use for extended periods.

SPECIFICATIONS

Feature	Detail
Brand	OMOTON
Model Number	B0974FPZDZ
Connectivity Technology	Bluetooth
Keyboard Description	Wireless
Recommended Use	Office
Special Feature	Rechargeable
Style	Contemporary
Product Dimensions (L x W x H)	36.2 x 11.6 x 2.1 cm (14.3 x 4.6 x 0.85 inches)
Material	Plastic
Power Source	Battery Powered (300mA Lithium Battery)
Keyboard Layout	AZERTY
Number of Keys	105
Water Resistance Level	Not Waterproof
Compatible Operating Systems	MacOS, Windows

WARRANTY AND SUPPORT

OMOTON products are subject to quality control and inspection. If you encounter any issues or have questions regarding your keyboard, please contact OMOTON customer support.

- **Quality Assurance:** Products undergo inspection and quality control.
- **Customer Service:** For damaged goods or any problems, contact customer support for a satisfactory solution within 24 hours.
- **Principle:** Quality and service are OMOTON's core principles.

For further assistance, please refer to the official OMOTON website or contact their customer service directly.



© 2026 OMOTON. All rights reserved.