#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- AUKEY /
- > AUKEY Sprint Wireless Power Bank PB-Y32 User Manual

#### **AUKEY PB-Y32**

# AUKEY Sprint Wireless Power Bank PB-Y32 User Manual

Model: PB-Y32 | Capacity: 10000 mAh

# 1. Introduction

Thank you for choosing the AUKEY Sprint Wireless Power Bank PB-Y32. This device is designed to provide portable power for your mobile devices, featuring both wired and wireless fast charging capabilities. Please read this manual carefully before use to ensure optimal performance and safety.

# 2. PRODUCT FEATURES

- 10000 mAh Capacity: High-capacity battery to charge your devices multiple times.
- Fast Charging Support: Supports Quick Charge 3.0 and Power Delivery for rapid charging of compatible devices.
- Wireless Charging: Conveniently charge Qi-compatible devices at up to 10W.
- Multiple Output Ports: Equipped with USB-C and USB-A ports for versatile charging.
- Compact and Portable Design: Easy to carry for on-the-go power.
- Safety Features: Built-in protections against overcharge, over-discharge, overcurrent, and short circuits.

# 3. PACKAGE CONTENTS

- AUKEY Sprint Wireless Power Bank PB-Y32
- USB-A to C Cable
- User Manual

# 4. SETUP AND INITIAL USE

# 4.1 Charging the Power Bank

Before first use, fully charge the power bank. It takes approximately 7 hours to fully charge the power bank

using a compatible USB-C power adapter.

- 1. Connect the included USB-A to C cable to the power bank's USB-C input port.
- 2. Connect the other end of the cable to a USB wall charger (not included).
- 3. The LED indicators will light up to show the charging status. All four LEDs will be solid when fully charged.



Image: The AUKEY Sprint Wireless Power Bank PB-Y32, showcasing its sleek black design and port layout.

# 5. OPERATING INSTRUCTIONS

# 5.1 Wired Charging

To charge your device using a cable:

- 1. Connect your device's charging cable to either the USB-A output port or the USB-C output port on the power bank.
- 2. Connect the other end of the cable to your device.
- 3. The power bank will automatically begin charging your device.




Image: The power bank connected via cable to a smartphone, demonstrating 18W Power Delivery fast charging.




Image: A smartphone connected to the power bank, illustrating Qualcomm Quick Charge 3.0 capabilities for rapid charging.

# 5.2 Wireless Charging

To charge your Qi-compatible device wirelessly:

- 1. Place your Qi-compatible device directly onto the wireless charging pad located on the top surface of the power bank. Ensure the device is centered on the charging symbol.
- 2. The power bank will automatically detect your device and begin wireless charging.




Image: A smartphone placed on the power bank's surface, demonstrating the wireless charging feature.



Image: A close-up view of the power bank showing the silicone ring designed to keep the phone stable during wireless charging.

# 5.3 Low-Current Charging Mode

This mode is ideal for charging low-power devices like wireless earbuds or smartwatches.

- 1. Press and hold the power button for 2 seconds to enter low-current charging mode. The first LED indicator will blink green.
- 2. Connect your low-power device or place it on the wireless charging pad.

3. To exit low-current charging mode, press the power button once, or it will automatically exit after 2 hours.



Image: The power bank connected to a smartphone and wireless earbuds, demonstrating its low-current charging mode for smaller devices.



Image: An illustration showing the power bank's broad compatibility with various devices, including smartphones, tablets, and gaming consoles.

# 6. MAINTENANCE

• Keep the power bank away from liquids, extreme heat, and strong magnetic fields.

- Do not drop or subject the power bank to strong impacts.
- Clean the power bank with a dry, soft cloth. Do not use corrosive cleaners.
- Store the power bank in a cool, dry place when not in use.
- Recharge the power bank at least once every 3 months to maintain battery health.

# 7. TROUBLESHOOTING

# 7.1 Power Bank Not Charging

- Ensure the charging cable is securely connected to both the power bank and the wall charger.
- Try a different USB-C cable or wall charger.
- Verify the wall charger's output meets the power bank's input requirements (DC 5V-3A / 9V-2A).

# 7.2 Device Not Charging from Power Bank

- Ensure the power bank has sufficient charge.
- Try a different charging cable for your device.
- For wireless charging, ensure your device is Qi-compatible and properly aligned on the charging pad. Remove any thick cases that might interfere.
- If charging a low-power device, ensure low-current charging mode is activated.

# 7.3 Power Bank Overheating

- It is normal for the power bank to become slightly warm during charging or discharging.
- If it becomes excessively hot, disconnect all devices and the charging cable immediately. Allow it to cool down before resuming use.
- Ensure proper ventilation and avoid covering the power bank during use.

# 8. Specifications

Feature	Detail
Model Name	Sprint
Model Number	PB-Y32
Battery Capacity	10000 mAh
USB Type-C Input	DC 5V-3A / 9V-2A
USB Type-C Output	DC 5V-3A / 9V-2A / 12V-1.5A
USB Type-A Output	18W
Max Output Power	18W
Wireless Charging Output	5W, 7.5W, 10W
Dimensions	144 x 67 x 17 mm

Feature	Detail
Weight	210 grams
Battery Cell Composition	Lithium Polymer
Special Features	Short Circuit Protection, Wireless Charging
Color	Black
Battery Charging Time	7 hours

# 9. WARRANTY AND SUPPORT

According to the product specifications, this product comes with**No Warranty**. For any product-related inquiries or support, please refer to the retailer or manufacturer's official website for contact information.

© 2024 AUKEY. All rights reserved.

#### Related Documents - PB-Y32

17.00		100		III.		
-			3	ā		
*	- 116				B	12300.
			E-		100	100
			MCC.	Lauren		

#### AUKEY Sprint X 20K 30W Power Bank User Manual & Specifications

Comprehensive user manual for the AUKEY Sprint X 20K 30W Power Bank (Model PB-Y42), including charging instructions, product care, safety precautions, and detailed specifications.



# Aukey PB-T5 20000 mAh Quick Charge Power Bank User Guide

Learn how to charge your Aukey PB-T5 20000 mAh Quick Charge Power Bank, use its flashlight, and important safety precautions. Features AiPower technology for optimal charging.



Liser Manual 10000mAh Universal Pavver Bank withPower Delivery 20 and Gudcomm<sup>®</sup> Curck Change<sup>®</sup> 2.0

#### AUKEY PB-Y22 10000mAh Universal Power Bank User Manual


User manual for the AUKEY PB-Y22 10000mAh Universal Power Bank, featuring Power Delivery 2.0 and Qualcomm Quick Charge 3.0. Includes specifications, product diagram, charging instructions, and care guidelines.

# AUKEY

User Manual 8000mAh Wireless Charging Power Bank with Fower Delivery 25 and Qualcomm? Quick Charge "3.0

#### AUKEY PB-Y25 8000mAh Wireless Charging Power Bank User Manual

User manual for the AUKEY PB-Y25 8000mAh Wireless Charging Power Bank, detailing its specifications, package contents, charging methods (wireless, wired, low-current), product care, and customer support information.



# AUKEY PB-Y3 30000mAh Type-C Power Bank Introduction Manual

Official introduction manual for the AUKEY PB-Y3 30000mAh Type-C Power Bank. Details features, technical specifications, AiPower and Qualcomm Quick Charge 3.0 technologies, charging instructions, cautions, FAQs, and warranty information.



#### AUKEY PB-XD13 20000mAh USB-C Power Bank User Manual and Specifications

Detailed user manual for the AUKEY PB-XD13 20000mAh USB-C Power Bank. Covers features like USB Power Delivery and Quick Charge 3.0, low-current charging mode, technical specifications, usage instructions, product care, and warranty information.