

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Kimwood](#) /

› [Kimwood Wired Earbuds ME537 Instruction Manual](#)

Kimwood ME537

Kimwood Wired Earbuds with Microphone - Model ME537

User Instruction Manual

INTRODUCTION

Thank you for choosing Kimwood Wired Earbuds, Model ME537. These in-ear headphones are designed to provide a high-quality audio experience with a built-in microphone for clear communication. This manual provides essential information on how to set up, operate, maintain, and troubleshoot your earbuds to ensure optimal performance and longevity.

SAFETY INFORMATION

- Avoid listening at high volume levels for extended periods to prevent hearing damage.
- Do not use the earbuds in situations where inability to hear ambient sounds could be dangerous, such as while driving or cycling.
- Keep the earbuds away from water and moisture.
- Do not attempt to disassemble or modify the earbuds. This will void the warranty.
- Keep out of reach of children.

PACKAGE CONTENTS

The Kimwood Wired Earbuds package includes the following items:

- 1 x Kimwood Wired Earbuds with Microphone (Model ME537)
- 1 x Stylish Storage Bag


PRODUCT OVERVIEW

The Kimwood ME537 earbuds feature an ergonomic design for comfortable wear and a 3.5mm jack for universal compatibility. The inline remote control allows for easy management of audio and calls.



Image 1: Kimwood Wired Earbuds, showing the left and right earpieces, inline remote, and 3.5mm audio jack.

The earbuds are designed with a focus on sound quality, featuring a 15mm dynamic driver for balanced audio across bass, midrange, and treble frequencies.



15mm Oversized caliber and Dynamic drive

The Nature of HiFi Sound

Deep Bass, Soft Medium, and Crisp Highs

It provides a wide immersion sound field and a powerful musical performance.

Image 2: Diagram illustrating the internal components of the earbud, highlighting the 15mm oversized dynamic driver responsible for HiFi sound quality.

SETUP

Connecting your Kimwood Wired Earbuds is a straightforward process:

- Identify the Audio Jack:** Locate the 3.5mm headphone jack on your device (smartphone, tablet, computer, MP3 player, etc.).
- Insert the Plug:** Gently insert the 3.5mm audio plug of the earbuds into your device's headphone jack until it is fully seated.
- Wear the Earbuds:** Place the left earbud (marked 'L') into your left ear and the right earbud (marked 'R') into your right ear. Adjust for a comfortable and secure fit.

Compatibility Note: These earbuds are compatible with most devices featuring a standard 3.5mm headphone jack.

Devices without a 3.5mm jack will require a compatible adapter (not included). Please note that volume control functionality on the inline remote may vary or not work with certain devices, such as some computers, laptops, MacBooks, iPods, iPads, or Nintendo Switch consoles. In such cases, adjust the volume directly on the connected device.

3.5mm Wired Headphones



Compatible with iPhone, iPad, Android Phones, Tablets, and all other music devices with 3.5mm headphone jack.



No Bluetooth




Image 3: Illustration showing the 3.5mm wired connection and various compatible devices including smartphones, tablets, computers, and gaming consoles.

OPERATING INSTRUCTIONS

The inline remote control provides convenient access to various functions:



Built-in HD Microphone and Remote Control



• Phone Call:

Press Once: Answer/End Call

Long Press: Reject Call

• Active Siri (iPhone)
↓
Long Press



• Music Play:

Press Once: Play/Pause Music

Press Twice: Next Track

Press Three Times: Previous Track

Image 4: Close-up of the inline remote control with buttons labeled for volume, play/pause, and microphone.

• Volume Control:

- Press the '+' button to increase volume.
- Press the '-' button to decrease volume.

• Music Playback:

- Press the center button once to Play/Pause music.
- Press the center button twice to skip to the Next Track.
- Press the center button three times to go to the Previous Track.

• Phone Calls:

- Press the center button once to Answer/End a call.
- Long press the center button to Reject an incoming call.

- **Voice Assistant:**

- Long press the center button to activate Siri (on compatible iPhone devices).

MAINTENANCE

Proper care ensures the longevity and performance of your earbuds:

- **Cleaning:** Gently wipe the earbuds with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earbuds in the provided stylish storage bag to protect them from dust, dirt, and tangles.
- **Cable Care:** Avoid sharply bending or pulling the cable to prevent internal damage. The TPU material is designed for durability and tangle resistance.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound or low volume	<ul style="list-style-type: none">• Earbuds not fully plugged in.• Device volume is too low or muted.• Incorrect audio output selected on device.• Damaged cable or jack.	<ul style="list-style-type: none">• Ensure the 3.5mm jack is fully inserted.• Increase volume on your device.• Check device audio settings and select the correct output.• Test with another device to rule out damage.
Microphone not working	<ul style="list-style-type: none">• Microphone muted on device.• Incorrect audio input selected on device.• Incompatible device.	<ul style="list-style-type: none">• Check device settings to ensure microphone is not muted.• Select the earbuds as the audio input device.• Confirm device compatibility; some devices may not support inline microphone functions.
Inline remote buttons not responding	<ul style="list-style-type: none">• Incompatible device.• Software glitch on device.	<ul style="list-style-type: none">• As noted in Setup, some devices (e.g., certain computers, iPads) may not fully support remote functions. Adjust controls directly on the device.• Restart your device.

SPECIFICATIONS

Feature	Detail

Feature	Detail
Model Name	Wired Earbuds (ME537)
Connectivity Technology	Wired
Headphones Jack	3.5 mm Jack
Ear Placement	In Ear
Form Factor	In Ear
Control Type	Media Control
Special Features	Lightweight, Microphone Included, Passive Noise Cancellation, Volume Control
Cable Material	Thermoplastic Polyurethane (TPU)
Item Weight	0.39 Ounces (approx. 11g)
Frequency Range	20 Hz - 20,000 Hz
Included Components	Earphone, Storage Bag

WARRANTY AND SUPPORT

Kimwood provides a 1-year worry-free support for this product. If you encounter any issues or have questions regarding your Kimwood Wired Earbuds, please do not hesitate to contact our customer support team.

Contact Information:

- Email: Earbuds-aftersales@outlook.com

We are committed to providing hassle-free replacement/return services and professional support.

© 2023 Kimwood. All rights reserved.

Documents - Kimwood – ME537

no relevant documents