

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Broonel](#) /

› Broonel Fine Point Digital Active Stylus Pen User Manual

## Broonel Fine Point Digital Active Stylus Pen

# Broonel Fine Point Digital Active Stylus Pen User Manual

Model: Fine Point Digital Active Stylus Pen

[Introduction](#)

[Setup](#)

[Operating  
Instructions](#)

[Maintenance](#)

[Warranty &  
Support](#)

[Troubleshooting](#)

[Specifications](#)

## 1. INTRODUCTION

---

Thank you for choosing the Broonel Fine Point Digital Active Stylus Pen. This stylus is designed to provide a precise and natural writing and drawing experience on a wide range of touchscreen devices. Please read this manual carefully to ensure proper use and optimal performance of your new stylus.

### Package Contents:

- Broonel Fine Point Digital Active Stylus Pen
- 1 x AAA Battery
- User Manual (this document)

## 2. SETUP

---

### 2.1 Installing the Battery

1. Unscrew the top cap of the stylus counter-clockwise.
2. Insert the included AAA battery into the battery compartment, ensuring the positive (+) and negative (-) terminals are correctly aligned.
3. Screw the top cap back on clockwise until secure.

### 2.2 First Use

The Broonel Fine Point Digital Active Stylus Pen does not require Bluetooth pairing. Once the battery is installed, simply press the power button located on the side of the stylus to turn it on. The LED indicator will illuminate, signifying it is ready for use.



**Image 1:** Close-up view of the stylus highlighting the LED ON/OFF switch and the adjustable 2.3mm nib. This image illustrates the key functional components of the stylus.

### 3. OPERATING INSTRUCTIONS


---

#### 3.1 Powering On/Off

- To turn on: Press the power button once. The LED indicator will light up.
- To turn off: Press the power button once again. The LED indicator will turn off.
- The stylus may also have an automatic power-off feature after a period of inactivity to conserve battery.

#### 3.2 Using the Stylus

The stylus is designed for precise input on compatible iOS and Android touchscreen devices. Hold the stylus as you would a regular pen. The fine 2.3mm nib allows for detailed writing, drawing, and navigation.



**Image 2:** An overhead shot demonstrating the stylus in use on a tablet for drawing, alongside a smartphone and a cup of coffee, illustrating its application in creative tasks.

### **3.3 Adjustable Nib**

The stylus features an adjustable nib that allows for varying sensor depth. This feature helps in achieving more accurate depth of field, enhancing the precision of your input. No specific adjustment tool is typically required; the nib adjusts automatically based on pressure or can be gently twisted if designed for manual adjustment (refer to specific product details if applicable).



**Image 3:** A hand precisely using the stylus on a tablet screen, which displays a detailed car design in a professional software, highlighting the stylus's accuracy for intricate work.

### 3.4 Compatibility

This stylus is designed to be compatible with a wide range of iOS and Android Tablet PCs and Smartphones. It is specifically compatible with devices such as the HP EliteBook x360 1040 G7 14" FHD Touchscreen Convertible Laptop.



**Image 4:** A user holding a tablet and sketching a car design with the stylus, positioned in front of a real red sports car, showcasing the stylus's utility for design and creative professionals.



**Image 5:** A hand actively using the stylus on a tablet screen that displays a collage of digital art and design elements, emphasizing its versatility across different creative applications.

## 4. MAINTENANCE

---

### 4.1 Cleaning

To clean your stylus, gently wipe the body with a soft, dry, lint-free cloth. Do not use abrasive cleaners, alcohol, or solvents, as these can damage the finish or internal components. Avoid getting moisture into the nib or battery compartment.

### 4.2 Storage

When not in use, store the stylus in a safe place to prevent damage to the nib. If storing for an extended period, it is recommended to remove the AAA battery to prevent potential leakage and damage to the stylus.

### 4.3 Nib Replacement

The 2.3mm nib is designed for durability. If the nib becomes worn or damaged over time, contact Broonel customer support for information on replacement nibs and instructions.

## 5. TROUBLESHOOTING

---

- **Stylus not turning on:**

- Ensure the AAA battery is correctly installed with the correct polarity.
- Replace the AAA battery with a new one.
- Ensure the top cap is securely screwed on.

- **Stylus not responding on screen:**

- Ensure the stylus is turned on (LED indicator illuminated).
- Check if your device's screen is clean and free of debris.
- Verify that your device is compatible with active stylus technology.
- Try restarting your tablet or smartphone.

- Ensure the nib is not damaged.
- **Inaccurate or inconsistent input:**
  - Ensure your screen is clean.
  - Check for any screen protectors that might interfere with stylus performance.
  - Ensure the nib is fully seated and not loose.
  - Some applications may have specific stylus settings; check app preferences.

## 6. SPECIFICATIONS

Feature	Detail
Model	Fine Point Digital Active Stylus Pen
Brand	Broonel
Color	Black
Nib Size	2.3mm (Adjustable)
Power Source	1 x AAA Battery
Connectivity	No Bluetooth Required
Compatibility	iOS & Android Tablet PCs & Smartphones (e.g., HP EliteBook x360 1040 G7)
ASIN	B097YVPLY1
Date First Available	June 25, 2021

## 7. WARRANTY & SUPPORT

### 7.1 Warranty Information

Broonel products are manufactured to high-quality standards. For specific warranty details, including coverage period and terms, please refer to the warranty card included with your purchase or visit the official Broonel website. Keep your proof of purchase for warranty claims.

### 7.2 Customer Support

If you encounter any issues or have questions regarding your Broonel Fine Point Digital Active Stylus Pen that are not covered in this manual, please contact Broonel customer support. You can typically find contact information on the product packaging, the official Broonel website, or through your retailer.

**Online Support:** [www.broonel.com/support](http://www.broonel.com/support)

