

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SteamOne](#) /

› [SteamOne Portable Garment Steamer User Manual](#)

## SteamOne EUNS150B

# SteamOne Portable Garment Steamer User Manual

Model: EUNS150B

Brand: SteamOne

## 1. INTRODUCTION

---

Thank you for purchasing the SteamOne Portable Garment Steamer. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your device. Please read it thoroughly before first use and keep it for future reference.

## 2. SAFETY INSTRUCTIONS

---

- Always unplug the steamer from the power outlet when not in use, before filling or emptying the water tank, and before cleaning.
- Do not immerse the steamer, power cord, or plug in water or other liquids.
- Keep the steamer out of reach of children and pets.
- Use only distilled or demineralized water to prevent mineral buildup.
- Do not direct steam at people, animals, or electrical appliances. Steam is hot and can cause burns.
- Ensure the power cord is not damaged and avoid kinking or stretching it.
- Do not operate the steamer if it has been dropped, damaged, or is leaking. Contact customer support.
- Always place the steamer on a stable, heat-resistant surface.

## 3. PRODUCT OVERVIEW

---

Familiarize yourself with the components of your SteamOne Portable Garment Steamer.



Figure 3.1: SteamOne Portable Garment Steamer, showing the main body, steam head, and transparent water tank.

# Caractéristiques techniques

La vapeur SteamOne élimine 99,99% des virus, germes et bactéries\*.  
(\*Testés par des laboratoires indépendants.)



Figure 3.2: Diagram highlighting key technical features: ON/OFF LED button, 2 power modes (Max/Eco), steam-on-demand trigger, stainless steel soleplate, 150ml removable water tank, suction cup hook, bottle connector, and transport pouch.

## Included Accessories:

- Fabric brush
- Suction cup hook
- Transport pouch
- Bottle connector

## INCLUS

CROCHET VENTOUSE



CONNECTEUR  
BOUTEILLE



POCHETTE  
DE TRANSPORT



Figure 3.3: The steamer shown with its included accessories: a suction cup hook, a bottle connector, and a transport pouch.

## 4. SETUP

---

1. **Unpack:** Carefully remove all components from the packaging.
2. **Fill Water Tank:**
  - Remove the removable water tank from the steamer.
  - Open the tank cap and fill with distilled or demineralized water. Do not exceed the MAX fill line. The tank capacity is 150ml.
  - Securely close the tank cap and reattach the tank to the steamer until it clicks into place.
3. **Connect Power:** Plug the power cord into a suitable electrical outlet (230 Volts).

## 5. OPERATING INSTRUCTIONS

---

## **5.1 Powering On and Heating**

1. After filling the water tank and plugging in the device, press the ON/OFF button. The LED indicator will illuminate.
2. The steamer will begin to heat up. It is ready for use in approximately 30 seconds.

## **5.2 Steaming Garments**

1. Hang the garment on a hanger. For best results, use the included suction cup hook to secure the hanger to a door or wall.
2. Hold the steamer upright, ensuring the steam head is facing away from you.
3. Press and hold the steam trigger to release steam. The steamer offers two power levels; adjust as needed for different fabrics.
4. Move the steam head slowly over the fabric, from top to bottom. For stubborn wrinkles, gently press the steam head against the fabric.
5. The steamer has an autonomy of approximately 8 minutes with a full 150ml tank. An indicator will signal when the tank is empty.
6. The patented Soft Start anti-drip system prevents water drips and stains on your garments.



Figure 5.1: A visual comparison showing a wrinkled shirt before steaming and the same shirt after being steamed, demonstrating wrinkle removal.

### 5.3 Fabric Compatibility

The SteamOne steamer is suitable for a wide range of fabrics, including but not limited to:

- Jean
- Linen
- Sequin
- Cotton
- Muslin
- Tulle
- Flocked fabrics
- Lace
- Wool

- Silk



Figure 5.2: A circular diagram illustrating various fabric types that can be safely steamed with the device, including denim, linen, silk, wool, lace, flocked, tulle, muslin, cotton, and sequin.

## 5.4 Other Applications

Beyond garments, the steamer can be used to refresh and sanitize various household items:

- Tablecloths
- Curtains
- Towels
- Carpets
- Covers
- Dishcloths
- Plush toys
- Bedding

- Cushions
- Sofas



Figure 5.3: A circular diagram showing various household items that can be steamed, such as tablecloths, curtains, towels, carpets, covers, dishcloths, plush toys, bedding, cushions, and sofas.

## 6. MAINTENANCE

### 6.1 Cleaning

- Always unplug the steamer and allow it to cool completely before cleaning.
- Wipe the exterior of the steamer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Empty any remaining water from the tank after each use to prevent mineral buildup.

### 6.2 Descaling

Regular descaling is recommended, especially if using tap water (though distilled water is preferred). Frequency depends on water hardness and usage.

1. Mix a solution of equal parts white vinegar and water.
2. Fill the water tank with this solution.
3. Plug in the steamer and allow it to heat up.
4. Run the steamer until the tank is empty.
5. Repeat the process with clean distilled water to rinse out any vinegar residue.

### 6.3 Storage

When not in use, store the steamer in a cool, dry place. Ensure the water tank is empty before storage. The included transport pouch can be used for convenient storage and travel.



Figure 6.1: The compact SteamOne steamer being placed into a travel luggage, demonstrating its portability and ease of storage.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No steam or low steam output.	Water tank empty; Steamer not heated sufficiently; Mineral buildup; Tank not properly seated.	Refill water tank; Wait 30 seconds for heating; Perform descaling; Ensure tank is securely attached.
Water leaking from steam head.	Overfilled water tank; Steamer not fully heated; Mineral buildup.	Do not overfill tank; Wait for full heat-up; Perform descaling. The anti-drip system should minimize this.
Steamer not turning on.	Not plugged in; Power outlet issue; Device malfunction.	Check power connection; Try a different outlet; Contact customer support if issue persists.
Automatic shut-off activates too soon.	Water tank empty.	Refill water tank.

## 8. SPECIFICATIONS

Feature	Detail
Model Number	EUNS150B (NS150B)
Power	2000 Watts
Voltage	230 Volts
Water Tank Capacity	150 Milliliters
Steam Output	30g/min
Heat-up Time	30 seconds
Autonomy	Approx. 8 minutes (with 150ml tank)
Dimensions (L x W x H)	1.3 x 20.2 x 22.52 cm (13L x 202W x 225H mm)
Weight	1.41 Kilograms
Material	Stainless Steel (soleplate)
Color	Black



Figure 8.1: The SteamOne steamer with its approximate dimensions indicated: 150.9 mm in length and 225.16 mm in height.



Figure 8.2: Visual representation of key performance metrics: 2000W power, 30g/min steam output, 30 seconds heat-up time, and 8 minutes autonomy.

## 9. WARRANTY AND SUPPORT

---

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official SteamOne website. SteamOne is committed to providing excellent customer service.

The product meets current French safety standards.