

## Prixton Picasso

# Prixton Picasso Portable Projector User Manual

## INTRODUCTION

This manual provides detailed instructions for the safe and efficient operation of your Prixton Picasso Portable Projector. Please read this manual thoroughly before using the device and retain it for future reference.

## WHAT'S IN THE BOX

Upon unpacking, please ensure all the following items are present:

- Prixton Picasso Portable Projector
- Remote Control
- HDMI Cable
- USB Cable
- (Optional: 100" Projection Screen, if included in your package)



Image: PxiXton Picasso portable projector with a projection screen.

## SAFETY INFORMATION

- Do not look directly into the projector lens when the lamp is on.
- Ensure proper ventilation to prevent overheating.
- Keep the device away from water or other liquids.
- Use only the provided power adapter.
- Do not attempt to disassemble or repair the projector yourself. Contact qualified service personnel.

## PRODUCT OVERVIEW

The PxiXton Picasso is a portable Full HD projector designed for versatile use. It features a high-quality LED lamp and multiple connectivity options.

### Key Features:

- Full HD 1920 x 1080 native resolution.
- 9000 lumens brightness (260 ANSI lumens).
- 3000:1 contrast ratio.
- LED lamp life of over 50,000 hours.
- Projection distance: 1 to 7 meters.

- Projection size: 30" to 210".
- Wireless connectivity for Android and iOS devices.
- Multiple input ports: 2x HDMI, USB 2.0, TF card, Jack, AV IN, DC IN.



Image: PRIXTON Picasso projector shown with its remote control.



Image: Top view of the projector, highlighting the lens and control buttons.

## SETUP

### 1. Placement

Place the projector on a stable, flat surface. Ensure there is adequate space around the projector for ventilation. The optimal projection distance is between 1 and 7 meters, allowing for a screen size from 30 to 210 inches.



Image: Visual guide for projection distance and screen size.

## 2. Power Connection

Connect the power adapter to the DC IN port on the projector and then plug it into a power outlet.

## 3. Initial Power On

Press the power button on the projector or the remote control to turn on the device. The indicator light will illuminate.

# 9.000 LUMENS



Image: Projector displaying its brightness specification.



Image: Projector powered on and projecting light.

## 4. Focus and Keystone Adjustment

Adjust the focus ring on the projector lens until the image is clear. Use the keystone correction dial (if available) to correct any trapezoidal distortion of the image.



Image: Projector emphasizing Full HD compatibility, relevant for image clarity.

## OPERATING INSTRUCTIONS

### 1. Input Source Selection

Use the "Source" button on the remote control or the projector to select your desired input: HDMI 1, HDMI 2, USB, TF Card, or AV.

### 2. Connecting Devices

- **HDMI:** Connect your laptop, gaming console, or other HDMI-enabled devices using an HDMI cable.
- **USB/TF Card:** Insert a USB drive or TF card into the respective port to play media files directly.
- **AV:** Use the AV input for older devices with composite video output.

### 3. Wireless Connection (Screen Mirroring)

The projector supports wireless screen mirroring for both Android and iOS devices.

1. Select the "Screen Mirroring" or "Wireless Display" option from the projector's main menu.
2. For iOS devices, enable "Screen Mirroring" or "AirPlay" on your device and select the projector from the list.
3. For Android devices, enable "Wireless Display," "Smart View," or "Cast" on your device and select the projector.
4. Ensure both the projector and your mobile device are connected to the same Wi-Fi network for

optimal performance.




Image: Projector connected wirelessly to a smartphone.



Image: Wireless connectivity icon and smartphone mirroring.

#### 4. Audio Output

The projector has built-in speakers. You can also connect external speakers or headphones via the 3.5mm audio jack for enhanced sound.

## MAINTENANCE

- **Cleaning the Lens:** Use a soft, lint-free cloth specifically designed for optical lenses to gently wipe the projector lens. Avoid using abrasive cleaners.
- **Cleaning the Casing:** Wipe the projector's exterior with a soft, dry cloth. Do not use liquid or aerosol cleaners.
- **Ventilation:** Regularly check that the ventilation openings are not blocked by dust or debris to ensure proper airflow and prevent overheating.
- **Storage:** When not in use for extended periods, store the projector in a cool, dry place, protected from dust.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
No image displayed	Power not connected; incorrect input source; cable not connected properly.	Check power connection; select correct input source; ensure HDMI/USB/AV cables are securely connected.
Image is blurry	Focus not adjusted; projector too close/far from screen.	Adjust the focus ring on the lens. Adjust projection distance.
Image is distorted (trapezoid shape)	Projector not perpendicular to the screen.	Adjust keystone correction dial. Reposition the projector.
No sound	Volume too low; audio cable not connected; source device muted.	Increase projector volume; check audio cable connections; unmute source device.
Cannot connect to Wi-Fi / Screen Mirroring issues	Incorrect Wi-Fi password; devices not on the same network; device compatibility issues.	Verify Wi-Fi password; ensure both devices are on the same 2.4GHz Wi-Fi network; restart both devices.
Spot on the lens / projected image	Dust or debris on the lens or inside the projector.	Gently clean the lens with a soft, lint-free cloth. If the spot is internal, contact customer support.

## SPECIFICATIONS

Feature	Detail
Brand	Prixton
Model Name	Picasso
Recommended Use	Home cinema
Special Feature	Portable, Wireless Connection
Connectivity Technology	HDMI, USB
Display Resolution	1920 x 1080 (Full HD)
Maximum Display Resolution	1920 x 1080

Feature	Detail
Display Type	LCD
Form Factor	Portable
Mounting Type	Floor Mount
Brightness	9000 Lumens (260 ANSI Lumens)
Wattage	85 Watts
Control Device Type	Remote Control
Compatible Devices	Laptop, Smartphone
Contrast Ratio	3000:1
Maximum Projection Distance	7 Meters
Light Source Life	50,000 Hours
Maximum Image Size	210 Inches
Minimum Projection Distance	1 Meter
Minimum Image Size	30 Inches
Video Encoding	H.264
Country of Origin	China

## WARRANTY AND SUPPORT

Your Pxihton Picasso Portable Projector is covered by a standard manufacturer's warranty. Please refer to the specific warranty terms provided at the time of purchase for details on coverage duration and conditions.

For technical support, troubleshooting assistance, or warranty claims, please contact Pxihton customer service. Contact information can typically be found on the official Pxihton website or on your purchase documentation.

**Return Policy:** This product is eligible for return or replacement within 30 days of purchase, subject to the retailer's return policy.