

Manuals.plus /

- › Greater Goods /
- › Greater Goods 0.1g Precision Coffee Scale with Timer User Manual

## Greater Goods 0460

# Greater Goods 0.1g Precision Coffee Scale with Timer

Model: 0460

### INTRODUCTION

Thank you for choosing the Greater Goods 0.1g Precision Coffee Scale with Timer. This digital scale is designed to provide accurate measurements for various brewing methods, including pour-over, espresso, and French press, with a weight capacity of up to 3 kg. Its precision and integrated timer make it an essential tool for achieving consistent and delicious coffee.

This manual provides detailed instructions for setting up, operating, and maintaining your coffee scale. Please read it thoroughly before first use to ensure optimal performance and longevity of your device.

### PRODUCT OVERVIEW

The Greater Goods Coffee Scale features a sleek design with an intuitive interface, making your brewing process seamless. Key components include a bright LCD display, responsive touch buttons, and a removable, dishwasher-safe silicone mat for easy cleaning and spill protection.



Figure 1: Greater Goods 0.1g Precision Coffee Scale. This image shows the scale from a top-down angle with a small white bowl filled with coffee beans placed on its weighing platform. The digital display shows '0:35 min sec' on the left and '50.2 g' on the right.

## Smart Design

A bright LCD display & sleek interface for flawless brewing.



Figure 2: Smart Design and Button Layout. This image provides a close-up view of the scale's display and control panel, highlighting the functions of each button: 'Units' (U Mode), 'Start/Pause' (Play/Pause/Reset), 'Timer', 'Color LCD', 'Tare' (T), and 'On/Off' (Power button).

### Key Features:

- **High Precision:** Measures with 0.1g accuracy for precise brewing.
- **Integrated Timer:** Features both count-up and count-down timer functions.
- **Multiple Units:** Easily switch between grams (g), ounces (oz), fluid ounces (fl.oz), pounds (lb), and milliliters (ml).
- **Tare Function:** Zero out the weight of containers or additional ingredients.
- **Durable Design:** Heat-resistant, waterproof, and features a removable, dishwasher-safe silicone cover.
- **Energy Saving:** Auto-timer off function conserves battery life.

### SETUP

1. **Unpack the Scale:** Carefully remove the scale and all packaging materials from the box.
2. **Install Batteries:** The scale requires 3 AAA batteries, which are included. Locate the battery

compartment on the underside of the scale, open the cover, insert the batteries according to the polarity indicators (+/-), and close the cover securely.

3. **Placement:** Place the scale on a hard, flat, and stable surface to ensure accurate readings. Avoid placing it on soft or uneven surfaces, or near sources of vibration or extreme temperature changes.
4. **Initial Power On:** Press the **Power** button ( ) to turn on the scale. The display will light up.

## OPERATING INSTRUCTIONS

### Power On/Off

- To turn the scale **ON**, press the **Power** button ( ) located on the right side of the display.
- To turn the scale **OFF**, press and hold the **Power** button ( ) for a few seconds until the display turns off. The scale also features an auto-off function to save battery life if inactive for a period.

### Unit Conversion

- To change the unit of measurement, press the **Units** button (**U MODE**) located on the left side of the display.
- Each press will cycle through the available units: grams (g), ounces (oz), fluid ounces (fl.oz), pounds (lb), and milliliters (ml). Select the desired unit for your measurement.

### Tare Function

The Tare function allows you to zero out the weight of a container or any item already on the scale, so you can measure additional ingredients accurately.

1. Place the empty container (e.g., coffee mug, pour-over dripper) on the center of the weighing platform. The display will show its weight.
2. Press the **Tare** button (**T**) located on the right side of the display. The display will reset to "0.0".
3. You can now add your ingredients (e.g., coffee grounds, water) to the container, and the scale will display only the weight of the added items.



## Accident-Proof

Protected by a spill-detering groove  
& removable, dishwasher-safe cover.

*Figure 3: Zero Out, Brew On. This image shows a two-panel comparison of the tare function. The left panel shows a glass coffee carafe on the scale with a weight reading. The right panel shows the same carafe after the tare button has been pressed, with the display showing '0.0'.*

### Timer Function

The integrated timer is essential for precise coffee brewing, allowing you to monitor extraction times.

- **Start/Pause Timer:** Press the **Start/Pause** button ( ) to start the timer. Press it again to pause the timer.
- **Reset Timer:** To reset the timer to zero, press and hold the **Reset** button ( ) for a few seconds.
- The timer can count both up and down, adapting to various brewing methods.

# Count Up or Down

The versatile timer adapts to any brewing method.



Count **UP** to the perfect pour-over.



Count **DOWN** for a flawless French press.

Figure 4: Count Up or Down Timer. This image displays two scales side-by-side. The left scale shows a pour-over setup with the timer counting up (0:03 min sec). The right scale shows a French press setup with the timer counting down (3:48 min sec).

## MAINTENANCE & CARE

- **Cleaning:** The silicone mat on the weighing platform is removable and dishwasher-safe for easy cleaning. For the main body of the scale, wipe with a soft, damp cloth. Do not immerse the scale in water or use abrasive cleaners.
- **Spill Protection:** The grooved surface of the silicone mat helps prevent spills from reaching the scale's internal components. In case of spills, remove the mat and clean immediately.
- **Storage:** Store the scale in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** If the display shows a low battery indicator, replace all 3 AAA batteries promptly to ensure accurate readings.

## Precision in Every Cup

Measure in 6 units with 0.1g accuracy, up to 6.6 lb.



Figure 5: Accident-Proof Design. This image shows a hand lifting the removable, black silicone cover from the top of the coffee scale, demonstrating its easy removal for cleaning.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Scale does not turn on	Dead or incorrectly installed batteries.	Check battery polarity. Replace with new AAA batteries.
Inaccurate readings	Scale not on a flat, stable surface; overload; external vibrations; dirty sensors.	Ensure scale is on a hard, level surface. Do not exceed 3kg. Avoid vibrations. Clean the scale thoroughly.
Display shows "Err" or "OL"	Overload.	Remove item immediately. Do not exceed the maximum weight capacity of 3kg.
Timer not working	Incorrect button press.	Ensure you are pressing the correct Start/Pause and Reset buttons as indicated in the Operating Instructions.

## SPECIFICATIONS

- **Model Number:** 0460
- **Weight Limit:** 3 Kilograms (6.6 lbs)
- **Readout Accuracy:** 0.1 gram
- **Display Type:** LCD
- **Material:** Acrylonitrile Butadiene Styrene, Silicone
- **Item Weight:** 12.3 Ounces
- **Product Dimensions:** 7.63 x 5.2 x 1.1 inches
- **Batteries:** 3 AAA batteries (included)
- **Special Features:** Auto Shut Off, Low Battery Warning, Non-Slip Platform, Tare Function, Timer

## WARRANTY & SUPPORT

Greater Goods stands behind the quality of its products. This coffee scale comes with **5-year warranty**.

For any questions, concerns, or assistance, please contact our St. Louis-based support team. We offer lifetime assistance to ensure your complete satisfaction.

Please visit the official Greater Goods website for contact information and further support resources.