



Manuals.plus /

› **Globe Electric** /

› Globe Electric 60024 3-Light Plug-in Track Lighting Instruction Manual

## Globe Electric 60024

# Globe Electric 60024 3-Light Plug-in Track Lighting Instruction Manual

Model: 60024 | Brand: Globe Electric

## INTRODUCTION

---

This manual provides instructions for the safe installation, operation, and maintenance of your Globe Electric 60024 3-Light Plug-in Track Lighting fixture. Please read thoroughly before use and retain for future reference.

## SAFETY INFORMATION

---

- Ensure power is off at the main circuit breaker before installation, maintenance, or bulb replacement.
- Use only GU10 base bulbs, with a maximum wattage of 50W per light head.
- This fixture is designed for indoor use only. Do not expose to moisture or outdoor elements.
- Do not modify the fixture or its components. Any modifications may void the warranty and create a safety hazard.
- Keep flammable materials away from the light bulbs when in operation.
- If you are unsure about any part of the installation, consult a qualified electrician.

## PACKAGE CONTENTS

---

- 1 x 3-Light Plug-in Track Bar
- 1 x Mounting Hardware Kit (screws, anchors, mounting plate)
- 1 x Instruction Sheet

*Note: GU10 base bulbs are sold separately and are not included with this fixture.*



Image description: A top-down view of the Globe Electric 60024 track lighting components laid out, including the white track bar with three light heads, the coiled power cord with an in-line switch, mounting hardware (screws, anchors, mounting plate), and the instruction manual.

## SETUP AND INSTALLATION

---

### Step 1: Prepare for Installation

Unpack all components and ensure all parts are present. Turn off power at the main circuit breaker before beginning installation to prevent electrical shock.

### Step 2: Mount the Fixture

The fixture can be mounted on a wall or ceiling. Use the provided mounting hardware (screws and anchors) to secure the metal mounting plate to your desired surface. Ensure the mounting surface can support the weight of the fixture. Once the mounting plate is secure, attach the track bar to the plate using the designated screws.



Image description: A diagram illustrating the wall mounting process for the track light, showing the placement of screws and anchors to secure the mounting plate to the wall.



Image description: The white track lighting fixture mounted on a white wall, with the power cord extending downwards.



Image description: The white track lighting fixture mounted on a white ceiling, with the power cord extending from one end.

### **Step 3: Install GU10 Bulbs**

This fixture requires three GU10/Bi-Pin Base MR16 bulbs (50W max each), which are sold separately. To install each bulb, align the two pins on the bulb with the two corresponding slots in the socket. Gently push the bulb into the socket and twist clockwise until it is securely seated. Do not overtighten.



Image description: A close-up view of one of the track light heads with a GU10 bulb correctly installed, showing the bulb's face.

#### **Step 4: Adjust Light Heads**

The three light heads are adjustable. You can pivot and rotate each head to direct light as needed for task, accent, or ambient lighting in your space.



Image description: A diagram highlighting the adjustable nature of the track light heads, showing arrows indicating their range of motion.

## OPERATING INSTRUCTIONS

---

Once the fixture is securely mounted and bulbs are installed, plug the 15-foot power cord into a standard 120V wall outlet. Use the in-line rocker switch, located on the power cord, to turn the light fixture ON or OFF.

## MAINTENANCE

---

### Cleaning

Always disconnect power to the fixture before cleaning. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.

### Bulb Replacement

Ensure the fixture is unplugged and bulbs have cooled completely before attempting to replace them. Follow the bulb installation steps outlined in the "Setup and Installation" section to replace old bulbs with new GU10 bulbs (max 50W).

## TROUBLESHOOTING

---

### Light does not turn on:

- Check if the fixture is properly plugged into a working 120V outlet.
- Ensure the in-line switch on the cord is in the "ON" position.
- Verify that the GU10 bulbs are correctly installed and not burnt out. Replace if necessary.
- Check the circuit breaker for the outlet to ensure power is supplied.

### Flickering lights:

- Ensure bulbs are securely seated in their sockets. Remove and re-install if necessary.
- Confirm that the bulbs used are compatible GU10 base bulbs and do not exceed the maximum 50W rating.
- If using LED bulbs, ensure they are of good quality and compatible with the fixture's electrical system.

## PRODUCT SHOWCASE

---

See the Globe Electric 60024 3-Light Plug-in Track Lighting in various settings:

Your browser does not support the video tag.

Video description: A demonstration of the track lighting fixture, highlighting its modern design and adjustable heads for various lighting needs.

Your browser does not support the video tag.

Video description: A review showcasing the track lights installed in an office setting, demonstrating their effectiveness in providing targeted illumination.

## SPECIFICATIONS

---

Feature	Detail
Brand	Globe Electric
Model Number	60024
Color	Matte White
Material	Metal
Power Source	Plug-In
Number of Light Sources	3
Bulb Base	GU10
Max Wattage per Bulb	50 watts
Voltage	120 Volts
Cord Length	15 feet
Switch Type	In-Line Rocker Switch
Indoor/Outdoor Usage	Indoor
Dimensions (L x W x H)	22.25"L x 2.38"W x 6"H
Item Weight	2.75 Pounds

## WARRANTY AND SUPPORT

---

This product comes with a limited warranty. For specific warranty details, technical support, or to view other Globe Electric products, please contact Globe Electric customer service or visit the official Globe Electric store.

Official Globe Electric Store: [Visit Store](#)

