

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Beastron](#) /
- › [Beastron Upgraded Remote Controlled Outlet User Manual](#)

Beastron 850016082398

Beastron Upgraded Remote Controlled Outlet User Manual

Model: 850016082398

1. INTRODUCTION

Thank you for purchasing the Beastron Upgraded Remote Controlled Outlet. This device allows you to wirelessly control your appliances and lights with ease, enhancing convenience and energy efficiency in your home or office. Please read this manual thoroughly before use to ensure proper installation and operation.



Image 1.1: The Beastron remote controlled outlet and its accompanying remote control unit.

2. PRODUCT FEATURES

- **Wireless Control:** Remotely turn on/off appliances and lights from up to 100 feet away.
- **Expandable System:** Learning functions allow pairing multiple outlets with one remote or multiple remotes with one outlet.
- **Strong RF Signal:** Operates through doors and walls without interference.
- **Energy Saving:** Helps eliminate standby power consumption, reducing electricity bills.
- **Power Outage Memory:** Outlets remain off after a power outage to conserve energy.
- **Versatile Use:** Suitable for various electronic devices including lights, air conditioners, heaters, audio systems, and holiday decorations.



Image 2.1: Visual representation of key features including 100 feet range, plug and play, energy conservation, convenience, and smart home integration.

3. PACKAGE CONTENTS

- 1 x Beastron Remote Controlled Outlet
- 1 x Remote Control
- 1 x Lithium Polymer Battery (pre-installed in remote)
- 1 x User Manual (this document)

4. SETUP AND PAIRING

4.1 Initial Setup

1. Unpack the remote controlled outlet and the remote control from the packaging.

2. Ensure the battery is correctly installed in the remote control. The battery is typically pre-installed.
3. Plug the Beastron Remote Controlled Outlet into a standard wall outlet. The indicator light on the outlet may flash briefly.

4.2 Pairing the Remote Control with the Outlet

The outlet and remote are typically pre-paired from the factory. If they are not responding or if you wish to pair additional remotes/outlets, follow these steps:

1. Plug the Beastron Remote Controlled Outlet into a wall socket.
2. Locate the pairing button on the outlet. This is usually the red button on the front.
3. Press and hold the pairing button on the outlet until its indicator light begins to flash. This indicates it is in pairing mode.
4. While the outlet's light is flashing, press any ON or OFF button on the remote control.
5. The outlet's indicator light will stop flashing and remain solid for a moment, then turn off, confirming successful pairing.
6. Test the connection by pressing the ON/OFF buttons on the remote.



Pair in Seconds

Hold the pairing button until it flashes.
Press any remote button within range to complete pairing.

Image 4.1: Illustration of the pairing button on the outlet and the remote control, with instructions to hold the button until it flashes and then press a remote button.

5. OPERATING INSTRUCTIONS


1. Plug the appliance or device you wish to control into the Beastron Remote Controlled Outlet.
2. Ensure the appliance's power switch is set to the ON position if it has one, so it can receive power from the outlet.
3. Use the "ON" button on the remote control to turn on the connected appliance.
4. Use the "OFF" button on the remote control to turn off the connected appliance.



Plug and Play

Turn on any device with the click of a button.

Image 5.1: The remote control being used to operate devices connected to the Beastron outlets in a home environment, demonstrating "Plug and Play" functionality.



100 Feet Range

Outlets communicate via RF signal.

Can be controlled through doors and walls without interfering with Wifi or cell phone frequencies

Image 5.2: Depiction of the 100-foot RF range, showing the remote controlling outlets through walls and across distances within a house.

Save time and effort



Christmas tree



Bedroom lights



Fan



Garden light

Make your life easier

Image 5.3: Examples of common applications for the remote controlled outlet, including holiday decorations, indoor lighting, fans, and outdoor lighting.

6. MAINTENANCE

- Keep the outlet and remote control clean by wiping with a dry, soft cloth.
- Do not expose the devices to excessive moisture, heat, or direct sunlight.
- If the remote control's range decreases or it becomes unresponsive, replace the Lithium Polymer battery.
- Ensure the outlet is unplugged from the wall before cleaning or performing any maintenance.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Outlet does not respond to remote.	<ul style="list-style-type: none"> ◦ Outlet not plugged in. ◦ Remote battery is low or dead. ◦ Outlet and remote are not paired. ◦ Appliance connected to outlet is off. 	<ul style="list-style-type: none"> ◦ Ensure outlet is securely plugged into a live wall socket. ◦ Replace the remote control battery. ◦ Follow the pairing instructions in Section 4.2. ◦ Ensure the appliance's power switch is in the ON position.
Reduced remote control range.	<ul style="list-style-type: none"> ◦ Low remote battery. ◦ Obstructions (thick walls, metal objects). ◦ Interference from other RF devices. 	<ul style="list-style-type: none"> ◦ Replace the remote control battery. ◦ Try moving the outlet or remote to a different location. ◦ Minimize other RF devices operating nearby.
Outlet indicator light not working.	<ul style="list-style-type: none"> ◦ No power to the outlet. ◦ Internal malfunction. 	<ul style="list-style-type: none"> ◦ Check the wall socket with another device. ◦ Contact customer support if power is confirmed.

8. SPECIFICATIONS

Attribute	Value
Model Number	850016082398
Product Dimensions	4 x 3.5 x 2.4 inches
Item Weight	5.29 ounces
Material	Copper
Total Power Outlets	1
Remote Battery Type	1 Lithium Polymer battery (included)
RF Range	Up to 100 feet (line of sight)
Color	White



Image 8.1: Detailed dimensions of the Beastron remote controlled outlet, showing its compact size.

9. WARRANTY AND SUPPORT

Beastron products are designed for reliability and performance. For specific warranty information, please refer to the product packaging or contact Beastron customer support directly. If you encounter any issues or have questions not covered in this manual, please reach out to the manufacturer for assistance.

For the most up-to-date support information, please visit the official Beastron website or contact their customer service department.



