



Manuals.plus /

- › Drfeify /
- › Drfeify Handlebar Adapter for 9 G30 Scooter Instruction Manual

Drfeify 9 G30 Handlebar Adapter

Drfeify Handlebar Adapter for 9 G30 Scooter Instruction Manual

Model: 9 G30 Handlebar Adapter

1. PRODUCT OVERVIEW

This Drfeify Handlebar Adapter is designed as a replacement part for the folding mechanism of the 9 G30 electric scooter. Fabricated from elongated aluminum, it offers good impact strength and wear resistance, ensuring durability and a precise fit. It directly replaces the original folding components, allowing for straightforward installation and restoration of the scooter's folding functionality.



Image 1.1: The Dfeify Handlebar Adapter shown in context on a 9 G30 electric scooter, highlighting its position as a replacement for the folding rod base.

2. PACKAGE CONTENTS

- 1 x Dfeify Handlebar Adapter Assembly

3. SPECIFICATIONS

Brand	Dfeify
Model Number	Dfeifydgqfc3ni6x1110
Material	Aluminum
Compatibility	9 G30 Electric Scooter
Dimensions (L x W x H)	Approximately 5.63 x 5.31 x 2.56 inches (143 x 135 x 65 mm)
Weight	Approximately 0.7 Kilograms



Image 3.1: Detailed dimensions of the handlebar adapter, showing its height and width.

4. SAFETY INFORMATION

Please read and understand all instructions before installation and use. Improper installation or use can lead to injury or damage to the scooter.

- Ensure the scooter is powered off and stable before beginning any installation or maintenance.
- Wear appropriate safety gear, such as gloves, during installation.

- Verify all screws and fasteners are securely tightened after installation to prevent loosening during operation.
- Regularly inspect the adapter for any signs of wear, damage, or loose components.
- If you are unsure about any step, seek professional assistance.

5. INSTALLATION (SETUP)

This section outlines the steps to replace the existing folding mechanism with the Drfeify Handlebar Adapter. Ensure you have the necessary tools (e.g., Allen wrenches) before starting.

1. **Prepare the Scooter:** Power off your 9 G30 electric scooter. Place it on a stable surface to prevent it from tipping over during installation.
2. **Remove Existing Folding Mechanism:** Carefully identify and loosen the screws securing the original folding rod base to the scooter's handlebar stem. Remove the old component.
3. **Position the New Adapter:** Align the Drfeify Handlebar Adapter with the mounting points on the scooter's handlebar stem. Ensure the orientation is correct for proper folding functionality.
4. **Secure the Adapter:** Insert the appropriate screws into the designated holes on the new adapter and tighten them securely. Do not overtighten, but ensure there is no wobble.
5. **Test Folding Functionality:** Once installed, carefully test the folding and unfolding mechanism to ensure it operates smoothly and locks securely in both positions.
6. **Final Inspection:** Double-check all screws for tightness and ensure the handlebar stem is firmly attached and stable.

For Ninebot 9 Max G30 electric

The folding parts of the original model are repaired and replaced, and can be used directly after installation.



Image 5.1: The handlebar adapter shown next to a scooter's folding mechanism, illustrating the replacement area.



Image 5.2: A detailed view of the adapter's internal components, which engage with the scooter's folding rod.

6. OPERATION

The Drfeify Handlebar Adapter functions as the primary folding mechanism for your 9 G30 scooter. To fold the scooter, engage the release lever or button on the adapter, allowing the handlebar stem to pivot downwards. To unfold, reverse the process, ensuring the adapter locks securely into place before riding. Always confirm the locking mechanism is fully engaged before operating the scooter.

7. MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your handlebar adapter.

- **Regular Inspection:** Periodically check the adapter for any signs of wear, cracks, or deformation, especially around the pivot points and screw connections.
- **Tighten Fasteners:** Over time, vibrations can cause screws to loosen. Regularly check and tighten all screws on the adapter to the appropriate torque.
- **Cleaning:** Keep the adapter clean from dirt, dust, and debris. Use a damp cloth to wipe it down. Avoid harsh chemicals that could damage the aluminum finish.
- **Lubrication (Optional):** If the folding mechanism feels stiff, a small amount of silicone-based lubricant can be applied to the pivot points, avoiding contact with brake components.

8. TROUBLESHOOTING

This section addresses common issues you might encounter with the handlebar adapter.

Problem	Possible Cause	Solution
Adapter feels loose or wobbly after installation.	Screws are not tightened sufficiently.	Ensure all mounting screws are securely tightened. Do not overtighten.
Difficulty folding or unfolding the scooter.	Mechanism is stiff or obstructed.	Check for any debris obstructing the mechanism. Apply a small amount of silicone lubricant to pivot points if necessary.
Unusual noises during folding/unfolding.	Lack of lubrication or minor misalignment.	Lubricate pivot points. Re-check installation for proper alignment. If noises persist, inspect for damage.

9. WARRANTY AND SUPPORT

This product is subject to a 30-day return policy for refund or replacement, as per the seller's terms. For specific warranty details or technical support, please refer to the retailer or contact Drfeify customer service through the platform where the product was purchased.

For further assistance, please visit the [Drfeify Store on Amazon](#).