

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Genesis](#) /
- › [Genesis Krypton 200 Gaming Mouse User Manual](#)

Genesis NMG-1713

Genesis Krypton 200 Gaming Mouse User Manual

Model: NMG-1713

1. INTRODUCTION

The Genesis Krypton 200 is a wired gaming mouse engineered for precision and comfort. It features a high-resolution optical sensor, customizable RGB lighting, and seven buttons, designed to enhance your gaming and computing experience.



Image 1.1: Angled top view of the Genesis Krypton 200 Gaming Mouse, showcasing its ergonomic design, scroll wheel, and side buttons.

2. PACKAGE CONTENTS

- 1x Genesis Krypton 200 Gaming Mouse
- 1x User Manual

3. PRODUCT FEATURES

- High-precision optical sensor with up to 6400 DPI
- 7 programmable buttons for versatile control
- Dynamic RGB backlighting for personalized aesthetics
- Ergonomic design for comfortable extended use
- Wired USB connectivity for reliable performance



Image 3.1: Angled top view of the Genesis Krypton 200 Gaming Mouse, highlighting its RGB lighting strip and Genesis logo.

4. SYSTEM REQUIREMENTS

- Operating System: Windows XP/Vista/7/8/10/11
- Available USB port

5. SETUP

1. **Connect the Mouse:** Plug the USB cable of the Genesis Krypton 200 mouse into an available USB port on your computer.
2. **Driver Installation:** The operating system will typically detect and install the necessary drivers automatically. No additional software installation is usually required for basic functionality.
3. **Ready for Use:** Once the drivers are installed, the mouse is ready for immediate use.



Image 5.1: Bottom view of the Genesis Krypton 200 Gaming Mouse, showing the optical sensor, model information, and regulatory markings.

6. OPERATING INSTRUCTIONS

6.1 Button Functions

The Genesis Krypton 200 features seven buttons, each with a default function:

- **Left Click:** Primary action button.
- **Right Click:** Secondary action button, typically opens context menus.

- **Scroll Wheel (Click):** Middle click button, often used for opening links in new tabs or specific application functions.
- **Scroll Wheel (Scroll):** Used for vertical scrolling through documents and web pages.
- **DPI Button:** Cycles through different DPI sensitivity levels.
- **Side Button 1 (Forward):** Navigates forward in web browsers or file explorers.
- **Side Button 2 (Back):** Navigates backward in web browsers or file explorers.



Image 6.1: Top-down view of the Genesis Krypton 200 Gaming Mouse, clearly showing the layout of its seven buttons, including the DPI button and side buttons.

6.2 DPI Adjustment

Press the dedicated DPI button, usually located behind the scroll wheel, to cycle through the available DPI

settings. The mouse's RGB lighting may change color or pattern to indicate the currently selected DPI level, allowing for quick sensitivity adjustments during gameplay or general use.

6.3 RGB Lighting

The Genesis Krypton 200 features integrated RGB backlighting. The lighting typically operates in pre-programmed cycles or modes. For advanced customization of lighting effects, colors, or patterns, please check the official Genesis website for any available software or drivers specific to this model.

7. MAINTENANCE AND CARE

- **Cleaning:** To clean the mouse, use a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, ensuring no liquid enters the mouse's internal components. Avoid using harsh chemicals, abrasive cleaners, or solvents.
- **Sensor Care:** Keep the optical sensor on the underside of the mouse clean and free from dust or debris to ensure accurate tracking.
- **Storage:** Store the mouse in a clean, dry environment when not in use to prevent damage from dust or moisture.
- **Cable Management:** Avoid sharp bends or excessive pulling on the USB cable to prevent internal wire damage.

8. TROUBLESHOOTING

- **Mouse not responding:**
 - Ensure the USB cable is securely connected to an active USB port on your computer.
 - Try connecting the mouse to a different USB port.
 - Restart your computer.
- **Cursor movement is erratic or imprecise:**
 - Ensure the mouse's optical sensor on the underside is clean and free of any dust, hair, or debris.
 - Use the mouse on a clean, uniform, non-reflective surface or a high-quality mouse pad. Avoid glass or highly reflective surfaces.
 - Adjust the DPI setting using the DPI button to see if a different sensitivity improves performance.
- **Scroll wheel not working correctly or not registering inputs:**
 - Check for any physical obstructions or debris around the scroll wheel mechanism.
 - If the issue persists, ensure your operating system's mouse settings are configured correctly.
 - Consider checking the Genesis support website for any specific software or firmware updates that might address scroll wheel performance.
- **RGB lighting not working or stuck:**
 - Verify the mouse is properly connected to your computer.
 - If specific software is required for lighting control, ensure it is installed and running.

9. TECHNICAL SPECIFICATIONS

Feature	Specification
Model Number	NMG-1713
Connectivity Technology	USB
Movement Detection Technology	Optical
DPI	Up to 6400 dpi
Number of Buttons	7
Special Feature	Ergonomic Design, RGB Lighting
Color	Black
Product Dimensions	26.1 x 20.75 x 4.25 inches
Item Weight	6.7 ounces

10. WARRANTY AND SUPPORT

This Genesis product is covered by a manufacturer's warranty. For detailed information regarding warranty terms, conditions, and duration, please refer to the warranty card or documentation included with your purchase. You may also visit the official Genesis website for the most up-to-date warranty policy.

For technical assistance, troubleshooting beyond this manual, or to inquire about replacement parts, please contact Genesis customer support through their official website or designated support channels. Please have your product model number (NMG-1713) and proof of purchase ready when seeking support.