

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Onikuma](#) /

› [Onikuma CW905 RGB Gaming Mouse User Manual](#)

Onikuma CW905

Onikuma CW905 RGB Gaming Mouse User Manual

Model: CW905

INTRODUCTION

This manual provides instructions for the setup, operation, and maintenance of your Onikuma CW905 RGB Gaming Mouse. This high-quality gaming mouse features 7 programmable buttons and a sensitivity of up to 6400 DPI, designed for an enhanced gaming experience on personal computers.

PACKAGE CONTENTS

- Onikuma CW905 RGB Gaming Mouse
- User Manual (this document)

PRODUCT OVERVIEW

The Onikuma CW905 Gaming Mouse is equipped with several features to optimize your gaming and computing experience.



Image: Onikuma CW905 RGB Gaming Mouse. This image displays the black gaming mouse from a top-down perspective, highlighting its ergonomic shape, scroll wheel, and the illuminated RGB elements.

Key Features:

- **7 Programmable Buttons:** Customize functions for various tasks and games.
- **6400 DPI Optical Sensor:** Adjustable sensitivity for precise control.
- **RGB Lighting:** Dynamic lighting effects for aesthetic appeal.
- **Ergonomic Design:** Comfortable for extended use, designed for right-hand orientation.
- **USB Connectivity:** Reliable wired connection.

SETUP INSTRUCTIONS

1. **Connect the Mouse:** Plug the USB connector of the Onikuma CW905 Gaming Mouse into an available USB port on your personal computer.
2. **Driver Installation:** The mouse is typically plug-and-play. Your operating system (e.g., Windows 10/11) should

automatically detect and install the necessary drivers. If prompted, follow the on-screen instructions.

3. **Software Installation (Optional):** For advanced customization of programmable buttons and RGB lighting, visit the official Onikuma website to download the dedicated software for the CW905 model. Install the software by following the provided instructions.

Note: While the product specifications mention Windows XP, the mouse is compatible with modern Windows operating systems (Windows 7, 8, 10, 11) for basic functionality. The customization software may require a newer OS version.

OPERATING INSTRUCTIONS

Basic Operation:

- **Left Click:** Primary action, selection.
- **Right Click:** Context menu, secondary action.
- **Scroll Wheel:** Scroll up/down documents and web pages. Click the scroll wheel for middle-click functionality (often used for opening links in new tabs).

DPI Adjustment:

The mouse features a dedicated DPI button (usually located behind the scroll wheel) to cycle through different sensitivity levels. Press this button to instantly change the mouse's tracking speed. The RGB lighting may change color to indicate the current DPI setting.

Programmable Buttons:

The Onikuma CW905 includes 7 programmable buttons. These buttons can be assigned specific functions, macros, or key combinations using the dedicated software. Refer to the "Customization" section for more details.

CUSTOMIZATION

To fully utilize the 7 programmable buttons and customize the RGB lighting effects, download and install the official Onikuma CW905 software from the manufacturer's website.

Button Programming:

1. Open the Onikuma CW905 customization software.
2. Select the button you wish to program from the graphical interface.
3. Choose a function from the available options (e.g., keyboard key, macro, multimedia control, DPI switch).
4. Save your settings to the mouse's onboard memory (if supported) or apply them.

RGB Lighting Control:

- Within the software, navigate to the lighting settings.
- Select from various lighting modes (e.g., static, breathing, rainbow wave).
- Adjust brightness, speed, and specific colors as desired.
- Apply the changes to see them reflected on your mouse.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the mouse. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid harsh chemicals.
- **Sensor Care:** Keep the optical sensor on the underside of the mouse clean and free from dust or debris to ensure accurate tracking.

- **Cable Management:** Avoid sharp bends or excessive pulling on the USB cable to prevent damage.
- **Storage:** When not in use for extended periods, store the mouse in a clean, dry environment.

TROUBLESHOOTING

Problem	Solution
Mouse is not responding.	<ul style="list-style-type: none"> • Ensure the USB cable is securely plugged into a working USB port. • Try plugging the mouse into a different USB port on your computer. • Restart your computer. • Check if the mouse works on another computer to rule out a computer-specific issue.
DPI or RGB settings are not changing.	<ul style="list-style-type: none"> • Ensure the customization software is installed and running. • Verify that changes are applied within the software. • Check for software updates or firmware updates for the mouse on the Onikuma website.
Mouse movement is erratic or inaccurate.	<ul style="list-style-type: none"> • Clean the optical sensor on the underside of the mouse. • Ensure you are using the mouse on a suitable surface (e.g., a mouse pad, not a reflective or transparent surface). • Adjust the DPI settings to a lower value if the cursor is too sensitive.

SPECIFICATIONS

Feature	Detail
Brand	Onikuma
Model Number	CW905-0B
Connectivity	Wired USB
DPI Sensitivity	Up to 6400 DPI
Buttons	7 Programmable Buttons (including Left, Right, Scroll Click)
Movement Detection	Optical
Hand Orientation	Right-hand
Recommended Use	Gaming
Compatible OS	Windows (XP and newer versions)
Color	Black
Item Weight	125 grams
Shipping Dimensions	16.2 x 9.3 x 4.6 cm

WARRANTY AND SUPPORT

For warranty information, technical support, or to download the latest drivers and software, please visit the official Onikuma website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty claims.

Note: The product may be eligible for extended warranty plans offered by third-party providers. Please refer to your purchase details for more information on such options.

