

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Vecupou](#) /

› [Vecupou Mini Projector Full HD 1080p Home Theater User Manual](#)

Vecupou Mini Projector

Vecupou Mini Projector User Manual

Model: Mini Projector

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Vecupou Mini Projector. Please read it thoroughly before use and retain it for future reference. This projector is designed for home entertainment, supporting Full HD 1080p resolution and offering multiple connectivity options.

Safety Information

- Do not look directly into the projector lens when the lamp is on.
- Ensure proper ventilation around the projector to prevent overheating.
- Avoid placing the projector in unstable locations or near water.
- Use only the power adapter supplied with the projector.
- Do not attempt to disassemble or repair the projector yourself. Contact qualified service personnel.

2. PACKAGE CONTENTS

Verify that all items are present in your package:

- Vecupou Mini Projector
- Power Adapter
- Remote Control
- HDMI Cable
- AV Cable
- User Manual
- Portable Projection Screen (may be included with some models)

3. PRODUCT FEATURES

- **Portable Design:** Compact and lightweight for easy transport and setup.
- **Full HD 1080p Support:** Supports resolutions up to 1920 x 1080 pixels for clear images.
- **Multi-Connection Options:** Compatible with TV Box, ChromeBook, PC, laptops, tablets, DVD Blu-ray players, SD cards, USB drives, game consoles, and smartphones.
- **Adjustable Projection Size:** Projects screen sizes from 32 to 176 inches (81.3 cm to 447 cm) with a projection distance of 1.5m to 5m.
- **Built-in Speaker:** Integrated audio for convenience.
- **Keystone Correction:** Vertical keystone adjustment for correcting distorted images.

4. PRODUCT OVERVIEW AND CONNECTIONS

Familiarize yourself with the projector's components and connection ports.



Image: Multi Device Connection Diagram. This image illustrates the various input and output ports available on the projector, including AV, USB, SD card slot, HDMI, and VGA ports, along with examples of devices that can be connected to each.

Port Descriptions:

- **HDMI Port:** Connects to devices like TV sticks, game consoles, laptops, and Blu-ray players.
- **USB Port:** Connects to USB flash drives for media playback.
- **SD Card Slot:** Inserts SD cards for media playback.
- **AV Port:** Connects to older devices using an AV cable.
- **VGA Port:** Connects to computers or laptops.
- **Audio Out (3.5mm Jack):** Connects to external speakers or headphones.

5. SETUP

5.1 Placement and Power

1. Place the projector on a stable, flat surface. Ensure there is adequate space around the projector for ventilation.
2. Connect the power adapter to the projector's power input and then to a power outlet.
3. Press the power button on the projector or remote control to turn it on.

5.2 Focus and Keystone Adjustment

Adjust the image clarity and shape using the focus and keystone rings on the projector.



Image: Focus and Keystone Adjustment. This image illustrates the location of the focus and keystone adjustment rings on the projector and demonstrates their effect on the projected image, allowing users to achieve a clear and rectangular display.

- **Focus Ring:** Rotate the focus ring until the image appears sharp and clear.
- **Keystone Ring:** Rotate the keystone ring to correct trapezoidal distortion, ensuring the image is rectangular.

6. CONNECTING DEVICES

6.1 HDMI Devices (TV Stick, Game Consoles, PC)

1. Connect the HDMI cable from your device (e.g., TV stick, game console, laptop) to the HDMI port on the projector.
2. Turn on both the projector and the connected device.
3. Press the 'Source' button on the projector or remote control and select 'HDMI' as the input source.



TV Stick & Box Connection

Image: TV Stick & Box Connection. This image demonstrates how to connect a TV stick or similar streaming device to the projector, displaying content on a large screen.

6.2 USB Devices (USB Drive, SD Card)

1. Insert your USB flash drive into the USB port or your SD card into the SD card slot.
2. Press the 'Source' button and select 'USB' or 'SD' as the input source.
3. Navigate through the files using the remote control and select the media you wish to play.

6.3 Smartphone/Tablet Connection

To connect a smartphone or tablet, an additional adapter (not included) is required.

Smartphone & Tablet Connection



Adapter not included in the package

Image: Smartphone & Tablet Connection. This image illustrates the use of external adapters, such as a Lightning to HDMI adapter for iOS devices or a Google Chromecast HDMI adapter, to connect smartphones and tablets to the projector. These adapters are not included with the projector.

- **For iOS Devices:** Use a Lightning to HDMI adapter. Connect the adapter to your iOS device, then connect an HDMI cable from the adapter to the projector's HDMI port.
- **For Android Devices:** Use a USB-C to HDMI adapter or a Google Chromecast HDMI adapter. Connect the adapter to your Android device, then connect an HDMI cable from the adapter to the projector's HDMI port.
- Select 'HDMI' as the input source on the projector.

6.4 External Audio Output

For enhanced sound, connect external speakers or a soundbar to the projector's 3.5mm audio out jack.

7. OPERATING THE PROJECTOR

7.1 Power On/Off

- **Power On:** Press the power button on the projector or remote control.

- **Power Off:** Press the power button again. The projector will go into standby mode. Disconnect from power when not in use for extended periods.

7.2 Source Selection

Use the 'Source' button on the remote control or projector to cycle through available input sources (HDMI, USB, SD, AV, VGA).

7.3 Menu Navigation

Use the arrow buttons and 'OK' button on the remote control to navigate the projector's on-screen menu for settings adjustments (e.g., picture mode, sound mode, aspect ratio).

8. MAINTENANCE

8.1 Cleaning the Lens

Use a soft, lint-free cloth or lens cleaning paper to gently wipe the projector lens. Avoid using abrasive cleaners or excessive force.

8.2 General Cleaning

Wipe the projector's exterior with a soft, dry cloth. Do not use liquid cleaners directly on the projector.

8.3 Storage

When not in use, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures. Use the original packaging or a protective case if available.

9. TROUBLESHOOTING

Problem	Possible Cause	Solution
No image displayed	Power not connected; Incorrect input source; Loose cable connection.	Check power cable; Select correct input source (HDMI, USB, etc.); Ensure cables are securely connected.
Image is blurry	Focus not adjusted; Projector too close/far from screen.	Adjust the focus ring; Adjust projection distance.
Image is trapezoidal	Keystone not adjusted; Projector not perpendicular to screen.	Adjust the keystone ring; Reposition the projector.
No sound	Volume too low; Muted; External speakers not connected or off.	Increase volume; Unmute; Check external speaker connection and power.
Remote control not working	Batteries low/dead; Obstruction between remote and projector.	Replace batteries; Remove any obstructions.

10. SPECIFICATIONS



Image: Projector Performance Comparison. This image highlights the performance metrics of the Vecupou Mini Projector, indicating 7500 Lumens brightness, Native 720P resolution, and a 5000:1 contrast ratio, compared to other projectors.

Feature	Specification
Brand	Vecupou
Product Type	Portable Projector
Color	Black
Native Display Resolution	1280 x 720 Pixels
Max Supported Resolution	1920 x 1080 Pixels (Full HD)
Display Type	LCD

Feature	Specification
Contrast Ratio	5000:1 (as per image)
Lamp Life	50,000 hours
Projection Size	32 - 176 inches (81.3 - 447 cm)
Projection Distance	1.5m - 5m
Aspect Ratio	4:3 / 16:9
Connectivity Technology	HDMI, USB
Total USB Ports	1
Compatible Devices	Smartphone, TV Stick, Game Consoles, PC, Laptops, Tablets, DVD Players, USB Drives, SD Cards
Special Features	Vertical Keystone Correction, Built-in Speaker, Lightweight
Product Dimensions	27.9L x 20.3W x 12.7H cm
Mounting Type	Table Mount

11. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact Vecupou customer service through their official website. Keep your proof of purchase for warranty claims.