

Manuals.plus /

› HOMCOM /

› HOMCOM Vespa Electric Motorcycle for Kids Instruction Manual

## HOMCOM 370-138WT

# Instruction Manual for HOMCOM Vespa Electric Motorcycle for Kids

Brand: HOMCOM

Model: 370-138WT

## INTRODUCTION

---

Thank you for purchasing the HOMCOM Vespa Electric Motorcycle for Kids. This officially licensed Vespa ride-on toy is designed for children aged 18-36 months, providing a fun and realistic driving experience. It features a 6V battery, working headlights, and a horn. Please read this manual carefully before assembly and use to ensure safe operation and proper maintenance.

## SAFETY INFORMATION

---

**Important:** This product is intended for children aged 18-36 months under direct adult supervision. Maximum weight capacity is 25kg.

- Always supervise children when operating the electric motorcycle.
- Ensure the child wears appropriate safety gear, such as a helmet, when riding.
- Do not use the product near stairs, steep slopes, swimming pools, or public roads.
- Only use on flat, dry surfaces. Avoid wet or uneven terrain.
- Regularly inspect the product for any damage or loose parts before each use.
- Keep hands, hair, and loose clothing away from moving parts.
- The charger and battery are not toys. Do not allow children to handle them.
- Only use the charger supplied with the product.
- Do not modify the electrical system.

*No specific warnings beyond general safety guidelines are applicable as per product information.*

## PACKAGE CONTENTS

---

Please check that all parts are present before assembly:

- Main Motorcycle Body

- Wheels (Front and Rear)
- Seat
- Handlebars
- Training Wheels (Removable)
- Charger
- Horn (integrated)
- Assembly Hardware (screws, washers, etc.)

## ASSEMBLY INSTRUCTIONS

---

Assembly is required for this product. Please follow these general steps. Refer to the included diagram for specific part identification.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Verify all components listed in the "Package Contents" section are present.
2. **Install Front Wheel:** Attach the front wheel to the motorcycle body using the provided axle and fasteners. Ensure it spins freely.
3. **Install Rear Wheels:** Attach the main rear wheel and the two removable training wheels. The training wheels provide additional stability for younger riders and can be removed as the child gains confidence.
4. **Attach Handlebars:** Secure the handlebars to the steering column. Ensure they are firmly attached and aligned correctly.
5. **Connect Battery:** Locate the battery compartment (usually under the seat). Connect the battery terminals according to the polarity markings (+ to +, - to -).
6. **Install Seat:** Place the seat onto the motorcycle body and secure it with the designated screws or clips.
7. **Final Check:** Before first use, ensure all screws are tightened, all connections are secure, and the wheels turn smoothly.

# REGALO PERFETTO PER I BAMBINI



Look  
accattivante



Materiale di  
Talta qualità



Facile  
da usare



Colore  
brillante

*Image: Stable structure with anti-fall device and removable side wheels for enhanced safety during assembly and use.*



Image: Detailed dimensions of the assembled electric motorcycle, including length, width, and height.

## OPERATING INSTRUCTIONS

Operating the HOMCOM Vespa Electric Motorcycle is simple and intuitive for young children.

- **Power On/Off:** Locate the power switch (if present, usually near the dashboard or foot pedal area). Turn it to the 'ON' position.
- **Driving:** To move forward, simply press the foot pedal located on the right side. Releasing the pedal will stop the motorcycle. The maximum speed is 3 km/h.
- **Lights:** The headlights will automatically illuminate when the acceleration pedal is pressed, adding to the realistic driving experience.
- **Horn:** Press the horn button on the handlebars to activate the horn sound.

- **Steering:** Use the handlebars to steer the motorcycle left or right.



*Image: Details of the easy-to-use controls: horn button on the handlebar, simple foot pedal for acceleration, and the ergonomically designed comfortable seat.*



*Image: A detailed view of the horn button conveniently located on the handlebar for easy access.*



*Image: A close-up of the functional front headlight and the official Vespa logo, enhancing the realistic design.*

## BATTERY CHARGING

---

The motorcycle is powered by a 6V, 4AH battery.

- **First Charge:** Charge the battery for 9-10 hours before the first use.
- **Subsequent Charges:** Charge for approximately 8 hours for a full charge.
- **Run Time:** A full charge provides approximately 45 minutes of continuous use, depending on usage conditions.
- **Charging Process:**
  - a. Ensure the motorcycle is turned off.
  - b. Locate the charging port (refer to the product diagram if unsure).
  - c. Plug the charger into the charging port, then plug the charger into a standard wall outlet.
  - d. The charger will typically have an indicator light to show charging status (e.g., red for charging, green for fully charged).

- e. Do not overcharge the battery. Disconnect the charger once charging is complete.

## MAINTENANCE

---

Regular maintenance will extend the life of your electric motorcycle.

- **Cleaning:** Wipe the motorcycle with a soft, damp cloth. Do not use abrasive cleaners or solvents. Do not hose down or immerse in water.
- **Storage:** Store the motorcycle in a dry, cool place away from direct sunlight and moisture. If storing for an extended period, charge the battery fully every 30 days to maintain its life.
- **Battery Care:** Do not allow the battery to completely discharge. Recharge it after each use. If the product will not be used for a long time, disconnect the battery.
- **Inspection:** Periodically check all screws, nuts, and bolts to ensure they are tight. Inspect wheels and tires for wear or damage.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Motorcycle does not move.	Battery is low or dead. Battery connection is loose. Power switch is off. Foot pedal is not fully pressed.	Charge the battery. Check and secure battery connections. Turn the power switch to 'ON'. Ensure the foot pedal is fully depressed.
Motorcycle moves slowly.	Battery is low. Overloaded (child too heavy). Operating on an incline or rough surface.	Recharge the battery. Ensure child's weight is within limits (max 25kg). Use on flat, smooth surfaces.
Lights or horn not working.	Battery is low. Loose wire connection.	Recharge the battery. Check connections (if accessible and safe).
Charging indicator light not working.	Charger not properly connected. Faulty charger or outlet.	Ensure charger is securely plugged into both motorcycle and wall outlet. Try a different outlet. If problem persists, contact customer support.

## SPECIFICATIONS

---

Feature	Detail
Model Number	370-138WT
Dimensions (L x W x H)	66.5 cm x 38 cm x 52 cm
Weight	4.7 kg
Recommended Age	18-36 months
Maximum Load Capacity	25 kg
Battery	6V, 4AH
First Charge Time	9-10 hours
Subsequent Charge Time	Approx. 8 hours
Continuous Use Time	Approx. 45 minutes (varies with use)
Maximum Speed	3 km/h
Material	Metal, Polypropylene (PP)
Color	White
Assembly Required	Yes

## WARRANTY AND SUPPORT

---

For any questions, concerns, or issues regarding your HOMCOM Vespa Electric Motorcycle, please contact the seller or manufacturer directly. Keep your purchase receipt for warranty purposes.

**Seller:** AOSOM

Please refer to the original purchase documentation for specific warranty terms and conditions.

