Cecotec Surface Precision 9350

Cecotec Surface Precision 9350 Digital Bathroom Scale User Manual

Model: 04602

1. INTRODUCTION

Thank you for choosing the Cecotec Surface Precision 9350 Digital Bathroom Scale. This manual provides essential information for the safe and efficient use of your new scale. Please read these instructions carefully before use and retain them for future reference.

The Surface Precision 9350 is a digital bathroom scale featuring a large 300 x 300 mm surface, an ultra-flat design, and a 6 mm tempered glass platform. It includes an invisible LED display for clear readings and a rechargeable lithium battery via USB, eliminating the need for disposable batteries. The scale offers a wide measurement range from 5 kg to 180 kg with 100 g increments and allows easy unit conversion between kilograms and pounds. Equipped with four high-precision sensors, it ensures stable and accurate measurements. Additional features include automatic disconnection, auto-on functionality, and indicators for overload and low battery.

Image: The Cecotec Surface Precision 9350 digital bathroom scale, showcasing its sleek design and included measuring tape.

2. SAFETY INSTRUCTIONS

- Always place the scale on a hard, flat, and stable surface. Uneven or soft surfaces (like carpet) can affect accuracy.

- The glass surface can be slippery when wet. Ensure the scale surface is dry before stepping on it to prevent accidents.

- Do not exceed the maximum weight capacity of 180 kg (400 lb).

- Avoid jumping on the scale or dropping heavy objects on it, as this may damage the glass platform or internal components.

- This scale is intended for personal use only and should not be used for commercial purposes or medical diagnosis.

- Keep the scale away from extreme temperatures, direct sunlight, and high humidity.

- Do not attempt to disassemble or repair the scale yourself. Contact qualified service personnel for assistance.

- Keep out of reach of children.

3. PRODUCT OVERVIEW

The Cecotec Surface Precision 9350 features a minimalist design with advanced functionality. Key components include:

- **Tempered Glass Platform:** Large, durable, and easy to clean weighing surface.
- **Invisible LED Display:** Provides clear weight readings when in use, discreetly hidden when off.
- **USB Charging Port:** Located on the side or back for convenient recharging of the internal lithium battery.
- **Unit Conversion Button:** Allows switching between kilograms (kg) and pounds (lb).
- **High-Precision Sensors:** Four sensors ensure accurate and consistent measurements.

Image: Top view of the Cecotec Surface Precision 9350 digital scale, displaying "0.0 kg" on its integrated LED screen.

4. SETUP

4.1 Initial Charging

Before first use, ensure the scale is fully charged. Connect the provided USB cable to the scale's charging port and to a standard USB power adapter (not included) or a computer USB port. The LED display may indicate charging status. A full charge typically takes a few hours.

Image: A close-up view of the USB charging port on the side of the Cecotec digital scale, with a white USB cable plugged in.

4.2 Placement

Place the scale on a hard, flat, and stable surface. Avoid carpets, rugs, or uneven flooring, as these can lead to inaccurate readings.

4.3 Unit Selection (kg/lb)

On the underside of the scale, locate the unit conversion button. Press this button to toggle between kilograms (kg) and pounds (lb) according to your preference. The selected unit will be displayed on the LED screen.

5. OPERATING INSTRUCTIONS

5.1 Taking a Measurement

1. Ensure the scale is placed on a firm, flat surface.

2. Gently step onto the center of the scale with bare feet. The scale will automatically turn on.

3. Stand still and wait for your weight to be displayed on the LED screen. The reading will flash a few times before stabilizing.

4. Once the reading is stable, you can step off the scale. The scale will automatically turn off after a few

seconds to conserve battery.

Image: A person's bare feet positioned on the Cecotec digital scale, with a weight measurement visible on the LED display.

Image: A person carefully stepping onto the Cecotec digital scale to initiate a weight measurement.

Image: A person standing on the Cecotec digital scale, demonstrating its use in an outdoor setting near a pool.

6. MAINTENANCE AND CARE

- **Cleaning:** Wipe the scale surface with a soft, damp cloth. Do not use abrasive cleaners or immerse the scale in water.
- **Storage:** Store the scale in a cool, dry place. Avoid storing it vertically for extended periods, as this may affect sensor calibration.
- **Battery:** Recharge the scale when the low battery indicator appears on the display. Regular charging helps maintain battery health.

7. TROUBLESHOOTING

| Problem	Possible Cause	Solution
"Lo" displayed	Low battery.	Recharge the scale using the USB cable.
"Err" displayed	Overload or unstable measurement.	Ensure weight does not exceed 180 kg. Step off and re-weigh, ensuring you stand still on a flat surface.

Problem	Possible Cause	Solution
Inaccurate readings	Scale on uneven/soft surface, not calibrated, or moved.	Place scale on a hard, flat surface. Step on briefly to turn on, then step off and wait for "0.0" to appear before re-weighing. This re-calibrates the scale.
Scale does not turn on	Battery is completely drained.	Charge the scale for at least 30 minutes before attempting to use it.

8. SPECIFICATIONS

Feature	Detail
Model Number	04602
Brand	Cecotec
Dimensions (L x W x H)	34.3 x 33.5 x 5.4 cm
Weight	1.8 Kilograms
Weight Limit	180 Kilograms (400 lb)
Measurement Increments	100 g (0.2 lb)
Material	Tempered Glass
Display Type	LED (Invisible)
Power Source	Rechargeable Lithium Battery (USB)
Special Features	Automatic Disconnection, Auto-on, Overweight Indicator, Low Battery Indicator

9. WARRANTY AND SUPPORT

Cecotec offers a commitment to product longevity, with spare parts availability for 10 years within the EU. For any issues not covered in the troubleshooting section, or for warranty claims, please contact Cecotec customer support. Refer to your purchase documentation for specific warranty terms and contact information.
Always ensure you have your model number (04602) and proof of purchase ready when contacting support.

Related Documents - **Surface Precision 9350**

[Cecotec Surface Precision 9400/9450 Full Healthy Digital Scale - User Manual](#)
Comprehensive user manual for the Cecotec Surface Precision 9400/9450 Full Healthy digital scale, covering setup, operation, body analysis features, maintenance, and warranty information.

[Cecotec Surface Precision 9500/9600 Smart Healthy Bathroom Scale User Manual](#)
Comprehensive guide for the Cecotec Surface Precision 9500 and 9600 Smart Healthy bathroom scales, covering setup, operation, mobile app integration, safety, maintenance, and troubleshooting.

[Cecotec Surface Precision EcoPower 10000 Healthy White/Black Bathroom Scale User Manual](#)
Comprehensive user manual for the Cecotec Surface Precision EcoPower 10000 Healthy bathroom scale. Learn about safety instructions, parts, operation, technical specifications, disposal, and warranty information for your body weight scale.

[Cecotec Cook Control 10100 EcoPower Compact Kitchen Scale - Instruction Manual](#)
Official instruction manual for the Cecotec Cook Control 10100 EcoPower Compact kitchen scale. Learn about its features, operation, cleaning, maintenance, technical specifications, and warranty.

[Cecotec Ready Warm 7000 Quartz Bath: User Manual & Technical Specifications](#)
Comprehensive user manual and technical specifications for the Cecotec Ready Warm 7000 Quartz Bath, a 1200W quartz heater. Includes safety instructions, operation guide, cleaning, maintenance, warranty information, and detailed technical data.

[Cecotec Bolero Hexa SM406000: Manual de Instrucciones y Seguridad](#)
Manual completo de instrucciones y seguridad para los hornos multifunción Cecotec Bolero Hexa SM406000 (Edge+, Glass Black, Glass White, Glass Grey). Incluye guía de uso, limpieza, resolución de problemas y especificaciones técnicas.