

manuals.plus /

- › [PPLEE](#) /
- › [PPLEE Extra Loud Vibrating Alarm Clock User Manual](#)

PPLEE CR1018I



PPLEE Extra Loud Vibrating Alarm Clock with Bed Shaker

Model: CR1018I

1. PRODUCT OVERVIEW

The PPLEE Extra Loud Vibrating Alarm Clock is designed to provide effective wake-up solutions for deep sleepers, individuals with hearing impairment, and the deaf. It features multiple wake-up modes, a large digital display, dual alarm settings, and convenient charging capabilities.



Image 1.1: The PPLEE Extra Loud Vibrating Alarm Clock with its bed shaker accessory.

Key Features:

- **Strong Bed Shaker & Loud Alarm Buzzer:** Offers three wake-up modes: loud buzzer, strong bed shaker, or a combination of both.
- **8.7" Large Mirror LED Display:** Provides clear time visibility and can also function as a makeup mirror.
- **Dual Alarms with Snooze Function:** Allows setting two independent alarms with a 9-minute snooze option.
- **Adjustable Brightness & Volume:** Features 8 levels of display brightness and 7 levels of alarm volume.
- **USB Charging Port:** Conveniently charge your mobile devices directly from the clock.
- **Battery Backup:** Maintains time and alarm settings during power outages (CR2032 battery included).
- **12/24H Mode & DST Function:** Supports both 12-hour and 24-hour time formats, along with Daylight Saving Time adjustment.

2. PACKAGE CONTENTS

Please check the box for the following items:

- 1 x PPLEE Mirror Alarm Clock
- 1 x Bed Shaker
- 1 x Power Plug with USB Cable
- 1 x Instruction Manual
- 1 x CR2032 Cell Coin Battery (pre-installed or separate)



Image 2.1: All components included in the product package.

3. SETUP GUIDE

3.1 Power Connection

1. Connect the USB cable to the alarm clock's power input port.
2. Plug the power adapter into a standard electrical outlet. The clock display will illuminate.
3. Ensure the CR2032 backup battery is installed in its compartment. This battery preserves time and alarm settings during power interruptions.



Image 3.1: Rear view of the alarm clock showing the AC power input and backup battery compartment.

3.2 Bed Shaker Placement

The bed shaker provides a strong vibration to assist in waking. For optimal effectiveness, place the bed shaker in one of the following locations:

- Under your pillow.
- Under your fitted sheet.
- Between your mattress and box spring.



Image 3.2: Recommended placements for the bed shaker to maximize vibration effectiveness.

4. OPERATING INSTRUCTIONS

4.1 Setting the Time

1. Press and hold the **TIME SET** button until the hour digits begin to flash.
2. Use the **HOUR** and **MINUTE** buttons to adjust the time.
3. Press **TIME SET** again to confirm and exit time setting mode.

4.2 Setting Alarms (Alarm 1 & Alarm 2)

The clock supports two independent alarms.

1. Press and hold the **ALARM 1** or **ALARM 2** button until the alarm time digits flash.
2. Use the **HOUR** and **MINUTE** buttons to set the desired alarm time.
3. Press **ALARM 1** or **ALARM 2** again to confirm the alarm time.
4. To activate or deactivate an alarm, short press the corresponding **ALARM 1** or **ALARM 2** button. An alarm icon will appear/disappear on the display.



Image 4.1: The dual alarm feature allows setting two separate wake-up times.

4.3 Snooze Function

When an alarm sounds, press the **SNOOZE** button to temporarily silence the alarm for 9 minutes. The alarm will sound again after the snooze period.

4.4 Turning Off Alarms

- **Temporary Turn Off:** Press the **ALARM OFF** button once when the alarm is sounding to stop it for the current day. It will reactivate the next day.
- **Permanent Turn Off:** Press and hold the **ALARM OFF** button to deactivate the alarm permanently. The alarm icon will disappear from the display.

4.5 Adjusting Display Brightness

The display has 8 levels of brightness. Short press the **DIMMER** button repeatedly to cycle through the brightness levels (OFF, Level 1-7). When in 'OFF' mode, the red indicator on top will remain on.

7 Level Volume Selectable



8 Level Brightness Adjustable



Image 4.2: Visual representation of the 8-level brightness adjustment for the LED display.

4.6 Adjusting Alarm Volume

The alarm buzzer has 7 adjustable volume levels. Short press the **VOLUME** button repeatedly to cycle through the volume levels.



Image 4.3: The alarm volume can be adjusted across 7 levels, from 92dB to 110dB.

4.7 Selecting Wake-Up Mode

Press the **BUZZ/VIB** button to select your preferred wake-up method:

- Loud Buzzer only
- Strong Bed Shaker only
- Both Buzzer and Shaker



Image 4.4: The alarm clock offers three distinct wake-up modes for personalized use.

4.8 12/24 Hour Format & DST

- **12/24 Hour Format:** Short press the **12/24H** button to switch between 12-hour and 24-hour time display.
- **DST Function:** Short press the **DST** button to activate or deactivate Daylight Saving Time.

USB Charging Port & 12/24H Time Format



Image 4.5: The clock supports both 12-hour and 24-hour time formats, and features a USB charging port.

4.9 USB Charging Port

The integrated USB charging port allows you to charge your smartphone or other USB-powered devices directly from the alarm clock. Simply connect your device's USB charging cable to the port on the clock.

5. MAINTENANCE

- Clean the clock surface with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- Keep the clock away from water and high humidity.
- Do not expose the clock to direct sunlight or extreme temperatures.
- If the clock will not be used for an extended period, consider removing the backup battery to prevent leakage.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock display is off.	No power supply; power cable loose.	Ensure the power adapter is securely plugged into the clock and a working outlet. Check if the dimmer is set to 'OFF'.
Alarm does not sound/vibrate.	Alarm not activated; volume too low; bed shaker not connected or placed incorrectly.	Verify alarm is activated (icon visible). Increase alarm volume. Ensure bed shaker is securely plugged in and properly placed.
Time/settings reset after power outage.	Backup battery is dead or not installed.	Replace the CR2032 backup battery. Ensure it is installed correctly.
USB charging not working.	Device not compatible; cable faulty; clock not powered.	Ensure the clock is powered. Try a different USB cable. Verify your device is compatible with standard USB charging.

7. SPECIFICATIONS

Feature	Detail
Brand	PPLLEE
Model Number	CR1018I
Color	Silver Surface (with Bed Shaker)
Display Type	Digital LED
Product Dimensions	8.7"W x 8.7"H (Display size)
Power Source	Corded Electric
Backup Battery	1 x CR2032 (included)
Material	Plastic
Item Weight	7 ounces (0.2 Kilograms)
Alarm Modes	Buzzer, Vibration, Buzzer + Vibration

Feature	Detail
Display Brightness	8 Levels (including OFF)
Alarm Volume	7 Levels
Time Format	12H/24H selectable
Special Features	Dual Alarms, Snooze, USB Charging Port, DST Function, Mirror Surface

8. WARRANTY AND SUPPORT







PPLEE is committed to providing high-quality products and customer satisfaction.


- **1-Year Warranty:** The product is covered by a 1-year warranty from the date of purchase against manufacturing defects.
- **90-Day Money-Back Guarantee:** If you are unsatisfied with the product, you may be eligible for a full refund within 90 days of purchase.
- **Lifetime Free Support:** PPLEE offers free lifetime user support for any questions or concerns regarding the product.
- **24-Hour Response Service:** For any inquiries, please contact us via Amazon. We aim to respond within 24 hours.



Image 8.1: Summary of warranty and support offerings.



	<p>PPLEE CR1018i Alarm Clock with USB Charger - User Manual</p> <p>Detailed user manual for the PPLEE CR1018i alarm clock, featuring dual alarms, USB charging, dimmer, and bed shaker. Learn how to set time, alarms, volume, DST, and use the vibrator function.</p>
	<p>PPLEE CR1008i Digital LED Alarm Clock with Bed Shaker User Manual</p> <p>User manual for the PPLEE CR1008i Digital LED Alarm Clock with Bed Shaker, covering setup, operation, features, and warranty information.</p>
	<p>PPLEE CR1018 Mirror Alarm Clock with USB Charger - User Manual</p> <p>Comprehensive user manual for the PPLEE CR1018 Mirror Alarm Clock with USB Charger. Learn how to set time, alarms, adjust brightness, use USB charging, and understand its features. Create your perfect sleep environment.</p>
	<p>PPLEE CR1008 Digital LED Alarm Clock User Manual</p> <p>Comprehensive user manual for the PPLEE CR1008 Digital LED Alarm Clock. This guide details setup, time and alarm setting, night light features, USB charging capabilities, DST adjustments, and warranty information provided by PPLEE and Yisong E-commerce Co.,Ltd.</p>
	<p>PPLEE CR1013 Wake-Up Alarm Clock User Manual</p> <p>Comprehensive user manual for the PPLEE CR1013 Wake-Up Alarm Clock, detailing setup, alarm settings, sunrise simulation, night light, white noise functions, and USB charging.</p>
	<p>PPLEE CR1001E Alarm Clock with USB Charger - User Manual</p> <p>Comprehensive user manual for the PPLEE CR1001E digital alarm clock. Learn how to set time, alarms, use the dimmer, DST, and USB charging features. Features a large LED display and battery backup.</p>



[PPLEE CR1018i Alarm Clock with USB Charger - User Manual](#)

Detailed user manual for the PPLEE CR1018i alarm clock, featuring dual alarms, USB charging, dimmer, and bed shaker. Learn how to set time, alarms, volume, DST, and use the vibrator function.

lang:en score:22 filesize: 9.19 M page_count: 2 document date: 2021-10-18