

Manuals.plus /

› MAMNV /

› MAMNV Robot Vacuum and Mop Combo BR151 Instruction Manual

MAMNV BR151

MAMNV Robot Vacuum and Mop Combo

MODEL: BR151 INSTRUCTION MANUAL

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your MAMNV Robot Vacuum and Mop Combo, Model BR151. This 2-in-1 device is designed to efficiently vacuum and mop various floor types, offering smart control options via WiFi, app, and Alexa voice commands. Its ultra-thin design allows for thorough cleaning in hard-to-reach areas, making it ideal for homes with hard floors, carpets, and pet hair.

What's in the Box

Upon unboxing your MAMNV Robot Vacuum and Mop Combo, please ensure all the following components are present:

- MAMNV Robot Vacuum and Mop Main Unit
- Charging Dock
- Power Adapter
- Remote Control (with batteries)
- Dustbin with Filter
- Water Tank
- Mop Pad
- Side Brushes (2 pairs)
- Cleaning Tool



Image: The MAMNV Robot Vacuum and Mop Combo main unit, remote control, and mop pad, illustrating the primary components included in the package.

Setup

- 1. Charging Dock Placement:** Place the charging dock against a wall in an open area, ensuring there are no obstacles within 1 meter (3 feet) to the sides and 2 meters (6 feet) in front. Connect the power adapter to the dock and plug it into a wall outlet.
- 2. Initial Charging:** Place the robot vacuum onto the charging dock. Ensure the charging contacts on the robot align with those on the dock. The indicator light on the robot will show charging status. Allow for a full charge before first use (approximately 4-5 hours).
- 3. Install Side Brushes:** Gently press the side brushes onto the posts on the bottom of the robot until they click into place.
- 4. Prepare for Vacuuming:** Ensure the dustbin with its filter is securely installed in the robot.
- 5. Prepare for Mopping (Optional):** Open the water tank, fill it with clean water (do not use cleaning solutions), and securely close the cap. Attach the mop pad to the bottom of the water tank. Insert the filled water tank into the designated slot on the robot.



Image: The robot vacuum automatically docking itself for charging, highlighting the charging base and the robot's position.

Operating

Your MAMNV Robot Vacuum offers multiple ways to initiate and manage cleaning tasks.

- **Manual Start:** Press the power button on the robot's top panel to start or pause cleaning.
- **Remote Control:** Use the included remote control to start/stop cleaning, select cleaning modes (Auto, Spot, Edge, Zig-zag), direct the robot manually, or send it back to the charging dock.
- **App Control:** Download the dedicated app (refer to the Quick Start Guide for QR code) to connect your robot via WiFi. The app allows for scheduling, real-time monitoring, cleaning mode selection, and adjusting suction power/water flow intensity.
- **Voice Control:** Integrate with Alexa for convenient voice commands to start or stop cleaning.

Advanced Gyroscope Navigation



vs



More comprehensive cleaning
cross over from hard floor to
carpet without effort



Image: The robot vacuum employing advanced gyroscope navigation for systematic cleaning, showing its path compared to random movement.

Ultra-Thin Design Multi-Clean Mode

2.87" slim body can easily glide into narrow spaces like under the bed/sofa for thoroughly clean.

2.87 inch



**Edge
Cleaning**



**Spot
Cleaning**

Image: The ultra-thin design of the robot vacuum allowing it to clean effectively under low-lying furniture.

Two levels of intensity adjustable as needed



Intelligent precision electric control water tank Uniform water discharge, will not soak the floor



Image: Diagram showing the two adjustable water intensity levels for mopping, ensuring precise water discharge.

Large-caliber suspension suction mouth



Close to the ground, Clean thoroughly
Meet the needs of different occasions
ground cleaning



Image: The robot vacuum's large-caliber suspension suction mouth effectively picking up various types of debris like hair, coffee, beans, dust, and general debris.

Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your robot vacuum.

1. **Emptying the Dustbin:** After each cleaning cycle, remove the dustbin by pulling the 'PULL' tab on the top cover. Open the dustbin lid and empty its contents into a trash receptacle.
2. **Cleaning the Filter:** Remove the filter from the dustbin. Tap it gently to dislodge dust. For a deeper clean, rinse the filter under running water. Ensure it is completely dry before reinserting. Replace the filter every 2-3 months, or more frequently depending on usage.
3. **Cleaning the Water Tank & Mop Pad:** After mopping, remove the water tank and empty any remaining water. Detach the mop pad, wash it by hand or machine, and allow it to air dry.
4. **Cleaning Side Brushes:** Periodically check the side brushes for tangled hair or debris. Use the provided cleaning tool or scissors to carefully cut and remove any tangled material. Replace worn-out brushes.
5. **Cleaning Main Brush:** Open the main brush cover on the bottom of the robot. Remove the main brush and use the cleaning tool to remove any tangled hair or debris. Reinstall the brush and cover.

6. **Cleaning Sensors and Charging Contacts:** Use a dry cloth to wipe the anti-drop sensors, bumper sensors, and charging contacts on both the robot and the charging dock.

Troubleshooting

If your robot vacuum encounters an issue, try the following steps:

- **Robot not charging:** Ensure the charging dock is powered on and the robot's charging contacts are clean and properly aligned with the dock.
- **Robot stuck or moving erratically:** Check for any obstructions (cables, small objects) around the wheels, brushes, or sensors. Clean these areas if necessary.
- **Poor cleaning performance:** Empty the dustbin, clean or replace the filter, and clean the main and side brushes. Ensure the water tank is filled for mopping.
- **App connectivity issues:** Ensure your home WiFi network is 2.4GHz and the robot is within range. Restart the robot and your router if needed.

Specifications

Feature	Detail
Brand	MAMNV
Special Feature	Smart
Color	Black
Product Dimensions	11.81"L x 2.91"W x 11.81"H
Filter Type	Cartridge
Battery Life	100 minutes
Voltage	14.4 Volts
Water Tank Capacity	0.2 Liters
Power Source	Battery Powered
Control Method	Remote, Voice
Compatible Devices	Amazon Echo
Form Factor	Robotic
Item Weight	9.2 pounds
Surface Recommendation	Hard Floor, Carpet

Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact MAMNV customer service directly. Keep your purchase receipt for warranty claims.

