

[Manuals.plus](#) /

› [Virone](#) /

› Virone RS-6 Wireless E27 Lamp Socket Remote Control Manual

Virone RS-6

Virone RS-6 Wireless E27 Lamp Socket Remote Control Manual

1. PRODUCT OVERVIEW

The Virone RS-6 is a wireless switch designed for standard E27 lamp sockets. This device allows you to remotely control your lighting using an included remote control. It is engineered for straightforward installation and ease of use, requiring no complex setup procedures.



Figure 1: Virone RS-6 Wireless E27 Lamp Socket and Remote Control

2. SETUP INSTRUCTIONS

1. **Unpack the Device:** Carefully remove the Virone RS-6 lamp socket and the remote control from its packaging.
2. **Insert Remote Control Battery:** The remote control requires one A23 battery. Open the battery compartment on the back of the remote and insert the battery, ensuring correct polarity.
3. **Install the Lamp Socket:** Screw the Virone RS-6 adapter into your existing E27 lamp holder. Ensure it is securely tightened.
4. **Install the Light Bulb:** Screw your E27 light bulb into the Virone RS-6 adapter.
5. **Power On:** Ensure the main power supply to the lamp holder is switched on. The device is now ready for operation.



Figure 2: Close-up view of the Virone RS-6 Wireless E27 Lamp Socket



Figure 3: Top view of the Virone RS-6 E27 screw base

3. OPERATING INSTRUCTIONS

The Virone RS-6 lamp socket is controlled wirelessly via the included remote control. The remote features dedicated buttons for easy operation:

- **ON/OFF Buttons:** Use the 'ON' button to turn the light on and the 'OFF' button to turn the light off.
- **Channel Buttons (1, 2, 3):** The remote control allows you to control up to three separate Virone RS-6 units independently. Press 'ON' for channel 1, 2, or 3 to activate the corresponding lamp socket, and 'OFF' for the respective channel to deactivate it.




Figure 4: Virone RS-6 Remote Control for operating the lamp socket

4. MAINTENANCE

- **Cleaning:** Wipe the lamp socket and remote control with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** When the remote control's range decreases or it stops responding, replace the A23 battery. Ensure the new battery is inserted with the correct polarity.
- **Storage:** Store the device in a dry place, away from direct sunlight and extreme temperatures.

5. TROUBLESHOOTING

- **Light does not turn on:**
 - Check if the main power supply to the lamp holder is on.
 - Ensure the light bulb is correctly screwed into the Virone RS-6 adapter and is functional.
 - Verify the Virone RS-6 adapter is securely screwed into the E27 lamp holder.

- Check the remote control battery. Replace if necessary.
- **Remote control not responding:**
 - Ensure the remote control battery is not depleted and is inserted correctly.
 - Confirm you are within the effective range (up to 30 m in open field). Obstacles may reduce this range.
 - Ensure there are no strong radio interference sources nearby.

6. SPECIFICATIONS

Feature	Specification
Brand	Virone
Model	RS-6
Material	Polycarbonate (PC)
Color	White
Product Dimensions (W x H x D)	36 mm x 82 mm x 14 mm
Mounting Type	Screw-in (E27 standard lamp holder)
Voltage	230 V~, 50 Hz
Max. Load Capacity	60 W
Protection Class (IP)	IP20
Transmitter Power Supply	1 x A23 battery
Free Field Range	30 m

7. OFFICIAL PRODUCT VIDEOS

No official product videos from the seller specifically demonstrating the Virone RS-6 Wireless E27 Lamp Socket with Remote Control were available for inclusion in this manual.

8. WARRANTY AND SUPPORT

Specific warranty terms and support contact information are not provided in the available product details. Please refer to your purchase documentation or contact your retailer for details regarding warranty coverage and technical support for your Virone RS-6 device.