

Combrite X8

Combrite X8 Rechargeable Wireless Gaming Mouse User Manual

Model: X8 | Brand: Combrite

1. INTRODUCTION

Thank you for choosing the Combrite X8 Rechargeable Wireless Gaming Mouse. This manual provides detailed instructions for setting up, operating, and maintaining your new mouse. Please read this manual thoroughly before use to ensure optimal performance and longevity of the product.



Image 1.1: Combrite X8 Wireless Gaming Mouse. This image displays the white Combrite X8 mouse with its honeycomb shell and vibrant RGB lighting, alongside the compact USB receiver.

2. PACKAGE CONTENTS

Please check the package for the following items:

- 1 x Combrite X8 Wireless Gaming Mouse
- 1 x USB Nano Receiver (stored in the bottom of the mouse)
- 1 x USB-C Charging Cable (70 cm)
- 1 x User Manual

3. PRODUCT OVERVIEW

The Combrite X8 mouse features an ergonomic, lightweight honeycomb design for comfortable use. It includes multiple buttons and customizable RGB lighting.



LIGHTWEIGHT HONEYCOMB DESIGN

MAKES IT EFFORTLESS TO MOVE AND LIFT
RELEASE YOUR WRIST GENTLY

Image 3.1: Lightweight Honeycomb Design. This image highlights the perforated honeycomb shell of the mouse, designed to reduce weight and provide ventilation.



Image 3.2: Combrite X8 Mouse Features. This image provides a detailed view of the mouse, showcasing the scroll wheel, DPI buttons, and side buttons.

4. SETUP INSTRUCTIONS

1. **Locate the USB Receiver:** The Nano USB receiver is stored in a compartment on the bottom of the mouse. Gently slide open the compartment cover to retrieve it.
2. **Connect the Receiver:** Insert the USB Nano receiver into an available USB port on your computer.
3. **Power On the Mouse:** Turn on the mouse using the power switch located on its underside.
4. **Automatic Connection:** The mouse should automatically connect to your computer. No additional drivers are typically required for basic functionality.



Image 4.1: Plug and Play Setup. This image illustrates the simple plug-and-play connection process, showing the mouse wirelessly connected to a laptop via the USB receiver.

5. OPERATING THE MOUSE

5.1 DPI Adjustment

The mouse features three preset DPI levels: 800, 1200, and 1600. You can cycle through these settings by pressing the DPI button located behind the scroll wheel. Each press will change the sensitivity, allowing you to adjust cursor speed to your preference.

5.2 LED Lighting Modes

The Combrite X8 mouse includes 10 different RGB LED lighting effects. To switch between lighting modes, press the DPI button and the left-click button simultaneously. To turn off the LED lighting, repeat this combination until the lights are off. Turning off the LEDs can help conserve battery life.

10 LIGHTING MODES

PRESS DPI BUTTON AND LEFT CLICK BUTTON TO SWITCH OR TURN OFF THE LIGHTING MODES
DPI+LEFT CLICK=LIGHTING MODE CHANGE



Image 5.1: 10 Lighting Modes. This image shows a collage highlighting various parts of the mouse, including the honeycomb design, comfortable scroll wheel, hollow flank, and side keys, all illuminated by different RGB effects.



Image 5.2: LED Light On/Off. This image contrasts two mice, one with its vibrant RGB lighting active and another with the lighting turned off, demonstrating the ability to control the illumination.

5.3 Charging the Mouse

The mouse is equipped with a built-in rechargeable Li-ion 750mAh battery. When the battery is low, connect the provided USB-C charging cable to the mouse's USB-C port and the other end to a USB power source (e.g., computer USB port, USB wall adapter). The mouse can be used while charging.



Image 5.3: Charging Indicator. This image shows the mouse with an illuminated scroll wheel, indicating that it is currently charging.

5.4 Silent Clicks

The Combrite X8 features silent-click switches, designed to reduce operational noise. This allows for a quieter user experience, suitable for various environments.

SILENT AND DURABLE CLICK



Image 5.4: Silent Click Feature. This image highlights the silent click functionality of the mouse buttons, indicating reduced noise during use.

5.5 Programmable Buttons

The mouse is equipped with 6 programmable buttons. Specific software or operating system settings may be required to customize the functions of these buttons. Refer to your operating system's peripheral settings for customization options.




Image 5.5: One-Click Desktop Button. This image illustrates a specific button on the mouse that can be configured to return to the desktop with a single click, useful for both gaming and work.

6. MAINTENANCE

6.1 Cleaning

To clean your mouse, use a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the mouse's internal components. Avoid using harsh chemicals or abrasive materials.

6.2 Battery Care

- Avoid fully discharging the battery frequently.
- Store the mouse in a cool, dry place when not in use for extended periods.
- Charge the mouse regularly to maintain battery health.

7. TROUBLESHOOTING

- **Mouse not responding:**

- Ensure the USB receiver is securely plugged into a working USB port.
- Check if the mouse is powered on.
- Recharge the mouse if the battery is low.
- Try plugging the receiver into a different USB port.

- **Cursor movement is erratic:**

- Clean the optical sensor on the bottom of the mouse.
- Ensure you are using the mouse on a suitable surface (non-reflective, uniform color).
- Adjust the DPI setting.

- **LED lights are off:**

- Press the DPI button and left-click button simultaneously to cycle through lighting modes or turn them on.
- Ensure the mouse has sufficient battery charge.

8. SPECIFICATIONS

Feature	Detail
Connection	2.4 GHz Wireless, USB-C (for charging)
Power Type	Rechargeable Li-on Battery
Battery Capacity	750mAh
Number of Keys	7 (including scroll wheel click)
Key Life	10 Million Switches
Lighting	10 RGB LED Modes
Wireless Range	Up to 10 meters
DPI Settings	800 / 1200 / 1600 DPI
Rated Voltage / Current	3.7V / 15mA
Product Weight	95g
Product Dimensions	13.5 x 7 x 4 cm
Compatibility	Windows, Mac, Linux (Desktop, Laptop, Chromebook)

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided at the time of purchase or visit the official Combrite website. Keep your proof of purchase for warranty claims.