

Deeyaple LED1305

Deeyaple 3D LED Digital Wall Clock

USER MANUAL

Model: LED1305

Introduction

Thank you for purchasing the Deeyaple 3D LED Digital Wall Clock. This versatile clock offers a clear 3D LED display, multiple functions including time, date, and temperature display, alarm with snooze, and adjustable brightness. It is designed for both wall mounting and desk placement, making it a perfect addition to your home or office. Please read this manual carefully to ensure proper use and maintenance of your new clock.



Image: The Deeyapple 3D LED Digital Wall Clock, showcasing its sleek design and accompanying remote control.

Key Features

- **Multifunctional Display:** Shows time (12/24 hour format), date, and temperature (Fahrenheit/Celsius).
- **Alarm with Snooze:** Set alarms with a convenient snooze function.
- **Adjustable Brightness:** Features 3 levels of brightness, with both automatic dimming based on ambient light and manual adjustment.
- **Power-off Memory Function:** Retains settings for 4-8 hours after power loss, eliminating the need for re-setup.
- **Dual Control:** Operate the clock using the included remote control or the buttons on the back of the unit.
- **Versatile Placement:** Designed for both wall mounting (includes non-marking hooks and expansion screws) and desk placement (includes a detachable stand).




Image: An overview diagram highlighting the clock's key features, including 24-hour system, date display, alarm, brightness control, night light, suspension display, time display, temperature display, remote setting, snooze, automatic dimming, and detachable stand.

Package Contents

Please check the package for the following items:

- 1 x Deeyaple 3D LED Digital Wall Clock
- 1 x Remote Control
- 1 x USB Power Cable
- 1 x Detachable Stand
- 1 x Set of Wall Mounting Accessories (non-marking hooks, expansion screws)
- 1 x User Manual



Image: A visual representation of the package contents, including the clock, remote, USB cable, stand, and mounting hardware.

Setup

1. Power Connection: Connect the USB power cable to the clock's power connector (located on the back) and plug the other end into a standard USB power adapter (not included) or a USB port. The clock will power on and display the default time.

2. Initial Setup (Time/Date/Temperature):

Use the remote control or the buttons on the back of the clock to set the current time, date, and preferred temperature unit (Fahrenheit or Celsius). Refer to the "Operating Instructions" section for detailed steps on setting these parameters.

3. Placement:

- **Desk Placement:** Attach the detachable stand to the base of the clock. Place the clock on a flat, stable surface such as a desk, table, or nightstand.
- **Wall Mounting:** Use the provided non-marking hooks and expansion screws. Identify the hook holes on the back of the clock. Mark the desired position on the wall, drill holes if necessary, insert expansion screws, and hang the clock securely.

Auto-dimming/Manual Adjustable Brightness




Image: A detailed view of the clock's dimensions and the back panel, indicating the infrared receiver, power connector, hook holes for wall mounting, and control buttons.


Operating Instructions

1. Time, Date, and Temperature Display

The clock can cycle through time, date, and temperature displays. Use the "MODE" button on the remote or the back of the clock to switch between display modes.

- **Time Display:** Shows the current time in 12-hour or 24-hour format.
- **Date Display:** Shows the current date (Month/Day/Year).
- **Temperature Display:** Shows the ambient temperature in Celsius or Fahrenheit.

Time Display



Loop Display Mode



Image: The clock demonstrating its "Loop Display Mode," cycling between showing the time, date, and temperature.

2. Brightness Adjustment

The clock features both automatic and manual brightness control.

- **Automatic Dimming:** The built-in light sensor detects ambient light and automatically adjusts the display brightness for optimal visibility and energy saving.
- **Manual Adjustment:** Use the "BRIGHT" button on the remote control to cycle through 3 levels of brightness (High, Medium, Low).




Image: A graphic illustrating the clock's brightness levels, from bright to dim, demonstrating its auto-dimming and manual adjustment capabilities.

3. Alarm Function

To set an alarm:

1. Press the "ALARM" button on the remote control.
2. Use the UP/DOWN arrows to set the desired alarm time.
3. Press "ALARM" again to confirm.

When the alarm sounds, press any button to activate the snooze function. The alarm will sound again after a set interval (default is 5 minutes). To turn off the alarm completely, press and hold the "ALARM" button.



Alarm with Snooze

Image: A visual showing the clock with an alarm icon and lightning bolts, indicating the alarm function with snooze.

4. Power-off Memory Function

The clock has a built-in memory function that retains your settings (time, date, alarm) for 4-8 hours in case of a power outage. This means you do not need to reset the clock after a brief power interruption.

Maintenance

- Cleaning:** Use a soft, dry cloth to wipe the clock's surface. Do not use abrasive cleaners or solvents, as they may damage the finish.
- Placement:** Avoid placing the clock in direct sunlight or near heat sources, as this may affect the display and internal components.
- Power:** Always use the provided USB cable and a compatible power adapter.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Clock does not turn on.	No power supply; loose cable connection.	Ensure the USB cable is securely connected and the power adapter is working. Try a different USB port or adapter.
Display is too dim or too bright.	Automatic dimming active; manual brightness needs adjustment.	Press the "BRIGHT" button on the remote to cycle through brightness levels. Ensure the light sensor is not obstructed.
Remote control not working.	Battery low/dead; obstruction between remote and clock; remote not pointed at infrared receiver.	Replace the remote control battery. Ensure there are no obstructions. Point the remote directly at the infrared receiver on the clock.
Time/Date/Temperature is incorrect.	Settings not configured or reset after prolonged power loss.	Follow the "Operating Instructions" to re-set the time, date, and temperature.

Specifications

Feature	Detail
Brand	Deeyaple
Model Number	LED1305
Color	Black
Product Dimensions (L x W x H)	24.99 x 3.81 x 8.99 cm (approx. 9.8 x 1.5 x 3.5 inches)
Material	Plastic
Item Weight	260 grams
Display Type	Digital (LED)
Power Source	Corded Electric (USB)
Special Features	Large display, adjustable brightness, alarm, calendar display, temperature display, silent clock, remote control.


Warranty and Support

Deeyaple is committed to providing high-quality products and responsive customer service. This product comes with a standard manufacturer's warranty. For any questions, technical support, or warranty claims, please contact your retailer or visit the official Deeyaple brand store on Amazon:

Visit the Deeyaple Store

Please retain your proof of purchase for warranty purposes.

Related Documents

 <p>180*90mm 105G铜版纸正反面彩色印</p>	<p><u>Deeyaple Magic Arm Quick Start Guide: Wireless Speaker and Phone Stand</u></p> <p>A quick start guide for the Deeyaple Magic Arm, a wireless Bluetooth speaker and phone stand. Learn about its features, specifications, controls, indicator lights, pairing, and warranty.</p>
--	--