



Manuals.plus /

› **TIMBOOTECH** /

› TIMBOOTECH Wireless HDMI Transmitter User Manual (Model B09QVDHDGP)

TIMBOOTECH B09QVDHDGP

TIMBOOTECH Wireless HDMI Transmitter User Manual

Model: B09QVDHDGP

1. INTRODUCTION

The TIMBOOTECH Wireless HDMI Transmitter system provides a convenient solution for wirelessly extending HDMI signals from a source device to a display. This manual provides detailed instructions for the proper setup, operation, and maintenance of your wireless HDMI system.

2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- Wireless HDMI Transmitter Unit (TX)
- Wireless HDMI Receiver Unit (RX)
- USB Power Cables (Quantity may vary)
- User Manual (This document)

3. PRODUCT FEATURES

- Wireless HDMI signal transmission.
- Supports various HDMI-enabled source devices.
- Compatible with HDTVs and projectors.
- Plug-and-play operation.
- Low power consumption (5 Watts).

4. SETUP INSTRUCTIONS

Follow these steps to set up your TIMBOOTECH Wireless HDMI Transmitter system:

1. **Connect the Transmitter (TX):** Plug the HDMI connector of the Transmitter unit into the HDMI output port of

your source device (e.g., laptop, PC, camera, set-top box, DVD player).

2. **Power the Transmitter (TX):** Connect the USB power cable to the Transmitter unit and plug the other end into a USB power source (e.g., a USB port on your source device, a USB wall adapter). The TX unit will power on automatically.
3. **Connect the Receiver (RX):** Plug the HDMI connector of the Receiver unit into an available HDMI input port on your display device (e.g., HDTV, projector).
4. **Power the Receiver (RX):** Connect the USB power cable to the Receiver unit and plug the other end into a USB power source (e.g., a USB port on your display, a USB wall adapter). The RX unit will power on automatically.
5. **Establish Connection:** Once both units are powered on, they will automatically attempt to pair and establish a wireless connection. This may take a few seconds. The indicator lights on both units will confirm a successful connection.



This image illustrates the transmitter (TX) and receiver (RX) components of the wireless HDMI system. The transmitter connects to source devices such as cameras, PCs, and set-top boxes. The receiver connects to display devices like HDTVs and projectors.

5. OPERATING INSTRUCTIONS

After successful setup, operating the wireless HDMI system is straightforward:

- **Power On:** Ensure both the Transmitter (TX) and Receiver (RX) units are powered on and connected to their respective devices.
- **Source Selection:** On your display device, select the HDMI input port to which the Receiver (RX) is connected.
- **Automatic Display:** The content from your source device connected to the TX unit should automatically appear on your display.
- **Multi-Transmitter Use (Optional):** If you have multiple TX units (up to 8 supported), you can switch between different source devices by pressing the button on the active TX unit. The RX unit will automatically detect and display the signal from the selected TX.



This image highlights the simple plug-and-play functionality of the wireless HDMI system. Simply connect the transmitter to your source device and the receiver to your display for instant wireless video transmission.

送信機を 最大 8 台増設！ 複数のパソコンで画面を切り替え



This image demonstrates the capability of connecting up to eight transmitter units to various source devices, allowing multiple users to share content wirelessly to a single display by switching between sources.

6. TROUBLESHOOTING

If you encounter issues, refer to the following troubleshooting guide:

- **No Signal on Display:**

- Ensure both TX and RX units are properly powered and their indicator lights are on.
- Verify that the HDMI cables are securely connected to both the source and display devices.
- Check that your display is set to the correct HDMI input source.
- Try restarting both the source device and the display.

- **Intermittent Signal or Poor Quality:**

- Ensure there are no significant obstructions (e.g., thick walls, metal objects) between the TX and RX units.
- Reduce the distance between the TX and RX units.
- Minimize interference from other wireless devices (e.g., Wi-Fi routers, cordless phones).
- Ensure both units are receiving adequate power.

- **Units Not Pairing:**

- Power cycle both the TX and RX units.
- Ensure they are within close proximity during the initial pairing process.

7. SPECIFICATIONS

Brand	TIMBOOTECH
Model Number	B09QVDHDGP
Connectivity Technology	HDMI
Total HDMI Ports	1 (per unit)
Connector Type	HDMI
Output Wattage	5 Watts
Surround Sound Channel Configuration	2
UPC	712297173755

8. MAINTENANCE

To ensure the longevity and optimal performance of your wireless HDMI system:

- Keep the units clean and free from dust. Use a soft, dry cloth for cleaning.
- Avoid exposing the units to extreme temperatures, humidity, or direct sunlight.
- Do not attempt to disassemble or repair the units yourself. This may void the warranty.
- Store the units in a cool, dry place when not in use for extended periods.

9. WARRANTY AND SUPPORT

This TIMBOOTECH Wireless HDMI Transmitter comes with a limited warranty. For specific warranty details, please refer to the documentation included with your purchase or contact TIMBOOTECH customer support.

For technical support or inquiries, please visit the official TIMBOOTECH website or contact their customer service department.