



Manuals.plus /

› Papablic /

› Papablic 3-in-1 Warm-Ease Baby Bottle Warmer PPL75 Instruction Manual

## Papablic PPL75

# Papablic 3-in-1 Warm-Ease Baby Bottle Warmer PPL75 Instruction Manual

Model: PPL75

## 1. IMPORTANT SAFETY INFORMATION

---

Please read and understand all instructions before using the Papablic 3-in-1 Warm-Ease Baby Bottle Warmer. Failure to follow these instructions may result in electric shock, fire, serious injury, or property damage. Keep this manual for future reference.

- **Electrical Safety:** Ensure the voltage indicated on the appliance matches your local power supply before connecting. Do not immerse the cord, plug, or appliance in water or other liquids. Do not operate the appliance with a damaged cord or plug.
- **Water Safety:** Always use distilled or purified water to prevent mineral buildup. Do not overfill the water reservoir. Ensure the water level is appropriate for the bottle size.
- **Burn Hazard:** Hot water and steam can cause severe burns. Exercise extreme caution when handling the appliance during and after operation. Always use the bottle lifter to remove bottles. Allow the appliance to cool before cleaning.
- **Child Safety:** This appliance is not intended for use by children. Keep the appliance and its cord out of reach of children. Adult supervision is required at all times when the appliance is in use.
- **Proper Use:** Use the appliance only for its intended purpose of warming baby bottles and food jars. Do not use attachments not recommended by the manufacturer. Do not place the appliance on or near a hot gas or electric burner, or in a heated oven.

## 2. PRODUCT OVERVIEW

---

The Papablic 3-in-1 Warm-Ease Baby Bottle Warmer is designed to safely and efficiently warm breastmilk, formula, and baby food. It features a digital timer, automatic shut-off, and a gentle water bath heating system to preserve nutrients.



Image: The Papablic 3-in-1 Warm-Ease Baby Bottle Warmer in use, illustrating its compact design and ease of integration into daily routines.

### Key Features:

- **3-in-1 Functionality:** Warms milk, defrosts milk, and keeps milk warm.
- **Digital Timer:** Provides precise control over warming duration.
- **Automatic Shut-Off:** Enhances safety by powering off when warming is complete.
- **Water Bath System:** Ensures even heating and helps preserve milk nutrients.
- **Easy-to-Use Control Panel:** Intuitive interface for selecting modes and settings.

### 3. PACKAGE CONTENTS

---

Upon unpacking, please ensure all items are present and in good condition:

- Papablic 3-in-1 Warm-Ease Baby Bottle Warmer Unit
- Bottle Lifter/Basket
- Instruction Manual

## 4. SETUP AND FIRST USE

---

### 4.1 Initial Cleaning

1. Unpack all components and remove any packaging materials.
2. Wipe the exterior of the warmer unit with a damp cloth.
3. Wash the bottle lifter/basket with warm, soapy water, rinse thoroughly, and air dry.
4. Do not immerse the main unit in water.

### 4.2 Placement

- Place the warmer on a stable, flat, heat-resistant surface, away from direct sunlight, heat sources, and water.
- Ensure there is adequate ventilation around the unit.

### 4.3 Filling the Water Reservoir

- Pour distilled or purified water into the water reservoir up to the indicated maximum fill line, or until the water level is slightly above the milk level in the bottle you intend to warm.
- Do not use tap water as it can lead to mineral buildup and affect performance.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Control Panel Overview



## Easy to Operate

- Automatically works out optimum warming time
- Memory mode for set-and-forget

*Image: The control panel features intuitive buttons for various functions and a digital display for time and temperature.*

The control panel includes a digital display and several buttons for selecting functions and adjusting settings:

- **Power Button:** Turns the unit on/off.
- **Mode Selection Buttons:** For warming, defrosting, and keeping warm.
- **+/- Buttons:** Adjusts warming time or temperature.
- **Digital Display:** Shows remaining time or current temperature.

### 5.2 Warming Milk/Formula

1. Place the bottle containing milk or formula into the bottle lifter/basket.
2. Insert the basket with the bottle into the warmer unit.
3. Ensure the water level in the reservoir is appropriate (slightly above the milk level in the bottle).
4. Press the Power button to turn on the unit.
5. Select the desired warming mode (e.g., for breastmilk or formula). The unit will display a default warming time.
6. Use the +/- buttons to adjust the warming time if necessary, based on the milk volume and starting

temperature (refrigerated or room temperature).

7. The warmer will begin heating. The digital display will count down the remaining time.
8. Once the warming cycle is complete, the unit will beep and automatically shut off.
9. Carefully use the bottle lifter to remove the hot bottle.
10. Always test the milk temperature on the back of your hand before feeding your baby.



*Image: The bottle warmer efficiently heats milk using a water bath, often ready in just a few minutes.*


### 5.3 Defrosting Milk

1. Place the frozen milk bottle or bag (ensure it is freezer-safe) into the bottle lifter/basket and then into the warmer.
2. Fill the reservoir with water as described in Section 4.3.
3. Press the Power button.
4. Select the Defrost mode. The unit will display a default defrosting time.
5. Adjust the time using the +/- buttons if needed.
6. The warmer will gently defrost the milk. The digital display will show the remaining time.
7. Once complete, remove the bottle/bag and check the milk. If not fully defrosted, you may run another short cycle or allow it to sit for a few minutes.

## 5.4 Keep Warm Function

This function allows you to maintain a constant, safe temperature for milk, ideal for night feedings.

1. After warming, or if you wish to keep pre-warmed milk at temperature, place the bottle in the warmer.
2. Select the Keep Warm mode. The unit will maintain a set temperature (e.g., 99°F / 37°C).
3. The digital display will show the current temperature.
4. The unit will automatically shut off after a prolonged period (e.g., 24 hours) or when manually powered off.



*Image: The 'Keep Warm' function helps maintain milk at a constant temperature, simplifying night feedings.*

## 5.5 Automatic Shut-Off



## Automatically Shut Off

- Built-in-timer displays countdown
- Sounds an alarm and power off when it's ready

*Image: The unit features an automatic shut-off mechanism for safety and convenience, indicated by a built-in timer.*

For safety and energy efficiency, the Papablic Warm-Ease Bottle Warmer is equipped with an automatic shut-off feature. After a warming or defrosting cycle is complete, the unit will beep and power off. In 'Keep Warm' mode, it will maintain temperature for an extended period before automatically shutting down.

## 6. MAINTENANCE AND CLEANING

---

### 6.1 Daily Cleaning

1. Always unplug the warmer and allow it to cool completely before cleaning.
2. Empty any remaining water from the reservoir.
3. Wipe the exterior and interior of the reservoir with a damp cloth. For stubborn stains, use a mild detergent and rinse thoroughly.
4. Wash the bottle lifter/basket with warm, soapy water and rinse well.
5. Do not use abrasive cleaning agents, scouring pads, or solvents.

### 6.2 Descaling

Mineral deposits (limescale) can build up in the water reservoir over time, especially if tap water is used.

Descaling regularly ensures optimal performance.

1. Mix 50ml of white vinegar with 100ml of cold water.
2. Pour the mixture into the water reservoir.
3. Allow the solution to soak for 30 minutes to 1 hour, or until the limescale dissolves. Do not turn on the warmer during this process.
4. Empty the solution and rinse the reservoir thoroughly with clean water several times to remove any vinegar residue.
5. Repeat if necessary.

## 6.3 Storage

When not in use, ensure the warmer is clean, dry, and stored in a cool, dry place, out of reach of children.

## 7. TROUBLESHOOTING

---

If you encounter issues with your Papablic Warm-Ease Bottle Warmer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Warmer not turning on.	Not plugged in; power outlet issue; unit malfunction.	Ensure the power cord is securely plugged into a working outlet. Try a different outlet. If the problem persists, contact customer support.
Milk not warming or warming too slowly.	Insufficient water; mineral buildup; incorrect time setting; bottle type.	Check water level and refill if necessary. Descal the unit (see Section 6.2). Increase warming time. Ensure bottle material is suitable for warming.
Milk is too hot.	Warming time too long; too much water.	Reduce warming time. Ensure water level is appropriate for the bottle size. Always test milk temperature before feeding.
Unit beeps continuously or displays an error.	Low water level; internal error.	Check water level and add water if needed. Unplug the unit, wait 5 minutes, then plug it back in. If the error persists, contact customer support.

If the issue is not resolved by the above steps, please contact Papablic Customer Support for assistance.

## 8. SPECIFICATIONS

---

- **Model Number:** PPL75
- **Manufacturer:** Papablic
- **Item Weight:** 969 g
- **Package Dimensions:** 22.9 x 13.7 x 12.2 cm
- **Power:** Refer to product label for specific voltage and wattage.
- **Material:** BPA-free plastic (typical for baby products).

## 9. WARRANTY AND SUPPORT

---

The Papablic 3-in-1 Warm-Ease Baby Bottle Warmer comes with a manufacturer's warranty. Please refer to the warranty card included in your package or visit the official Papablic website for detailed warranty terms and conditions.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Papablic Customer Service through their official website or the contact information provided with your purchase.