

Globe Electric 51802

Globe Electric Williams 51802 1-Light Wall Sconce Instruction Manual

Model: 51802

1. INTRODUCTION

Thank you for purchasing the Globe Electric Williams 51802 1-Light Wall Sconce. This fixture is designed for indoor use, offering a blend of rustic industrial and mid-century modern aesthetics with its matte black finish and dark faux wood accents. This manual provides essential information for the safe and proper installation, operation, and maintenance of your new wall sconce. Please read all instructions carefully before beginning installation and retain this manual for future reference.



Image 1.1: The Globe Electric Williams 51802 1-Light Matte Black Wall Sconce. This image displays the overall design of the fixture, featuring a matte black finish and a dark faux wood accent, suitable for various indoor settings.

2. SAFETY INFORMATION

WARNING: Risk of electric shock. Turn off power at the circuit breaker or fuse box before installation or servicing. Improper installation can result in electric shock or fire.

- Read all instructions carefully before installing.
- Consult a qualified electrician if you are unsure about the installation process.
- Ensure all electrical connections comply with local codes and ordinances.
- Do not exceed the maximum wattage specified for this fixture (60W).
- Use only the recommended bulb type (A19, CFL/Incandescent/LED).
- Do not connect this fixture to an ungrounded electrical system.
- Handle the fixture with care to avoid damage.
- Keep flammable materials away from the light bulb when in operation.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation. If any parts are missing or damaged, do not attempt to assemble or install the fixture. Contact customer service for assistance.

- 1 x Williams 1-Light Wall Sconce Fixture
- 1 x Mounting Hardware Kit (includes mounting plate, screws, wire nuts)
- 1 x Instruction Manual

4. TOOLS REQUIRED (NOT INCLUDED)

The following tools are typically required for installation:

- Phillips Head Screwdriver
- Flathead Screwdriver
- Wire Strippers
- Electrical Tape
- Pliers
- Safety Glasses

5. INSTALLATION

This fixture can be installed as either a hardwired unit or a plug-in unit. Follow the appropriate steps below.

5.1 Hardwired Installation

1. **Turn off Power:** Locate the circuit breaker or fuse box and turn off the power to the junction box where you will be installing the fixture.
2. **Prepare Mounting Plate:** Attach the mounting plate to the junction box using the screws provided in the hardware kit. Ensure the plate is securely fastened.
3. **Make Electrical Connections:**
 - Connect the **black** wire from the fixture to the **black** (hot) wire from the junction box using a wire nut.
 - Connect the **white** wire from the fixture to the **white** (neutral) wire from the junction box using a wire nut.
 - Connect the **ground** wire (bare copper or green) from the fixture to the **ground** wire from the junction box (or to the green ground screw on the mounting plate) using a wire nut.
 - Ensure all connections are secure and no bare wire is exposed. Wrap connections with electrical tape if necessary.
4. **Mount Fixture:** Carefully tuck all wires into the junction box. Align the fixture base with the mounting plate and secure it with the decorative nuts or screws provided.
5. **Install Bulb:** Screw in one A19 bulb (not included) into the socket. Do not exceed 60 watts.
6. **Restore Power:** Turn the power back on at the circuit breaker.



Image 5.1: Typical wiring diagram for a hardwired wall sconce. This diagram illustrates the connection of black (hot), white (neutral), and ground wires from the fixture to the corresponding wires in the electrical junction box.

5.2 Plug-In Installation

1. **Prepare Fixture:** If the fixture is designed for both hardwire and plug-in, ensure the plug-in cord is properly attached and secured according to the manufacturer's instructions (if not pre-assembled).
2. **Mount Fixture:** Secure the fixture to the wall using the provided mounting hardware. Ensure it is firmly attached to a wall stud or using appropriate wall anchors.
3. **Install Bulb:** Screw in one A19 bulb (not included) into the socket. Do not exceed 60 watts.
4. **Plug In:** Insert the plug into a standard wall outlet.

6. OPERATION

Once installed and power is restored, the wall sconce can be operated. If hardwired, control the light using the wall switch connected to the circuit. If installed as a plug-in unit, the fixture may feature an integrated push-button switch on the cord or base for convenient on/off control.

- **Bulb Type:** Use one A19 bulb.
- **Wattage:** Maximum 60 Watts.
- **Light Source:** Compatible with CFL, Incandescent, or LED bulbs.

7. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your wall sconce.

- **Cleaning:** Turn off the power and allow the fixture to cool before cleaning. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- **Bulb Replacement:** Ensure the power is off and the bulb has cooled completely before attempting to replace it. Unscrew the old bulb and screw in a new A19 bulb, ensuring it does not exceed 60 watts.
- **Inspection:** Periodically check all connections and mounting hardware to ensure they remain secure.

8. TROUBLESHOOTING

If your wall sconce is not functioning correctly, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture.	Check circuit breaker/fuse.
	Loose wire connections.	Turn off power, check wire connections.
	Defective bulb.	Replace bulb.
	Wall switch is off (for hardwired). Fixture switch is off (for plug-in).	Ensure wall switch is in the ON position. Ensure fixture switch is in the ON position.
Light flickers.	Loose bulb.	Tighten bulb.
	Loose wire connections.	Turn off power, check wire connections.
	Incorrect bulb type.	Ensure correct bulb type and wattage.

If the problem persists after attempting these solutions, contact a qualified electrician or Globe Electric customer support.

9. SPECIFICATIONS

Brand	Globe Electric
Model Number	51802
Product Type	Wall Sconce
Color	Matte Black
Material	Brass
Style	Mid-Century Modern
Indoor/Outdoor Usage	Indoor
Power Source	Corded Electric (Hardwired/Plug-In)
Light Source	CFL/Incandescent/LED
Number of Light Sources	1
Recommended Bulb Type	A19
Max Wattage	60 W
Mounting Type	Wall Mount
Height	7.5 in.
Width	6 in.
Depth	5.7 in.
Item Weight	2 Pounds
UPC	058219518021

10. WARRANTY AND SUPPORT

This Globe Electric Williams 51802 Wall Sconce comes with a **1-year limited warranty** from the date of purchase, covering defects in materials and workmanship. This warranty does not cover damage caused by improper installation, accident, misuse, abuse, or normal wear and tear.

For warranty claims, technical support, or missing parts, please contact Globe Electric customer service. You can find contact information and additional resources by visiting the official Globe Electric website or their store on Amazon:

[Visit the Globe Electric Store on Amazon](#)

Please have your model number (51802) and proof of purchase ready when contacting support.