



Manuals.plus /

› [Lenovo](#) /

› [Lenovo ThinkCentre M700 SFF Gaming Desktop Computer User Manual](#)

Lenovo M700

Lenovo ThinkCentre M700 SFF Gaming Desktop Computer User Manual

Model: M700

Brand: Lenovo

INTRODUCTION

This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your Lenovo ThinkCentre M700 Small Form Factor (SFF) Gaming Desktop Computer. Please read this manual thoroughly before using the product to ensure proper operation and longevity.

PRODUCT OVERVIEW

The Lenovo ThinkCentre M700 SFF is a compact yet powerful desktop computer designed for both business productivity and gaming. It features a 6th Generation Intel Core i7-6700 processor, 16GB DDR4 RAM, a 1TB SSD, and an NVIDIA GeForce GT 1030 2GB dedicated graphics card, alongside integrated Intel HD Graphics 530.


This system comes pre-installed with Windows 10 Pro (64-bit) and includes a wireless keyboard and mouse combo, and a USB Wi-Fi & Bluetooth combo adapter.

Front View



This image displays the front view of the Lenovo ThinkCentre M700 SFF desktop computer. It shows the optical drive, front USB ports (USB 2.0 and USB 3.0), headphone and microphone jacks, and the power button. The "Lenovo" logo is visible on the side panel.

Front Panel Ports



A detailed view of the front panel ports, indicating two USB 2.0 ports, two USB 3.0 ports, and the audio jacks for microphone and headphones. This highlights the accessible connectivity options.

Rear View



This image shows the rear panel of the desktop, detailing the various input/output ports including USB 3.0, USB 2.0, serial, Ethernet (RJ-45), VGA, and DisplayPort connections. The power supply unit and ventilation grilles are also visible.

Dimensions



An illustration of the Lenovo ThinkCentre M700 SFF with its dimensions: 13.31 inches (width), 14.05 inches (height), and 3.46 inches (depth). This provides a clear understanding of the physical size of the unit.

Included Components

- Lenovo ThinkCentre M700 SFF Desktop
- Wireless Keyboard & Mouse Combo
- USB Wi-Fi & Bluetooth Combo Adapter
- Power Cord

SETUP

Follow these steps to set up your Lenovo ThinkCentre M700 SFF desktop computer.

1. **Unpacking:** Carefully remove all components from the packaging. Ensure all included items are present.
2. **Placement:** Place the desktop on a stable, flat surface with adequate ventilation. Avoid placing it in direct sunlight or near heat sources. Ensure there is enough space around the vents for proper airflow.
3. **Connect Monitor:** Connect your monitor to one of the available video output ports on the rear of the desktop (VGA or DisplayPort). The system supports up to 3 monitors.



This image shows the Lenovo ThinkCentre M700 SFF desktop connected to a monitor, keyboard, and mouse, illustrating a typical setup.

4. **Connect Peripherals:**
 - Insert the USB Wi-Fi & Bluetooth Combo Adapter into an available USB port.
 - Connect the wireless keyboard and mouse receiver to another available USB port.
 - Connect any other desired peripherals (e.g., speakers, external hard drives) to the appropriate ports.
5. **Power Connection:** Connect the power cord to the power input on the rear of the desktop, then plug the other end into a grounded electrical outlet.
6. **First Boot:** Press the power button on the front of the desktop. The system will boot into Windows 10 Pro. Follow the on-screen instructions for initial Windows setup, if prompted.

OPERATING INSTRUCTIONS

Power On/Off

- **To Power On:** Press the power button located on the front panel.
- **To Shut Down:** Click the Start button in Windows, then select Power > Shut down.
- **To Restart:** Click the Start button in Windows, then select Power > Restart.
- **To Sleep:** Click the Start button in Windows, then select Power > Sleep.

Using the Optical Drive (DVD-RW)

The integrated DVD-RW drive allows you to read and write CDs and DVDs.

1. Press the eject button on the drive to open the tray.
2. Place the disc label-side up on the tray.
3. Gently push the tray back into the drive until it clicks shut.
4. The operating system will typically detect the disc and prompt you for action.

Connecting to Networks

Your system supports both wired (Ethernet) and wireless (Wi-Fi) network connections.

- **Wired Connection:** Connect an Ethernet cable from your router/modem to the RJ-45 port on the rear of the desktop.
- **Wireless Connection:** Ensure the USB Wi-Fi adapter is connected. In Windows, click the network icon in the system tray, select your Wi-Fi network, enter the password, and connect.

Display Configuration

The system supports multiple displays via the integrated Intel HD Graphics 530 and the dedicated NVIDIA GeForce GT 1030.

- To configure display settings, right-click on the desktop and select "Display settings" or "NVIDIA Control Panel" for advanced options.
- You can extend your desktop across multiple monitors or duplicate your display.

MAINTENANCE

Regular maintenance helps ensure the optimal performance and longevity of your desktop computer.

- **Cleaning:**
 - Use a soft, lint-free cloth to wipe down the exterior of the desktop.
 - For stubborn marks, dampen the cloth slightly with water or a mild, non-abrasive cleaner.
 - Use compressed air to clear dust from ventilation grilles and ports periodically. Ensure the system is powered off before cleaning.
- **Software Updates:** Regularly check for and install updates for Windows, drivers (especially graphics drivers for NVIDIA GT 1030), and other installed software. This improves security, performance, and compatibility.
- **Data Backup:** Periodically back up important data to an external drive or cloud storage to prevent data loss.
- **Antivirus/Malware Protection:** Keep your antivirus software up-to-date and perform regular scans to protect against malicious software.

TROUBLESHOOTING

This section provides solutions to common issues you might encounter.

Problem	Possible Cause	Solution
Computer does not power on.	Power cord loose; power outlet issue.	Check power cord connections at both the desktop and the wall outlet. Try a different outlet.
No display on monitor.	Monitor not connected; incorrect input source; graphics driver issue.	Ensure monitor cable is securely connected. Check monitor's input source. Restart computer. Update graphics drivers if possible.
Wi-Fi not connecting.	Wi-Fi adapter loose; incorrect password; router issue.	Re-insert USB Wi-Fi adapter. Verify Wi-Fi password. Restart router.
System is slow or unresponsive.	Too many programs running; low disk space; malware.	Close unnecessary programs. Free up disk space. Run antivirus scan.

If you encounter issues not covered here, please refer to the [Lenovo support website](#) or contact customer service.

SPECIFICATIONS

Component	Specification
Processor	6th Generation Intel Core i7-6700 (3.40 GHz, up to 4.00 GHz, 4 Cores, 8 Threads, 6 MB Intel Smart Cache)
Memory (RAM)	16GB DDR4 RAM (upgradable to 32GB DDR4-2133)
Storage	1TB SSD
Operating System	Microsoft Windows 10 Pro (64-bit)
Graphics	Integrated Intel HD Graphics 530 & NVIDIA GeForce GT 1030 2GB
Optical Drive	DVD-RW
Wireless Connectivity	USB Wi-Fi & Bluetooth Adapter (802.11n)
Front Ports	2 x USB 3.0, 2 x USB 2.0, Microphone (3.5mm), Headphone (3.5mm)
Rear Ports	2 x USB 3.0, 2 x USB 2.0, Serial (9-pin), Ethernet (RJ-45), VGA, DisplayPort
Dimensions (L x W x H)	13.31" x 14.05" x 3.46"
Weight	9 kg (19.8 lbs)

WARRANTY AND SUPPORT

This product is sold as "Renewed" and typically comes with a limited warranty from the seller or Amazon Renewed.

- **Return Policy:** The product has a 90-day return policy for refund/replacement.
- **Protection Plans:** Optional 2-Year and 3-Year Protection Plans are available for purchase.
- **Technical Support:** For technical assistance, refer to the seller's contact information or the Amazon Renewed support

page.

For general Lenovo product support and drivers, visit the official Lenovo support website.