

VEVOR E70-36

VEVOR Insert Range Hood Instruction Manual

Model: E70-36 | 36 Inch, 800 CFM, 3-Speed Button Control

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, observe the following:

- Install this range hood in accordance with all specified instructions.
- Always disconnect power before servicing or cleaning the unit.
- Ensure proper ventilation for combustion gases from fuel-burning equipment to prevent back-drafting.
- Do not use the range hood for exhausting hazardous or explosive materials.
- Clean grease filters frequently. Grease accumulation can lead to fire.
- Never leave surface units unattended at high settings. Boil-overs cause smoking and greasy spill-overs that may ignite.
- Use appropriate pan size. Always use cookware appropriate for the size of the surface element.

Refer to local building codes and regulations for specific installation requirements.

PRODUCT OVERVIEW

The VEVOR Insert Range Hood (Model E70-36) is a 36-inch stainless steel built-in kitchen vent designed to effectively remove cooking fumes and odors. It features a powerful 800 CFM motor, 3-speed push-button controls, energy-efficient LED lighting, and easy-to-clean baffle filters. This unit supports both ducted and ductless configurations to suit various kitchen setups.

Key Features

- **Powerful 800 CFM Suction:** Effectively removes smoke, grease, and odors.
- **3-Speed Push Button Control:** Easy selection of fan speeds (200/500/800 CFM) and light control.
- **Durable Stainless Steel Construction:** Rust-proof and corrosion-resistant for longevity.
- **Energy-Efficient LED Lights:** Two 3W LED lamps provide bright, warm illumination for the cooking area.
- **Dual Filtration System:** Includes detachable, dishwasher-safe stainless steel baffle filters and internal charcoal filters for comprehensive air purification.

- **Ducted/Ductless Convertible:** Flexible installation options to vent air outdoors or recirculate filtered air indoors.
- **Ultra-Quiet Operation:** Max noise level of 62dB for a peaceful cooking environment.

Package Contents

- 1 x Built-in Range Hood
- 1 x Duct (59.1 inch / 1.5 m)
- 1 x Carbon Filter
- 1 x Manual



VEVOR Insert Range Hood, 36 Inch, installed in a kitchen setting.

This image shows the VEVOR Insert Range Hood seamlessly integrated into a kitchen cabinet above a stovetop, demonstrating its sleek, built-in design.


SETUP AND INSTALLATION

Proper installation is crucial for the optimal performance and safety of your range hood. It is recommended that installation be performed by a qualified technician.

Ducted vs. Ductless Configuration

Your VEVOR range hood can be configured for either ducted or ductless operation:

- **Ducted (Vented) Mode:** Air is drawn through the baffle filters, passed through the duct, and expelled outside your home. This method offers the most effective removal of cooking fumes and moisture.
- **Ductless (Recirculating) Mode:** Air is drawn through the baffle filters, then through activated charcoal filters (included), which remove odors and smoke. The filtered air is then recirculated back into the kitchen. This mode is suitable when external venting is not feasible.



Dual Filtration System: Ducted and Ductless Configurations.

This diagram visually explains how the range hood operates in both ducted mode (venting outside) and ductless mode (recirculating air through charcoal filters).

Dimensions

Ensure adequate space for installation. The overall dimensions are 35.5 x 11.5 x 15.3 inches (90.2 x 29.3 x 38.9 cm).

Product Dimensions		
Measurement	Value (Inches)	Value (cm)

Measurement	Value (Inches)	Value (cm)
Overall Length	35.5	90.2
Overall Width	11.5	29.3
Overall Height	15.3	38.9

USER-FRIENDLY DESIGNS

Bring you the excellent cooking time

The diagram illustrates the VEVOR range hood's design features. It shows the stainless steel body, the front panel with the VEVOR logo and five push-button controls, and the internal components including the LED lights and the grease-collecting box. Callouts point to the stainless steel body, the LED lights, the clip design for the front plate, and the grease-collecting box.

Stainless Steel Body
Rustproof & Durable

3W Warm Color LED Lights
Bright but Not Dazzling

Clip Design
Free to Install & Detach Plate

Grease-Collecting Box
Effortless to Clean

Detailed Product Dimensions and Measurements.

This image provides a comprehensive view of the range hood's dimensions, including various internal and external measurements for precise installation planning.

OPERATING INSTRUCTIONS

The VEVOR Insert Range Hood features intuitive push-button controls for easy operation.

Control Panel

The control panel is located on the front of the unit and includes buttons for power, fan speed adjustment, and

lighting.



Control Panel with Push Buttons for Fan Speed and Lights.

This image highlights the user-friendly push-button control panel, showing the On/Off, Speed (Low, Mid, High), and Light buttons.

Fan Speed Adjustment

Press the 'Speed' buttons to cycle through the three available fan speeds:

- **Low (200 CFM):** Ideal for light cooking, simmering, or maintaining air quality.
- **Medium (500 CFM):** Suitable for everyday cooking tasks like sautéing.
- **High (800 CFM):** Provides maximum suction for heavy cooking, frying, or stir-frying.

STRONG & QUIET SUCTION

High-efficiently suck up the cooking oil fumes

- Noise Low at 62dB
- 125W Galvanized Motor



200CFM Low Speed



Stewing



500CFM Mid Speed



Roasting



800CFM High Speed



Stir-frying

Fan Speed Settings for Various Cooking Needs.

This visual guide illustrates the effectiveness of each fan speed setting (Low, Mid, High) for different cooking activities such as stewing, roasting, and stir-frying.

LED Lighting

Press the 'Light' button on the control panel to turn the LED lights on or off. The two 3W LED lamps provide ample illumination for your cooking surface.

MAINTENANCE AND CLEANING

Regular maintenance ensures the longevity and efficient operation of your VEVOR range hood.

Filter Cleaning

The stainless steel baffle filters should be cleaned regularly (e.g., monthly, depending on cooking frequency) to prevent grease buildup.

- To remove: Locate the clips on the filter plates. Push the clip inward and pull the filter down.
- Cleaning: The baffle filters are dishwasher safe. Alternatively, wash them by hand with warm, soapy water. Rinse

thoroughly and allow to dry completely before reinstallation.

- To reinstall: Align the filter with the slots and push it up until the clips secure it in place.



Removable Baffle Filters for Easy Cleaning.

This image provides a clear view of the underside of the range hood, showing the easily detachable baffle filters designed for convenient cleaning.

Charcoal Filter Replacement (Ductless Mode Only)

If operating in ductless mode, the activated charcoal filters should be replaced every 3-6 months, depending on usage. These filters are not washable and must be replaced.

- To replace: Remove the baffle filters. The charcoal filters are typically attached to the motor housing. Twist or unclip the old filters and replace with new ones.

Exterior Cleaning

Clean the stainless steel exterior with a soft cloth and a non-abrasive stainless steel cleaner. Always wipe in the direction of the grain to avoid scratching. Do not use abrasive cleaners or scouring pads.

TROUBLESHOOTING

If you encounter issues with your range hood, refer to the following table for common problems and solutions.

Common Troubleshooting Guide

Problem	Possible Cause	Solution
Fan does not operate	No power supply; Motor malfunction; Control panel issue	Check power connection and circuit breaker. Contact customer support if motor or control panel is faulty.
Lights do not work	Bulb failure; Wiring issue; Control panel issue	Replace LED bulbs if faulty. Check wiring connections. Contact customer support if control panel is faulty.
Insufficient suction	Clogged filters; Improper ducting; Motor speed too low	Clean or replace filters. Ensure ducting is correctly installed and free of obstructions. Increase fan speed.
Excessive noise	Loose parts; Obstruction in fan; Improper installation	Check for loose screws or components. Remove any obstructions. Ensure proper installation and secure mounting.

PRODUCT SPECIFICATIONS

Detailed technical specifications for the VEVOR Insert Range Hood Model E70-36.

VEVOR Insert Range Hood E70-36 Specifications

Feature	Specification
Model	E70-36
Body Material	201 Stainless Steel
Air Flow Capacity	800 Cubic Feet Per Minute (CFM)
Number of Speeds	3 (200/500/800 CFM)
Control Type	Push Button Control
Noise Level	62dB (Max)
Motor Power	125W
LED Light Power	3W (x2)
Duct Length	59.1 inch / 1.5 m
Product Dimensions	35.5 x 11.5 x 15.3 inch / 90.2 x 29.3 x 38.9 cm
Product Weight	32 lbs / 14.5 kg
Filter Type	Baffle (Stainless Steel), Charcoal (for ductless)
Ventilation Type	Ducted/Ductless Convertible
Certification	ETL Listed
Voltage	110 Volts

WARRANTY AND SUPPORT

VEVOR products are designed for durability and performance. This product comes with a standard warranty. For specific warranty details, please refer to the warranty card included in your product packaging or visit the official VEVOR website.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact VEVOR customer service. Have your model number (E70-36) and purchase date ready when contacting support.

You can find more information and support resources on the VEVOR official website:www.vevor.com