navycrest A1 Pro

navycrest Dash Cam Mount for A1 Pro Car Dash Camera User Manual

Model: A1 Pro Dash Cam Mount

---

1. INTRODUCTION

This manual provides essential instructions for the proper installation, operation, and maintenance of your navycrest Dash Cam Mount, designed specifically for the A1 Pro Car Dash Camera. Please read this manual thoroughly before use to ensure optimal performance and longevity of your product.

The navycrest Dash Cam Mount offers a secure and stable platform for your A1 Pro dash camera, ensuring reliable recording while driving. Its compact design integrates seamlessly with your vehicle's interior.

2. PRODUCT COMPONENTS

The navycrest Dash Cam Mount consists of a compact housing with a multi-pin connector for the dash camera and ports for external connections. Familiarize yourself with the components:

Image 1: Front view of the navycrest Dash Cam Mount. It features a square design with a multi-pin connector on one side for attaching to the dash camera. The top edge includes an AV port and a Type-C port for power and data connections.

- **Mount Body:** The main structure that secures the dash camera.
- **Multi-pin Connector:** Located on the front, designed to interface with the A1 Pro Dash Camera.
- **AV Port:** For audio/video output (if supported by the dash cam).
- **Type-C Port:** For power input and data transfer.

3. SETUP AND INSTALLATION

Follow these steps to correctly install your dash cam mount:

1. **Prepare the Mounting Surface:** Ensure the chosen area on your windshield or dashboard is clean, dry, and free of dust or grease. Use an alcohol wipe for best results. This ensures strong adhesion.

2. **Attach Mount to Dash Cam:** Align the multi-pin connector on the mount with the corresponding port on your navycrest A1 Pro Dash Camera. Gently push the camera onto the mount until it clicks securely into place.

3. **Secure Mount to Vehicle:** Remove the protective film from the adhesive pad on the mount. Press the mount firmly onto the prepared surface in your vehicle for at least 30 seconds. Apply consistent pressure to ensure proper adhesion.

4. **Connect Power:** Insert the Type-C power cable into the Type-C port on the mount. Connect the other end to your vehicle's power source (e.g., cigarette lighter adapter).

5. **Adjust Angle:** Once secured, adjust the angle of the dash camera to ensure it captures the desired field of view.

4. OPERATING INSTRUCTIONS

The mount itself does not require active operation. Its primary function is to securely hold the dash camera and provide connectivity for power and data.

- **Power Connection:** The Type-C port on the mount facilitates power delivery to the connected A1 Pro Dash Camera. Ensure the power cable is securely connected for continuous operation of the dash cam.

- **AV Output:** If your setup requires external display, connect an AV cable to the AV port on the mount. Refer to your A1 Pro Dash Camera manual for specific AV output functions.

- **Removal:** To remove the dash camera from the mount, gently press any release tabs (if present on your A1 Pro camera) and slide the camera off the multi-pin connector. To remove the mount from the vehicle, carefully peel it off the surface, taking care not to damage the adhesive or vehicle interior.

5. CARE AND MAINTENANCE

Proper maintenance ensures the longevity and reliability of your dash cam mount.

- **Cleaning:** Use a soft, dry cloth to wipe the mount's surface. Avoid abrasive cleaners or solvents, which can damage the material or finish.

- **Adhesive Care:** If the mount needs to be re-positioned, ensure the new surface is clean. The adhesive may lose effectiveness after multiple removals. Consider using a new adhesive pad if necessary to maintain secure attachment.

- **Port Inspection:** Periodically check the AV and Type-C ports for dust or debris. Use a soft brush or compressed air to gently clean them if needed to ensure proper connectivity.

6. TROUBLESHOOTING

If you encounter issues with your navycrest Dash Cam Mount, refer to the following common solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Mount does not adhere securely to the surface.	Surface was dirty, oily, or not dry. Adhesive pad is worn.	Clean the surface thoroughly with an alcohol wipe and let it dry completely before re-applying. If the adhesive is worn, replace it with a new, strong adhesive pad.
Dash camera is loose on the mount.	Camera not fully engaged with the multi-pin connector. Connector pins are damaged.	Ensure the camera is pushed firmly onto the mount until it locks. Inspect the multi-pin connector for any visible damage. If damaged, contact customer support.
Dash camera not receiving power through the mount.	Type-C cable not fully inserted. Cable or power source faulty. Internal connection issue.	Verify the Type-C cable is securely plugged into both the mount and the power source. Test the cable and power source with another device if possible. Ensure the dash camera is correctly seated on the mount's multi-pin connector.

7. PRODUCT SPECIFICATIONS

The following are the technical specifications for the navycrest Dash Cam Mount:

- **Model Compatibility:** Specifically designed for navycrest A1 Pro Car Dash Camera.
- **Dimensions:** Approximately 1.5 x 1 x 0.5 inches (L x W x H).
- **Weight:** Approximately 0.49 ounces.
- **Connectivity:** Multi-pin connector for camera, AV port, Type-C port for power.
- **Mounting Type:** Adhesive.
- **Material:** Durable plastic and metal components.

8. WARRANTY AND CUSTOMER SUPPORT

Warranty Information:

Every navycrest product is covered by a one-year warranty from the date of purchase. This warranty covers manufacturing defects and ensures your product functions as intended under normal use. Please retain your proof of purchase for warranty claims.

Customer Support:

For technical assistance, troubleshooting, or any questions regarding your navycrest Dash Cam Mount, please contact our customer care team. We aim to respond to all inquiries within 12 hours.

Contact: Please refer to your product packaging or the official navycrest website for the most current customer service contact information (e.g., email address).

If you are not satisfied with your purchase, a full refund is available within 30 days of purchase, subject to return policy terms.

[Navycrest A3 4K-WiFi Dash Cam User Manual | Installation, Features & Support](#)
Comprehensive user manual for the Navycrest A3 4K-WiFi Dash Cam. Learn about installation, features, WiFi connection, app usage, troubleshooting, and support. Includes setup guides and FAQs.

[Navycrest Q7 2.5K Front & Rear 5G WiFi Dash Cam User Manual](#)
User manual for the Navycrest Q7 dash cam, covering installation, features, troubleshooting, and support. Learn how to set up and use your 2.5K front and rear dash cam with 5G WiFi.

[Navycrest A3 4K-WiFi Dash Cam User Manual | Installation, Setup, and Troubleshooting](#)
Comprehensive user manual for the Navycrest A3 4K-WiFi Dash Cam. Learn about installation, WiFi connection, app usage, settings, parking mode, and frequently asked questions.

[A2-4K Channel Dash Cam Quick Start Guide | Navycrest](#)
Get started with your Navycrest A2-4K Channel dash cam. This quick start guide covers SD card insertion, power connection, formatting, 24-hour recording, WiFi troubleshooting, and warranty registration.

[Navycrest A2 Pro Dash Cam Quick Setup Guide](#)
A quick start guide for the Navycrest A2 Pro dash cam, covering SD card insertion, power connection, rear camera connection, SD card formatting, and 24-hour recording setup. Includes important precautions and warranty information.

[A1-4K Dash Cam: Installation, Features, and FAQs](#)
Comprehensive guide for the Navycrest A1-4K dash cam, covering installation, warranty registration, troubleshooting common issues (power, SD card, WiFi), and detailed explanations of parking monitor modes. Includes recommended accessories and support contact.