

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [KLARSTEIN](#) /

› [Klarstein Monumenta Extractor Hood User Manual](#)

## KLARSTEIN 10039395

# Klarstein Monumenta Extractor Hood User Manual

Model: 10039395 (CGCH3-Monumenta-SS)

Brand: KLARSTEIN

## 1. IMPORTANT SAFETY INFORMATION

Please read this manual carefully before installing and operating your Klarstein Monumenta extractor hood. Keep these instructions for future reference.

- Ensure the power supply voltage matches the rating plate on the appliance.
- Do not allow children to operate the appliance.
- Always disconnect the appliance from the power supply before cleaning or maintenance.
- Do not flambé under the range hood.
- Ensure adequate ventilation in the room when the range hood is used simultaneously with gas or other fuel-burning appliances.
- The exhaust air must not be discharged into a flue that is used for exhausting fumes from appliances burning gas or other fuels.
- Regular cleaning of the grease filter is essential to prevent fire hazards.

## 2. PRODUCT OVERVIEW

The Klarstein Monumenta is a wall-mounted extractor hood designed to efficiently remove cooking fumes and odors from your kitchen. It features a sleek stainless steel design, LED lighting, and a 5-button control panel.



Figure 1: Klarstein Monumenta extractor hood in a kitchen environment.

The hood can operate in two modes:

- **Exhaust Air Mode:** Fumes are extracted and discharged outside through a ventilation duct.
- **Recirculating Air Mode:** Fumes are filtered through activated charcoal filters and the purified air is returned to the kitchen.

## 3. SETUP AND INSTALLATION

This section provides general guidance for installing your extractor hood. For detailed steps, refer to the included multilingual user manual and consult a qualified installer if necessary.

### 3.1 Unpacking and Components

Carefully unpack the appliance and check for any damage. Ensure all components are present:

- 1 x Cooker Hood Unit
- 1 x Grease Filter (pre-installed or separate)
- 2 x Activated Carbon Filters (for recirculation mode)
- Mounting Hardware (screws, wall plugs, brackets)
- Multilingual User Manual

Figure 2: Components including grease filter and activated carbon filters.

### 3.2 Mounting the Hood

The Klarstein Monumenta is a wall-mounted canopy hood. Ensure the wall is strong enough to support the weight of the hood (approx. 12.5 kg / 27.5 lbs). Maintain the recommended distance between the cooking surface and the bottom of the hood as specified in local building codes and the detailed manual.

- Mark drilling points on the wall according to the provided template.
- Drill holes and insert wall plugs.
- Secure the mounting bracket(s) to the wall.
- Carefully lift and attach the hood to the bracket(s).
- Connect the exhaust ducting (for exhaust air mode) or install activated carbon filters (for recirculation mode).
- Connect the power supply.



Figure 3: Product dimensions for installation planning.

## 4. OPERATING INSTRUCTIONS

The Klarstein Monumenta extractor hood features a user-friendly 5-button control panel located on the front.

## 4.1 Control Panel Functions

The control panel typically includes buttons for:

- **Power ON/OFF:** To switch the hood on or off.
- **Fan Speed Selection:** Three distinct power levels (1, 2, 3) are available to adjust the extraction rate according to your cooking needs.
- **Light ON/OFF:** To control the integrated LED lighting (2 x 1.5 watts) for illuminating your cooking area.

It is recommended to switch on the extractor hood a few minutes before you start cooking and leave it running for a few minutes after you finish to ensure all fumes and odors are effectively removed.

## 5. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your extractor hood. Always disconnect the power supply before performing any maintenance.

### 5.1 Cleaning the Grease Filter

The aluminum grease filter should be cleaned regularly (approximately every 2-4 weeks, depending on usage) to prevent grease buildup and maintain extraction efficiency. The central front flap can be opened for easy access.

- Remove the grease filter by releasing its latches.
- Wash the filter by hand in hot soapy water or in a dishwasher using a mild detergent.
- Ensure the filter is completely dry before re-installing.

### 5.2 Replacing Activated Carbon Filters (Recirculation Mode)

If your hood is operating in recirculation mode, the activated carbon filters need to be replaced periodically (typically every 3-6 months, depending on usage) as they cannot be washed. Used filters lose their odor-absorbing capacity.

- Remove the grease filter to access the activated carbon filters.
- Twist or unlatch the old carbon filters to remove them.
- Install new activated carbon filters, ensuring they are securely in place.
- Matching replacement activated charcoal filters are available under item number 10030727.

### 5.3 Cleaning the Exterior

Clean the stainless steel exterior with a soft cloth and a non-abrasive cleaner specifically designed for stainless steel. Avoid harsh chemicals or abrasive pads that could scratch the surface.

## 6. TROUBLESHOOTING

If you encounter issues with your extractor hood, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Hood does not turn on	No power supply; Power cord disconnected; Fuse blown.	Check power connection; Ensure plug is fully inserted; Check household fuse/circuit breaker.

Problem	Possible Cause	Solution
Poor extraction performance	Grease filter clogged; Activated carbon filters saturated (recirculation mode); Incorrect fan speed; Insufficient room ventilation.	Clean grease filter; Replace activated carbon filters; Select higher fan speed; Ensure windows/doors are slightly open for air intake.
Excessive noise	Loose components; Improper installation; Obstruction in ducting.	Check for loose screws or parts; Verify correct installation; Inspect ducting for blockages.
Lights not working	Light bulb faulty; Electrical connection issue.	Replace LED bulb (if replaceable); Check wiring connections (consult a technician).

If the problem persists after attempting these solutions, please contact Klarstein customer support.

## 7. SPECIFICATIONS

Feature	Specification
Model	10039395 (CGCH3-Monumenta-SS)
Type	Wall-mounted Extractor Hood
Material	Stainless Steel
Air Flow Capacity	Up to 559 m <sup>3</sup> /h
Number of Speeds	3
Noise Level	Max. 68 dB
Lighting	2 x 1.5 Watt LED
Filter Type	Aluminum Grease Filter, Activated Carbon Filter (for recirculation)
Controls	Push Button (5-button control panel)
Energy Efficiency Class	B
Product Dimensions (WxHxD)	Approx. 40 x 89 x 31.5 cm (15.75 x 35.04 x 12.4 inches)
Item Weight	Approx. 12.5 kg (27.5 lbs)
Power Supply	220-240 V~   50/60 Hz
Motor Power	190 Watt

## 8. WARRANTY AND SUPPORT

For warranty information, technical support, or service requests, please refer to the warranty card included with your product or contact Klarstein customer service directly. Ensure you have your model number (10039395) and purchase details available when contacting support.

Additional resources, including FAQs and further product documentation, may be available on the official Klarstein website.

